




# HONDA

## CB350F



# 4

Courtesy of  Honda4Fun  
[www.hondastour.com](http://www.hondastour.com) [www.honda4fun.com](http://www.honda4fun.com)

# PARTS LIST

## HONDA GENUINE PARTS

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## E-1 Cylinder Head Cover

Ref. No.	Part No.	Description	Reqd. No. CB350F	Serial No.	Export Area
1	12310-333-020	COVER, CYLINDER HEAD	1		
2	12320-333-020	COVER COMP., BREATHER	1		
3	12329-333-010	GASKET, BREATHER COVER	1		
4	12361-300-000	CAP, TAPPET ADJUSTING WOLE	8		
5	12391-333-000	GASKET, CYLINDER HEAD COVER	1		
6	12431-333-010	GEAR, TACHOMETER	1		
7	12435-333-000	COLLAR, TACHOMETER GEAR	1		
8	15761-303-000	TUBE, BREATHER	1		
9	15772-292-010	CLIP, BREATHER TUBE	1		
10	50018-333-000	BOLT, U.B.S. 6X38	2		
11	90084-333-000	BOLT, SEALING	4		
12	50457-333-000	WASHER, THRUST, 12 MM	1		
13	50458-324-010	WASHER, THRUST, 6.7MM	1		
14	50601-333-000	SET RING, 12.7MM	1		
15	91201-324-010	OIL SEAL, 6.5X14.5X7	1		
16	91302-001-020	O-RING, 30.8MM	8		
17	93700-05020-0A	SCREW, OVAL, 5X20	1		
18	94109-14000	WASHER, DRAIN PLUG, 14MM	4		
19	95700-06028	BOLT, FLANGE, 6X28	9		
20	95700-06032	BOLT, FLANGE, 6X32	6		
21	95700-06035	BOLT, FLANGE, 6X35	2		
22	95700-06040	BOLT, FLANGE, 6X40	3		
23	95700-06060	BOLT, FLANGE, 6X60	5		

## E-6 Oil Filter · Oil Pan

Ref. No.	Part No.	Description	Reqd. No. CB350F	Serial No.	Export Area
1	11210-333-020	PAN, OIL	1		
2	11398-333-020	GASKET, OIL PAN	1		
3	15151-333-000	SCREEN, OIL STRAINER	1		
4	15152-333-000	PLATE, OIL SEPARATOR	1		
5	15153-333-000	BODY, OIL SCREEN	1		
6	15155-333-000	PIPE, MISSION OIL	1		
7	15157-333-000	SPRING, OIL SCREEN SETTING	1		
8	15411-333-000	CASE, OIL FILTER	1		
9	15412-300-024	ELEMENT, OIL FILTER (TOKYO ROKI)	1		
10	15414-300-000	SEAT, OIL FILTER SPRING	1		
11	15415-300-000	SPRING, OIL FILTER ELEMENT SET	1		
12	15420-333-000	BOLT COMP., OIL FILTER CENTER	1		
13	15423-333-000	COLLAR, OIL FILTER BOLT	1		
14	15473-300-300	VALVE, CHECK	1		
15	15474-300-310	SPRING, CHECK VALVE	1		
16	15477-300-300	PIN, SPRING SET	1		
17	51302-028-000	O-RING, 15X2.5	1		
18	91316-300-003	O-RING, 89X4.5	1		
19	51329-590-003	O-RING, 16.5X2	1		
20	92800-12000	BOLT, DRAIN PLUG, 12MM	1		
21	93500-06012	SCREW, PAN, 6X12	4		
22	54109-12000	WASHER, DRAIN PLUG, 12MM	1		
23	95700-06040	BOLT, FLANGE, 6X40	11		



## E-11 A.C. Generator

Ref. No.	Part No.	Description	Reqd. No. CB356F	Serial No.	Export Area
1	11631-333-010	COVER A, DYNAMO	1		
2	11632-333-010	COVER B, DYNAMO	1		
3	11691-333-000	GASKET, DYNAMO COVER	1		
4	21101-333-004	ROTOR COMP. (ND)	1		
5	21102-333-004	STATOR COMP. (ND)	1		
6	21103-333-004	COIL COMP., FIELD (ND)	1		
7	21110-333-000	HARNES, A.C. GENERATOR WIRE	1		
8	35750-333-013	SWITCH ASSY, NEUTRAL 35750-333-023	1	1067277	
	35750-333-023	SWITCH, NEUTRAL (TOYO)	1	1067278	
9	35751-333-003	O-RING	1		
10	35755-333-010	PLATE, NEUTRAL SWITCH FIXING	1		
11	50014-333-000	BOLT, HEX., 10X32	1		
12	93500-06012	SCREW, PAN, 6X12	1		
13	93500-06016	SCREW, PAN, 6X16	3		
14	93500-06032	SCREW, PAN, 6X32	3		
15	93500-06040	SCREW, PAN, 6X40	2		
16	93500-06055	SCREW, PAN, 6X55	2		
17	93700-04012-08	SCREW, OVAL, 4X12	2		



## E-16 Transmission

Ref. No.	Part No.	Description	Reqd. No. CB350F	Serial No.	Export Area
1	13492-283-000	RING, BEARING SET, 52MM	2		
2	23211-333-030	SHAFT, TRANSMISSION MAIN	1		
3	23220-333-010	SHAFT, TRANSMISSION COUNTER	1		
4	23420-333-000	GEAR, COUNTER SHAFT LOW	1		
5	23431-333-010	GEAR, MAIN SHAFT SECOND	1		
6	23451-333-000	GEAR, MAIN SHAFT THIRD	1		
7	23461-333-010	GEAR, COUNTER SHAFT THIRD	1		
8	23471-333-000	GEAR, MAIN SHAFT FOURTH	1		
9	23481-333-000	GEAR, COUNTER SHAFT FOURTH	1		
10	23491-333-020	GEAR, MAIN SHAFT FIFTH	1		
11	23501-333-000	GEAR, COUNTER SHAFT FIFTH	1		
12	23801-333-000	SPROCKET, DRIVE (17T)	1		
13	23811-292-000	PLATE, DRIVE SPROCKET FIXING	1		
14	24261-283-000	PIN, GEAR SHIFT FORK GUIDE	2		
15	50411-333-000	WASHER, 20MM	3		
16	50451-300-000	WASHER, THRUST, 25MM	4		
17	50601-300-000	CIR CLIP, 25MM	4		
18	91002-286-008	BEARING, BALL, 52C5HS (TOYO)	1		
19	91022-333-018	BEARING, NEEDLE, 20MM (TOYO)	2		
20	91205-333-005	OIL SEAL, 34X52X13.5X15.5	1		
21	91207-333-000	OIL SEAL, 34X9	1		
22	92000-C6012	BOLT, HEX., 6X12	2		



## F-1 Right Handle Switch - Cable

Ref. No.	Part No.	Description	Reqd. No. CR350F	Serial No.	Export Area
1	17910-333-000	CABLE COMP. A; THROTTLE	1		A;D;E;I;T
	17910-333-610	CABLE COMP. A; THROTTLE	1		F;G
2	17920-333-000	CABLE COMP. B; THROTTLE	1		A;D;E;I;T
	17920-333-610	CABLE COMP. B; THROTTLE	1		F;G
3	35300-333-610	SWITCH ASSY.; LIGHTING DIMMER KILL	1		F;D;F;G;I;T
	35300-333-671	SWITCH ASSY.; LIGHTING DIMMER KILL	1		A;D
4	35315-235-000	KNOB; LIGHTING SWITCH	1		
5	35317-001-310	BUTTON; HORN SWITCH PUSH	1		
6	35318-259-000	SPRING; HORN BUTTON SWITCH	1		
7	53141-300-010	PIPE; THROTTLE GRIP	1		
8	53163-300-020	ADJUSTER; THROTTLE GRIP	1		
9	53165-342-670	RUBBER; GRIP RIGHT	1		
10	53190-300-000	BOLT; THROTTLE GRIP ADJUSTING	1		
11	53191-300-000	SPRING; THROTTLE ADJUSTER	1		
12	88100-333-004	MIRROR; RIGHT REAR VIEW	1		A;D
	88100-333-610	MIRROR; RIGHT REAR VIEW	1		E;D;G;I;T
	88110-304-621	MIRROR; RIGHT REAR VIEW	1		F
13	93500-05025-0A	SCREW; PAN. 5X25	1		
14	93500-05032-0A	SCREW; PAN. 5X32	1		

FRAME GROUP

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

## F-6 Front Brake Caliper - Disk

Ref. No.	Part No.	Description	Reqd. No. CB350F	Serial No.	Export Area
1	45100-323-043	CALIPER ASSY. (TOKIKO)	1		
2	45101-323-013	CALIPER A (TOKIKO)	1		
3	45102-323-003	CALIPER B (TOKIKO)	1		
4	45104-317-700	JOINT, CALIPER HOLDER	1		
5	45105-323-043	PAD COMP. A (TOKIKO)	1		
6	45106-323-006	PAD COMP. B (SAHII)	1		A+D+ED+F+C
	45106-323-013	PAD COMP. P (TOKIKO)	1		
7	45107-323-020	PISTON COMP.	1		
8	45108-300-003	SEAL, PISTON (TOKIKO)	1		
9	45115-323-010	HOLDER, CALIPER	1		
10	45116-323-010	PIN, CALIPER HOLDER 45116-323-020	1	1055093	A+D+ED+F+C
	45116-323-020	PIN, CALIPER HOLDER	1	1055094	A+D+ED+F+C IF
11	45117-300-020	BOLT, CALIPER ADJUSTING	1		
12	45119-333-000	SPRING, CALIPER ADJUST	1		
13	45120-317-701	DISK COMP., FRONT BRAKE	1	1065402	
	45120-369-000	DISK COMP., FRONT BRAKE	1	1065403	
14	45140-333-000	COVER COMP., DISK	1		
15	45224-579-013	VALVE, BLEEDER	1		
16	45225-579-013	CAP, BLEEDER	1		
17	90165-323-000	BOLT, CALIPER SETTING	2		
18	90309-357-000	NUT, HEX., 8MM	4	1070100	
19	90522-317-700	WASHER, TONGUED, 8MM	2	1070099	
20	91259-333-000	O-RING, 9.5X1.7	2		
21	92200-06029	BOLT, HEX., AX2R	2		
22	92700-08045	BOLT, STUD, AX45	1		
23	94001-06000	NUT, HEX., 6MM	1		
24	94001-08000-05	NUT, HEX., 8MM / 1070099 (5)	1	1070100	
25	94101-06000	WASHER, PLAIN, 6MM	2		
26	94102-10000	WASHER, PLAIN, 10MM	2		
27	94111-06000	WASHER, SPRING, 6MM	2		
28	94111-08000	WASHER, SPRING, 8MM	1		
29	94201-16220	PIN, SPLIT, 1.6X22	1		



## F-10 Steering Stem

Ref. No.	Part No.	Description	Req. No. CB350F	Serial No.	Export Area
1	5C301-268-305	RACE, STEERING TOP BALL	1		
2	5C302-268-305	RACE, STEERING BOTTOM BALL	1		
3	53124-250-000	SEAL, STEERING HEAD DUST	1		
4	53200-333-000B	STEM COMP., STEERING	1		A+D
→	53200-333-610B	STEM COMP., STEERING	1		E0+I, G+IT
5	53211-268-305	RACE, STEERING TOP CONE	1		
6	53212-250-305	RACE, STEERING BOTTOM CONE	1		
7	53215-250-000	WASHER, STEERING HEAD DUST SEAL	1		
8	53215-317-000	COVER COMP., HANDLE LOCK CASE	1		A+D
9	53220-286-000	THREAD COMP., STEERING HEAD TOP	1		
10	53225-333-000	GUIDE, INNER CABLE	1		
11	53226-333-000	BRACKET, CABLE GUIDE	1		
12	53600-230-004	LOCK COMP., STEERING HANDLE (TOYO)	1		A+D
13	53631-268-020	SPRING, HANDLE LOCK	1		A+D
14	90304-323-670	NUT, STEERING STEM	1		
15	90503-283-000	WASHER, STEERING STEM	1		
16	92000-08032-0A	BOLT, HEX., BX32	2		
17	93500-03009-0A	SCREW, PAN, 3X8	1		A+D
18	94101-03000	WASHER, PLAIN, 3PP	1		A+D
19	94101-08000	WASHER, PLAIN, 8PP	2		
20	96211-08000	BALL, STEEL, #0	37		



## F-15 Exhaust Muffler

Ref. No.	Part No.	Description	Req. No. CD150F	Serial No.	Export Area
1	18231-333-010	JOINT, EXHAUST PIPE	4		
2	18233-303-010	COLLAR, EXHAUST PIPE JOINT	8		
3	18291-028-000	GASKET, EXHAUST PIPE	4		
4	18300-333-010	MUFFLER COMP. 1, EXHAUST 18300-333-610	1	1055093	A+B
	18300-333-610	MUFFLER COMP. 1, EXHAUST	1	1055094	A+B C+D+E
	18300-333-710	MUFFLER COMP. 1, EXHAUST	1		IT
5	18325-333-000	BRACKET, RIGHT MUFFLER	1		
6	18400-333-010	MUFFLER COMP. 2, EXHAUST 18400-333-610	1	1055093	A+B
	18400-333-610	MUFFLER COMP. 2, EXHAUST	1	1055094	A+B C+D+E
	18400-333-710	MUFFLER COMP. 2, EXHAUST	1		IT
7	18425-333-000	BRACKET, LEFT MUFFLER	1		
8	18472-300-000	TUBE, MUFFLER CONNECTING	2		
9	18473-300-000	BAND, MUFFLER CONNECTING	2		
10	18500-333-010	MUFFLER COMP. 3, EXHAUST 18500-333-610	1	1055093	A+B
	18500-333-610	MUFFLER COMP. 3, EXHAUST	1	1055094	A+B C+D+E
	18500-333-710	MUFFLER COMP. 3, EXHAUST	1		IT
11	18600-333-010	MUFFLER COMP. 4, EXHAUST 18600-333-610	1	1055093	A+B
	18600-333-610	MUFFLER COMP. 4, EXHAUST	1	1055094	A+B C+D+E
	18600-333-710	MUFFLER COMP. 4, EXHAUST	1		IT
12	93500-05016-00	SCREW PAN, 5X16	2		
13	94001-06000	NUT, HEX., 8MM	8		
14	94001-08000-00	NUT, HEX., 8MM	8		
15	94111-08000	WASHER, SPRING, 8MM	8		
16	95011-64000	RUBBER D, STAND STOPPER	1		



## F-20 Rear Fender

Ref. No.	Part No.	Description	Reqd. No. CB350F	Serial No.	Export Area
1	32983-011-000	GROMMET, WIRE COND	2		
2	32985-300-000	GROMMET, WIRE COND	2		
3	50400-333-000	PIPE, REAR	1		4+D+F0+F+IT
	50400-333-610	PIPE, REAR	1		G
4	60100-333-000XW	FENDER COMP., REAR	1		4+D+F
	60100-333-610XW	FENDER COMP., REAR	1		G
	60100-333-730XW	FENDER COMP., REAR	1		FD+IT
5	60105-333-000	FENDER B ASSY., REAR	1		
6	60121-317-731	MURGUARD, REAR FENDER	1		FD+IT
7	67507-333-610	MARK, TIRE CAUTION	1		G
	67507-333-670	MARK, TIRE CAUTION	1		G
	67507-333-680	MARK, TIRE CAUTION	1		D+FD+F+IT
8	50512-300-000	WASHER, 6X20	2		
9	52000-C6020	BOLT, HEX., 6X20	2		
10	53000-C8065-08	BOLT, HEX., 6X65	2		
11	53500-06C20-49	SCREW, PAN, 6X20	3		FD+IT
12	54001-06C00	NUT, HEX., 6MM	2		FD+IT
13	54001-08C00-05	NUT, HEX., 8MM	2		
14	54101-06C00	WASHER, PLAIN, 6MM	2		
15	54101-08C00	WASHER, PLAIN, 8MM	2		
16	54111-06C00	WASHER, SPRING, 6MM	3		FD+IT



## F-23 Turn Signal (Used in A,D,ED,F & IT)

Ref. No.	Part No.	Description	Req'd. No. CB350F	Serial No.	Export Area
1	33400-292-670	LIGHT ASSY., RIGHT FRONT TURN SIGNAL	1	1040853	A D
	33400-292-003	LIGHT ASSY., RIGHT FRONT TURN SIGNAL	1		F
	33400-317-730	LIGHT ASSY., RIGHT FRONT TURN SIGNAL	1		ED+IT
	33600-306-670	LIGHT ASSY., RIGHT REAR TURN SIGNAL	1	1040854	A
2	33401-292-003	BASE, RIGHT FRONT TURN SIGNAL	4		A+D+ED+F+IT
2	33402-268-671	LENS, FRONT TURN SIGNAL	4 2		A+D+F ED+IT
4	33407-267-003	SOCKET, RIGHT FRONT TURN SIGNAL	1	1040853	A
	33610-306-670	SOCKET COMP., RIGHT REAR TURN SIGNAL	1	1040854	A
4	33407-264-000	HOLDER, TURN SIGNAL SOCKET	4		A+D+ED+F+IT
4	33408-284-000	RUBBER, TURN SIGNAL CUSHION 33409-341-701	4	1072359	A+D+ED+F+IT
	33404-341-701	RUBBER, TURN SIGNAL CUSHION	4	1072360	A+D+D+IT
7	33410-292-000	CORP, FRONT TURN SIGNAL SUP	1 1	1040853	A D+ED+F+IT
8	33441-333-000	STAY, REAR TURN SIGNAL	2 2	1040853	A D+ED+F+IT
	33441-455-670	STAY, REAR TURN SIGNAL	2	1040854	A
9	33443-268-671	PACKING, FRONT TURN SIGNAL LENS	4		A+D+ED+F+IT
10	33450-292-670	LIGHT ASSY., LEFT FRONT TURN SIGNAL	1 1	1040853	A D
	33450-292-003	LIGHT ASSY., LEFT FRONT TURN SIGNAL	1		F
	33450-317-730	LIGHT ASSY., LEFT FRONT TURN SIGNAL	1		ED+IT
	33650-306-670	LIGHT ASSY., LEFT FRONT TURN SIGNAL	2	1040854	A
11	33453-292-003	SOCKET COMP., LEFT TURN SIGNAL	1 1	1040853	A D+F+D+F+IT
	33660-306-670	SOCKET, LEFT REAR TURN SIGNAL	2	1040854	A
12	33460-292-650	CORP, FRONT TURN SIGNAL SUP	1 1	1040853	A D+ED+F+IT
13	33600-300-000	LIGHT ASSY., RIGHT REAR TURN SIGNAL	1		A+D
	33600-333-620	LIGHT ASSY., RIGHT REAR TURN SIGNAL	1		F
	33600-333-730	LIGHT ASSY., RIGHT REAR TURN SIGNAL	1		ED+IT
14	33602-323-631	LENS, REAR TURN SIGNAL	2		ED+IT

## F-24-2 Tail Light (Used in G)

Ref. No.	Part No.	Description	Reqd. No. CB310F	Serial No.	Export Area
1	33700-292-610	TAIL LIGHT ASSY	1		G
2	33701-051-000	LENS, TAIL & STOP LAMP	1		G
3	33707-292-610	CORD, COMP., TAIL LIGHT	1		G
4	33708-292-610	CORD, STOP LIGHT	1		G
5	33709-051-000	PACKING, TAIL LIGHT LENS	1		G
6	33710-292-610	SOCKET, TAIL LIGHT	1		G
7	33715-051-000	LENS, LICENSE	1		G
8	33716-051-000	PLATE, INTERCEPTION	1		G
9	33717-292-610	BOLT, TAIL LIGHT SETTING	2		G
10	33741-333-610	REFLECTOR, REFLEX	1		G
11	64701-292-610R	BRACKET, NUMBER PLATE	1		G
12	64905-333-000	RUBBER, CUSHION	4		G
13	64906-118-000	COLLAR, NUMBER BRACKET	4		G
14	90525-030-000	WASHER, HANDLE HOLDER SETTING	4		G
15	92000-06C25-02	BOLT, HEX., 6X25	4		G
16	93500-03045-08	SCREW, PAN, 3X45	2		G
17	94001-06C00	NUT, HEX., 6MM	1		G
18	94111-06C00	WASHER, SPRING, 6MM	1		G
19		BULB, TAIL LIGHT STOP (LOCAL PROCUREMENT)	1		G
20		BULB, TAIL (LOCAL PROCUREMENT)	1		G



## F-29 Kick Arm - Change Pedal

Ref. No.	Part No.	Description	Req. No. CB350F	Serial No.	Export Area
1	24700-333-000	PEDAL COPP., GEAR CHANGE	1		
2	29241-333-010	JOINT, KICK ARM	1		
3	22293-333-000	CLIP, KICK STARTER ARM	1		
4	28794-333-000	WASHER, KICK ARM	1		
4	28300-333-010	ARM ASSY., KICK STARTER	1		
6	28301-333-010	ARM, KICK STARTER	1		
7	29305-333-010	CAP, KICK ARM	1		
7	28211-329-000	RUBBER, KICK STARTER	1		
9	28323-333-000	SPRING, KICK STARTER STOPPER	1		
10	92000-06020	BOLT, HEX., 6X20	1		
11	92000-06035	BOLT, HEX., 6X35	1		
12	55011-40000	RUBBER, CHANGE PEDAL	1		
13	56211-10000	BALL, STEEL, #10	1		



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL