

T3571

**S/N 3628 11001
& above**


T3571L

**S/N 3629 11001
& above**



Bobcat®

**PARTS
MANUAL**



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Cab Assy II

Item	Part Number	Denomination	Remarks	Serial Number	Qty
4	6910503	Box filter			1
5	01696.4	Washer			4
6	01590.9	Screw			4
7	63332.1	Cap			4
8	6910504	Seal			1.00m
9	6910502	Cab filter			2
10	6910929	Internal grille			2
11	6910505	Screw			4
12	61378.6	Washer			4
13	01664.2	Nut			4
21	79902.3	Sunshade			1
22	6910697	Screw			1
30	78816.6	Rear Worklight	Was 6909970		1
31	78815.8	Front worklight	Was 6909971		2
	58446.6	Bulb			3
32	01591.7	Screw			4
33	29272.2	Washer			4
34	63332.1	Cap			4
36	97504.5	Bracket			1
37	01717.8	Washer			2
38	100338-23F	Screw			2
39	6910878	Roof cowling			1
40	79581.5	Cover			1
41	101438-93V	Dome Light			1
42	01443.1	Bulb			1
43	6910505	Screw			2
44	007346-02F	Washer			2
45	100345-04U	Nut			2
46	34214.7	Screw			5
48	6911769	Seat assy	For details, see page 29		1
49	01596.6	Screw			4

Pedals Installation

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	96089.8	Support			1
	01596.6	Screw			4
	01697.2	Washer			4
12	6908480	Pedal			1
13	000350-08C	Washer			1
14	01754.1	Pin			1
15	59893.8	Brake pedal pad			1
16	98240.5	Throttle Cable			1
17	6908479	Pedal shaft			1
18	77919.9	Bracket			2
19	01605.5	Screw			6
20	100345-09A	Nut			6
21	6908478	Brake pedal			1
22	01736.8	Pin			1
23	01124.7	Spring			1
24	01608.9	Screw			1
25	01669.1	Nut			1
26	62185.4	Screw			1
27	01597.4	Screw			1
28	51851.4	Nut			2
29	6909383	Inching switch (detector)			1
30	01478.7	Screw			2
31	6910952	Washer			2
32	100345-05V	Nut			2
33	6909324	Service brake switch			1
34	01596.6	Screw			4
35	01697.2	Washer			4
36	6910649	Abutment			1
37	100345-09A	Nut			1

Door Assy

Item	Part Number	Denomination	Remarks	Serial Number	Qty
	6910733	Upper door assy	Pos. 36 to 50 ; Was 6909925		1
	6910736	Lower door assy	Pos. 1 to 4 + 8 to 35 + 51+52 ; Was 6909923		1
	6910738	Lower door and glass	Pos. 1 + 2		1
1	6910737	Lower door	Was 6910510		1
2	6908791	Glass, lower part door			1
3	6911000	Seal			1
4	6911001	Seal			1
5	01606.3	Screw			2
6	6910991	Washer			2
7	6910990	Washer			2
8	6910989	Spacer			2
9	63334.7	Nut cap			2
10	6910543	Handle			1
11	01719.4	Washer			2
12	01603.0	Screw			2
13	63334.7	Nut cap			2
14	97360.2	Door Strap			1
15	01579.2	Screw			2
16	51851.4	Nut			2
17	63333.9	Nut cap			4
18	6910994	Lock cover			1
19	29272.2	Washer			3
20	6910996	Screw			3
21	6910544	Cable			1
22	6914942	Cable stop			1
23	63334.7	Nut cap			2
24	6910546	Lock			1
25	6910997	Screw			2
26	01697.2	Washer			2
27	01668.3	Nut			2
28	6910545	Cable			1

Differential - Front Axle

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	89957.5	Differential, Complete			1
2	100485-56T	Washer			4
3	100485-55S	Pin	See 89957.4		2
5	64855.0	Disc			2
6	64856.8	Counter Disc			10
7	75774.0	Disc	Was 64857.6		8
8	66048.0	Screw			2
9	75793.0	Plate			2
10	100345-40J	Clamp			2
11	00909.2	Bearing	Was 000398-08U		2
12	92601.4	Housing		3628 11096 & below + 3629 11008 & below	1
	89921.1	Housing		3628 11097 & above + 3629 11009 & above	1
13	100338-39W	Screw			12
14	75778.1	Bevel Gear			1
15	75779.9	Shim 2.50mm	Thickness 2.50 mm		1
	75780.7	Shim 2.60mm	Thickness 2.60 mm		1
	75781.5	Shim 2.70mm	Thickness 2.70 mm		1
	75782.3	Shim 2.80mm	Thickness 2.80 mm		1
	75783.1	Shim 2.90mm	Thickness 2.90 mm		1
	75784.9	Shim 3.00mm	Thickness 3.00 mm		1
	75785.6	Shim 3.10mm	Thickness 3.10 mm		1
	75786.4	Shim 3.20mm	Thickness 3.20 mm		1
	75787.2	Shim 3.30mm	Thickness 3.30 mm		1
	75788.0	Shim 3.40mm	Thickness 3.40 mm		1
16	07187.8	Bearing			1
17	101288-39H	Spacer			1
18	100348-06X	Washer			1
19	100345-37F	Nut			1
20	64851.9	Washer			1

Differential - Rear Axle

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	100338-39W	Screw			12
2	92601.4	Housing			1
3	00909.2	Bearing			2
4	100345-40J	Clamp			2
5	75775.7	Stop Plate			2
6	66048.0	Screw			2
7	71209.1	Differential Assembly	Pos. 7 to 10		1
8	100485-55S	Pin	See 71209.1		2
9	100485-56T	Washer			4
10	75789.8	Washer			2
11	75791.4	Ring Gear	Pos. 11 to 15		1
12	100348-06X	Washer			1
13	100345-37F	Nut			1
14	64851.9	Washer			2
15	101288-39H	Spacer			1
16	75779.9	Shim 2.50mm	Thickness: 2.50 mm		2
	75780.7	Shim 2.60mm	Thickness: 2.60 mm		2
	75781.5	Shim 2.70mm	Thickness: 2.70 mm		2
	75782.3	Shim 2.80mm	Thickness: 2.80 mm		2
	75783.1	Shim 2.90mm	Thickness: 2.90 mm		2
	75784.9	Shim 3.00mm	Thickness: 3.00 mm		2
	75785.6	Shim 3.10mm	Thickness: 3.10 mm		2
	75786.4	Shim 3.20mm	Thickness: 3.20 mm		2
	75787.2	Shim 3.30mm	Thickness: 3.30 mm		2
	75788.0	Shim 3.40mm	Thickness: 3.40 mm		2
17	07187.8	Bearing			2
18	75802.9	Washer			1
19	75728.6	Clamp			1
20	97410.5	Seal			1
21	75806.0	Bracket			1
22	75805.2	Clip			1

Frame Level Installation

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	92089.2	Frame Level Cylinder Assembly	For details, see page 139		1
2	67166.9	Spindle			1
3	58880.6	Washer			2
4	06734.8	Retaining Ring			2
5	27052.0	Bush			2
6	68656.8	Mounting Block			2
7	94990.9	Screw			4
8	100345-16H	Nut			4
9	77013.1	Adapter			2
10	92126.2	Hose			2
11	100370-40B	Elbow			2
12	67198.2	Hose			2
13	77075.0	Elbow union			2
14	6911082	Hydraulic valve	Includes Pos. 15		1
15	6912537	Coil			2
16	15798.2	Screw			2
17	51851.4	Nut			2
18	6911081	Frame level selector valve	Includes Pos. 19		1
19	6912536	Coil			2
20	014375-30H	Adapter			1
21	6910691	Hose	With rear option		1
	6911059	Hose	Without rear option		1
22	77912.4	Adapter			1
23	100370-29P	Fitting			1
24	67198.2	Hose			1
25	77013.1	Adapter			1
26	6910822	Collector			1
27	022375-04U	Adapter			1

Hydrostatic Hoses and Fittings

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	NAP	Hydrostatic drive pump	Order now 6913565 ; Was 6910533 ; For details, see page 169	3628 11091 & below + 3629 11008 & below	1
	6913565	Hydrostatic pump	For details, see page 173	3628 11092 & above + 3629 11009 & above	1
2	100454-17G	Washer			4
3	89517.7	Washer			4
4	01613.9	Screw			4
5	67046.3	Adapter			3
6	014375-33L	Adapter			2
7	6909780	Pipe			1
8	100375-40U	Adapter			2
9	97880.9	Check valve			1
10	78705.1	Adapter			1
11	6913204	Hose			1
12	6910599	Hose			1
13	008372-34M	T- union			1
14	6910161	Hose			1
15	003304-21D	O-ring			4
16	92210.4	Washer			16
17	28689.8	Screw			16
18	6909745	Hose			1
19	78256.5	Hydrostatic Motor Assy	For details, see page 179		1
20	89518.5	Washer			4
21	100338-18Z	Screw			4
22	67046.3	Adapter			2
23	014375-96E	Connector			2
24	96795.0	Hose	Was 6913659		1
25	6914746	Hose	Was 6908560		1
26	96755.4	Hose			1
27	96756.2	Hose			1
28	6909746	Hose			1
29	100375-15S	Reducer			1
30	100345-34C	Nut			1

Hydrostatic Pump Assy 6913565

Item	Part Number	Denomination	Remarks	Serial Number	Qty
31	6912563	Screw			6
32	71675.3	Plug			1
33	71711.6	Spring			2
34	71736.3	Housing			1
35	6912564	Screw			3
36	6912064	Seal			2
37	71737.1	Seal-lock nut			1
38	71685.2	Slide nut			1
39	71734.8	Housing			1
40	71735.5	Screw			3
41	71733.0	Seal			2
42	71732.2	Seal			2
43	6912065	Housing			1
44	71674.6	Plug			1
45	98695.0	Gasket			1
46	6912066	Plug			1
47	71674.6	Plug			1
48	71674.6	Plug			1
49	71753.8	Screw			1
50	81424.4	Screw			1
51	81425.1	Screw			1
52	71757.9	Charge pump assy			1
53	71762.9	Flange	Also includes Pos. 69		1
54	81427.7	Valve			1
55	71585.4	Bearing			1
56	71701.7	Shaft			1
57	71702.5	Snap ring			1
58	81421.0	Axle seal kit			1
59	6912567	Plate			1
60	6912067	Screw			3
61	6912068	Screw			4

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Cylinder Block

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6912027	Cylinder block kit	Pos. 2 to 23		1
2		Cylinder block	Order Pos. 1		1
3		Bearing cap	Order Pos. 1		1
4		Bearing cap	Order Pos. 1		1
5		Bearing cap	Order Pos. 1		1
6		Bearing cap	Order Pos. 1		1
7	64627.3	Bush			10
8	64628.1	Screw			10
9	6911915	Bush			1
10	6911937	Plug			1
11	6911936	Plug			2
12	71263.8	Plug			1
13	32478.0	Plug			1
14	6911928	Plug			1
15	93379.6	Dowel			2
16	6911932	Plug			2
17	6911892	Plug			1
18	6911931	Plug			1
19	6911862	Piston cooling jet			4
20	71564.9	Screw			4
21	6911964	Plate			1
22	6911983	Gasket			1
23	71381.8	Screw			4
24	6911887	Oil seal housing			1
25	6912051	Screw			10
26	6911893	Plug			1
27	6911964	Plate			1
28	6911983	Gasket			1
29	71381.8	Screw			4
30	6911930	Plug			1
31	64988.9	Stud			8

Turbocharger

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6911993	Manifold			1
2	6911973	Gasket			1
3	93408.3	Screw			1
4	6911909	Turbocharger			1
5	6911978	Gasket			1
6	6911868	Stud			4
7	71490.7	Nut			4
8	6911957	Pipe			1
9	6911979	Gasket			1
10	6911980	Gasket			1
11	93321.8	Screw			2
12	64878.2	Screw			2
13	6912008	Pipe	Pos. 14 to 20		1
14		Pipe	Order Pos. 13		1
15	6911935	Banjo bolt			1
16	6911863	Washer			1
17	6911863	Washer			1
18	6911935	Banjo bolt			1
19	6911863	Washer			1
20	6911863	Washer			1
21	6911955	Pipe			1
22	6911889	Collar			1
23	6911949	Hose			1
24	6911889	Collar			1
25	71381.8	Screw			4
26	6911981	Gasket			1
27	6911948	Adaptor			1
28	6911868	Stud			3
29	71490.7	Nut			3
30	6911992	Exhaust elbow			1
31	71346.1	Screw			3

Air Conditioning Installation

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6915517	Belt protector	Was 6914411		1
2	01578.4	Screw			2
3	01697.2	Washer			2
4	97610.0	Washer			2
5	6908181	Spindle			1
6	90531.5	Roller			1
7	6914328	Spacer			1
8	6908180	Support			1
9	000345-96E	Nut			1
10	01522.2	Screw			1
11	000350-20Q	Washer			1
12	100345-09A	Nut			1
13	90545.5	Alternator Belt			1
14	01605.5	Screw			3
15	000350-03W	Washer			3
16	74335.1	Plug			1
17	89644.9	Compressor			1
18	54009.6	Screw			4
19	100345-09A	Nut			4
20	6909391	Support			1
21	89647.2	Hose			1
22	81439.2	Condenser			1
23	88844.6	Hose			1
24	6911207	Support			2
25	66679.2	Rivet			6
26	85171.7	Thumb Screw			2
27	6911209	Support			1
28	6911210	Support			1
29	6913148	Adhesive sponge			1
30	6911201	Support			1
31	89643.1	Dryer			1

Part Number	Denomination	WAS	Page	Subgroup
100324-04M	Screw		67	Hub Reduction - Front Axle / Rear Axle
100329-22A	Screw		111	AMA - Installation
100331-01U	Screw		39	Cowling Installation
100338-07M	Screw		19	Cab & Fixations
100338-15V	Screw		63	Axle Installation
100338-18Z	Screw		165	Hydrostatic Hoses and Fittings
100338-23F	Screw		25 289 303	Cab Assy II Rear View Mirror Rear Hydraulic Hook
100338-39W	Screw		75 85	Differential - Front Axle Differential - Rear Axle
100338-42A	Screw		83	Housing - Rear Axle
100345-04U	Nut		19 25 283	Cab & Fixations Cab Assy II Matriculation Plate Option
100345-05V	Nut		35 187 255 283 285	Pedals Installation Electrical Circuit Cab Air Conditioning Installation Matriculation Plate Option Trailer Plug
100345-06W	Nut		101 103 115 117 147 149 183 213 255 293 303 329	Steering Hoses & Fittings (without damper) Steering Hoses & Fittings (with damper) Parking Brake Hydraulic Installation Parking Brake Hydraulic Installation (accumulat Hydraulic Control Valve Fixations Hydraulic Control Valve Installation Electrical Circuit Chassis Cooling Fan Circuit (with optional reverse) Air Conditioning Installation Windshield Protection Grill Rear Hydraulic Hook Pression Retaining Kit for Rear Hydr Function
100345-09A	Nut		3 11 19 35 57 59 91 99 147 149 189 199 255 277 299 319 341	Chassis Engine Cover Cab & Fixations Pedals Installation Fixed Boom Assy End Boom Assy Boom Hydraulic Installation Lift & Compensation Cylinder Installation Hydraulic Control Valve Fixations Hydraulic Control Valve Installation Electrical Circuit Engine Engine Installation Air Conditioning Installation Tow Valve Installation Rear Hydraulic Function Fuel Pre-Filter Kit Bales Pikes
100345-11C	Nut		63	Axle Installation
100345-15G	Nut		19	Cab & Fixations
100345-16H	Nut		3 9 17 19 125	Chassis Fuel Tank Installation Engine Basket Cab & Fixations Frame Level Installation

Part Number	Denomination	WAS	Page	Subgroup
6908476	Steering column		37	Steering Column Installation
6908477	Steering wheel		37	Steering Column Installation
6908478	Brake pedal		35	Pedals Installation
6908479	Pedal shaft		35	Pedals Installation
6908480	Pedal		35	Pedals Installation
6908586	Hose		199	Engine Installation
6908594	Hose		107 109	Joystick Installation (without AMA) Joystick Installation (with AMA)
6908595	Hose		113	Service Brake Hydraulic Installation
6908633	Forks lock		339	Floating Pallet Forks
6908638	Stop		339	Floating Pallet Forks
6908656	Drift		339	Floating Pallet Forks
6908659	Forks support		339	Floating Pallet Forks
6908663	Plate		199	Engine Installation
6908672	Hose		107 109	Joystick Installation (without AMA) Joystick Installation (with AMA)
6908786	Glass, roof		21	Cab Assy
6908787	Glass, rear cab		49	Rear Window Installation
6908788	Glass, right side		21	Cab Assy
6908789	Glass, left side		25	Cab Assy II
6908790	Windshield		21	Cab Assy
6908791	Glass, lower part door		45	Door Assy
6908792	Glass, upper part door		45	Door Assy
6908847	Seal		17	Engine Basket
6908901	Hose, expansion tank		199	Engine Installation
6908902	Hose		199	Engine Installation
6909020	Plate		11	Engine Cover
6909147	Spindle		3	Chassis
6909205	Joystick spacer		195	Joystick / Susmic Installation
6909206	Support		195	Joystick / Susmic Installation
6909253	Hose		99	Lift & Compensation Cylinder Installation
6909254	Hose		97	Boom Hydraulic Supply
6909321	Tyre		265	TITAN 400/70-R20 Wheels
6909324	Service brake switch		35 187	Pedals Installation Electrical Circuit Cab
6909334	Set of wheels		265	TITAN 400/70-R20 Wheels
6909335	R.H. wheel assy		265	TITAN 400/70-R20 Wheels
6909336	L.H. wheel assy		265	TITAN 400/70-R20 Wheels
6909356	Instrument panel		41	Control Panel Switches
6909362	Accumulator		331	Lift Cylinder Accumulator Kit
6909363	Valve, lift cylinder		99	Lift & Compensation Cylinder Installation
6909383	Inching switch (detector)		35 187	Pedals Installation Electrical Circuit Cab
6909391	Support		255	Air Conditioning Installation
6909434	Hose		117	Parking Brake Hydraulic Installation (accumulat
6909439	Bush		3	Chassis

Part Number	Denomination	WAS	Page	Subgroup
6911998	Bracket		245	Turbocharger
6911999	Bracket		249	Alternator
6912002	Rocker assy		227	Rocker Shaft
6912003	Rocker assy		227	Rocker Shaft
6912004	Rocker assembly		227	Rocker Shaft
6912005	Spindle assy		227	Rocker Shaft
6912006	Pipe pump		233	Fuel Injection Equipment
6912007	Dipstick tube		231	Oil Sump - Oil Pump
6912008	Pipe		245	Turbocharger
6912009	Lift pump		237	Fuel Feeding
6912010	Oil pump		231	Oil Sump - Oil Pump
6912011	Pipe assy		243	Water Pump and Thermostat
6912012	Water inlet assy		243	Water Pump and Thermostat
6912014	Pipe assy		239	Cylinder Head Cover
6912015	Oil cooler		241	Oil Cooler and Filter
6912016	Cover assy		229	Timing Gear
6912017	Head cover assy		239	Cylinder Head Cover
6912018	Clip		233	Fuel Injection Equipment
6912019	Bottom joint and gasket		253	Engine Gaskets Sets
6912020	Top joint and gasket kit		253	Engine Gaskets Sets
6912021	Bearing		219	Crankshaft - Pistons
6912022	Bearing kit		219	Crankshaft - Pistons
6912023	Mounting kit		237	Fuel Feeding
6912024	Water pump kit		243	Water Pump and Thermostat
6912025	Repair kit		243	Water Pump and Thermostat
6912026	Piston ring kit		219	Crankshaft - Pistons
6912027	Cylinder block kit		215	Cylinder Block
6912028	Cylinder head assy		223	Cylinder Head
6912029	Crankshaft assy		219	Crankshaft - Pistons
6912030	Bar		233	Fuel Injection Equipment
6912031	Bearing kit		219	Crankshaft - Pistons
6912032	Bearing kit		219	Crankshaft - Pistons
6912033	Bearing kit		219	Crankshaft - Pistons
6912034	Bearing		219	Crankshaft - Pistons
6912035	Bearing		219	Crankshaft - Pistons
6912036	Bearing		219	Crankshaft - Pistons
6912038	Cap		233	Fuel Injection Equipment
6912040	Conrod kit		219	Crankshaft - Pistons
6912041	Conrod kit		219	Crankshaft - Pistons
6912042	Conrod kit		219	Crankshaft - Pistons
6912043	Conrod kit		219	Crankshaft - Pistons
6912044	Conrod kit		219	Crankshaft - Pistons
6912046	Crankshaft gear		219	Crankshaft - Pistons
6912047	Plug		229	Timing Gear
6912049	Belt		221	Flywheel and Drive Pulley

Part Number	Denomination	WAS	Page	Subgroup
75591.8	Lock Valve		135	Tilt Cylinder
75594.2	Hydraulic Motor Solenoid		179	Hydrostatic Motor Assy
75618.9	Bushing		127	Lift Cylinder
			129	Compensating Cylinder
			135	Tilt Cylinder
75658.5	U-joint		63	Axle Installation
			65	Cardan Shaft
75708.8	Cover Plate		71	Housing - Front Axle
75709.6	O-ring		71	Housing - Front Axle
75710.4	O-ring		71	Housing - Front Axle
75713.8	Pin		69	Reducer Box - Front Axle
75715.3	Screw		71	Housing - Front Axle
75716.1	Screw		71	Housing - Front Axle
75717.9	Breather		69	Reducer Box - Front Axle
			71	Housing - Front Axle
75722.9	Tie Rod End		77	Steering - Front Axle
			87	Steering - Rear Axle
75723.7	Tie Rod Assembly		77	Steering - Front Axle
			87	Steering - Rear Axle
75724.5	Screw		77	Steering - Front Axle
75725.2	Steering Cylinder		77	Steering - Front Axle
75726.0	Cylinder head		77	Steering - Front Axle
			87	Steering - Rear Axle
75727.8	Detector		77	Steering - Front Axle
75728.6	Clamp		77	Steering - Front Axle
			85	Differential - Rear Axle
			87	Steering - Rear Axle
75734.4	Washer		77	Steering - Front Axle
			87	Steering - Rear Axle
75739.3	Washer		83	Housing - Rear Axle
75746.8	Support		83	Housing - Rear Axle
75747.6	Bushing		83	Housing - Rear Axle
75748.4	Bushing		83	Housing - Rear Axle
75749.2	Washer		83	Housing - Rear Axle
75758.3	Steering Cylinder		87	Steering - Rear Axle
75760.9	Detector		87	Steering - Rear Axle
75762.5	Seal Kit		77	Steering - Front Axle
			87	Steering - Rear Axle
75774.0	Disc	64857.6	75	Differential - Front Axle
75775.7	Stop Plate		85	Differential - Rear Axle
75778.1	Bevel Gear		75	Differential - Front Axle
75779.9	Shim 2.50mm		75	Differential - Front Axle
			85	Differential - Rear Axle
75780.7	Shim 2.60mm		75	Differential - Front Axle
			85	Differential - Rear Axle
75781.5	Shim 2.70mm		75	Differential - Front Axle
			85	Differential - Rear Axle
75782.3	Shim 2.80mm		75	Differential - Front Axle
			85	Differential - Rear Axle

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL