




Quality Parts

FRT 2000 SE / 6

Valid for machine number..... 399076AA-399141AA

Only valid for machine number.....

--	--	--	--	--	--	--	--

Ordering number 185872

Date 1996-11-01 / ITS / ESIF

Language..... GB; SE; DE; FR

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

5830-002	Electric steering motor Elektrisk styrmotor; Elektro-Lenkmotor; Moteur de direction électrique	Electrical steering
5840-001	Fan motor Kylfläktsmotor; Lüftermotor; Ventilateur	
6000	Hydraulic/pneumatic system Hydraulik/pneumatik; Hydraulikanlage/Pneumatik; Système hydraulique/pneumatique	
6110-007	Hydraulic tank Hydraultank; Hydrauliktank; Réservoir hydraulique	
6120-054	Hoses and pipes, connection, fixation Rör-/slangledning, koppl., fastsättning; Rohr/Schlauch/Verschraubung. befestig.; Tuyaux / flexibles raccords	Triplex
6120-055	Hoses and pipes, connection, fixation Rör-/slangledning, koppl., fastsättning; Rohr/Schlauch/Verschraubung. befestig.; Tuyaux / flexibles raccords	Duplex
6120-056	Hoses and pipes, connection, fixation Rör-/slangledning, koppl., fastsättning; Rohr/Schlauch/Verschraubung. befestig.; Tuyaux / flexibles raccords	
6130-009	Filters and housing Filter, filterhus; Filter, Gehäuse; Filtres, logement de filtre	
6140-007	Hydraulic pump Hydraulpump; Hydraulikpumpe; Pompe hydraulique	
6210-010	Main valve unit lift/reach/tilt Huvudventil lyft/utskjut./tilt; Hauptventil Hub/Schub/Neigung; Soupape principale levage/rétraction/inclinaison	
7000	Operating funktion - lifting mast/cylinder Arbetsfunktion - lyftstativ/cylindrar; Arbeitsfunktion - Hubgerüst / zylinder; Fonction de travail - mat / cylindre	
7120-024	Chains / yokes / rollers Kedja/kedjeok/rullar; Kette / Kettenjoch / Rollen; Chaines / poulies	
7130-009	Main mast fork carriage Huvudstativokvagn; Gabel-/Aggregatträger Haupthubergüst; Tablier porte-fourches mât principal	
7190-006	Mast carriage, mast fixation points Stativinfästning; Mastbefestigung / Wagen; Chariot porte-mat / point fixation mat	
7210-002	Side shift / fork spread units Side shift/gaffelspridningsaggregat; Seitenwechsel / Gabelspreizung; Déplacement lateral	
7310-028	Lift cylinders Lyftcylinder; Hubzylinder; Verin de levage	Duplex
7310-029	Lift cylinders Lyftcylinder; Hubzylinder; Verin de levage	Triplex
7320-005	Tilt cylinders Tiltcylinder; Neigezylinder; Vérin d'inclinaison	

2550-009 Mechanical drive gear unit

[1996-06-19]

Drivaggregat/-växel; Antriebsaggregat/-getriebe; Groupe de traction, réducteur

			168 FRT2000 SE	399076 - 399141
Pos	Description	Pcs	Part No	Note
01	Gear Växel; Getriebe; Engrenage	1	83862	
11	Washer Bricka; Scheibe; Rondelle	35	83964	
12	Gear ring Kuggring; Zahnkranz; Couronne dentée	1	83965	
13	Screw Skruv; Schraube; Vis	12	83966	
14	Cam Nock; Nocken; Came	1	83967	
15	Bearing unit Lagerenhet; Lagereinheit; Unité de roulement	1	83968	
16	O-ring O-ring; O-ring; Joint torique	1	83969	
18	Cap Lock; Deckel; Couvercle	1	83971	
19	Nut Mutter; Mutter; Ecrou	1	83972	
21	Bearing Lager; Lager; Roulement	1	83974	
22	Shim(50 x 62 x 0,1 / 0,3 / 0,5) Shims; Schim; Cale		83975	
23	Screw Skruv; Schraube; Vis	2	83976	
24	Bearing Lager; Lager; Roulement	1	83977	
25	Shim(45 x 55 x 0,1 / 0,3 / 0,5) Shims; Schim; Cale		83978	
26	Screw Skruv; Schraube; Vis	8	83979	
27	O-ring O-ring; O-ring; Joint torique	1	83980	
28	Gear wheel set Drevsats; Zahnradatz; Jeux de roue dentée	1	83825	
30	Screw Skruv; Schraube; Vis	2	83826	
31	Locking plate Låsplåt; Schlussplatte; Lame de serrage	1	83827	
32	Cap Lock; Deckel; Couvercle	1	83828	
33	Washer Bricka; Scheibe; Rondelle	1	83829	
34	Bearing Lager; Lager; Roulement	1	83882	
35	Shim Shims; Schim; Cale		83883	
36	Screw Skruv; Schraube; Vis	1	83884	
37	Sealing ring Tättningsring; Dichtungsring; Bague d'étanchéité	2	83885	
38	Bearing Lager; Lager; Roulement	1	83886	
39	Disc Skiva; Runde Scheibe; Disque	1	83887	
40	Washer Bricka; Scheibe; Rondelle	1	83888	
42	Cylinder pin Cylindrisk pinne; Zylinderstift; Goupille cylindre	1	83890	
43	Screw Skruv; Schraube; Vis	4	83891	
44	Screw Skruv; Schraube; Vis	2	83892	

3540-009 Support/castor wheels

[1996-05-13]

Stöd-/länkhjul; Stützräder/Gelenkrollen; Roues stabilisatrices/pivotantes

			168 FRT2000 SE	399076 - 399141
Pos	Description	Pcs	Part No	Note
01	Wheel Hjul; Rad; Roue	2	85338	
11	Link wheel compl. Länkhjul kompl.; Gelenkrad kompl.; Roue articulée compl.	1	84952	
12	Nut Mutter; Mutter; Erou	2	28231	
13	Washer Bricka; Scheibe; Rondelle	2	29831	
14	Axle Axel; Achse; Axe	1	85047	
15	Bush Bussning; Bague; Bague	2	84482	
16	Washer Bricka; Scheibe; Rondelle	1	85182	
17	Screw Skruv; Schraube; Vis	1	29829	
18	Shim(17 x 24 x 0,02 mm) Shims; Schim; Cale		85333-001	
18	Shim(17 x 24 x 0,1 mm) Shims; Schim; Cale		85333-002	
18	Shim(17 x 24 x 0,5 mm) Shims; Schim; Cale		85333-003	
19	Sealing ring Tättningsring; Dichtungsring; Bague d'étanchéité	1	85335	
20	Screw Skruv; Schraube; Vis	1	29829	
21	Sealing ring Tättningsring; Dichtungsring; Bague d'étanchéité	1	85334	
22	Bearing Lager; Lager; Roulement	1	85331	
23	Bearing Lager; Lager; Roulement	1	85332	
24	Screw Skruv; Schraube; Vis	2	26486	
25	Nut Mutter; Mutter; Erou	2	20148	
26	Castor wheel bracket Länkhjulsfäste; Lenkradsbefestigung; Support de roue	1	85057	
27	Castor wheel bracket Länkhjulsfäste; Lenkradsbefestigung; Support de roue	1	85058	
28	Castor wheel fork Länkhjulsgaffel; Gelenkradgabel; Fourche des roues	1	85059	
29	Screw Skruv; Schraube; Vis	2	29829	
30	Nut Mutter; Mutter; Erou	2	20006	
31	Washer Bricka; Scheibe; Rondelle	2	23604	
32	Nut Mutter; Mutter; Erou	2	28231	
33	Axle Axel; Achse; Axe	1	85046	
34	Ball bearing Kullager; Kugellager; Roulement a billes	4	20908	
35	Axle Axel; Achse; Axe	1	85050	
36	Bush Bussning; Bague; Bague	2	84482	
37	Nut Mutter; Mutter; Erou	2	85049	
38	Screw Skruv; Schraube; Vis	2	85044	

Pos	Description	Pcs	Part No	Note
13	Bracket Fäste; Halterung; Support	1	135664	
14	Locking pin Spännstift; Spannstift; Goupille	1	28825	
15	Pedal Pedal; Pedal; Pédale	1	135663	
16	Washer Bricka; Scheibe; Rondelle	1	135459	
17	Nut Mutter; Mutter; Ecrou	1	20016	
18	Washer Bricka; Scheibe; Rondelle	1	20404	
19	Spinner Spinnare; Lenkfleier; Poignée volant	1	141840	
20	Steering wheel(D = 110 mm) Ratt; Lenkrad; Volant	1	135457	
21	Locking ring Spårring; Schliessring; Circlip	1	20009	
22	O-ring O-ring; O-ring; Joint torique	1	20620	
23	Ball bearing Kullager; Kugellager; Roulement a billes	1	28300	
24	Bearing bracket Lagerhållare; Lagerhalten; Support de roulement	1	135461	
25	Locking ring Spårring; Schliessring; Circlip	1	20008	
26	Screw Skruv; Schraube; Vis	8	21437	
27	Motor Motor; Motor; Moteur	1	135463	
28	Bracket Fäste; Halterung; Support	1	137320	
29	Bracket Fäste; Halterung; Support	1	135609	
30	Screw Skruv; Schraube; Vis	4	27500	
31	Cushion Dyna; Kissen; Coussin	1	135458	
32	Screw Skruv; Schraube; Vis	1	135818	
33	Washer(Nylon) Bricka; Scheibe; Rondelle	1	28968	
34	Nut Mutter; Mutter; Ecrou	1	118316-008	
35	Screw Skruv; Schraube; Vis	2	28511	
36	Bush Bussning; Bague; Bague	2	44110	
37	Axle Axel; Achse; Axe	1	135460	
38	Bush Bussning; Bague; Bague	4	44110	
39	Screw Skruv; Schraube; Vis	2	116429	
40	Locking pin Spännstift; Spannstift; Goupille	2	28825	
41	Screw Skruv; Schraube; Vis	1	135818	
42	Nit Nit; Niet; Rivet	4	21988	
43	List List; Leiste; Bande	2	135760	
44	Rod Stång; Stange; Tige	1	135761	
45	Arm Arm; Arm; Bras	1	137318	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

5190-004



5190-004 Battery cut out connector/contactator

[1996-06-19]

Batterifrånskiljare, huvudkontaktor; Batterietrennung, Hauptkontaktor; Coupe-circuit de batterie, contacteur

			168 FRT2000 SE	399076 - 399141
Pos	Description	Pcs	Part No	Note
01	Connector(Complete) Handske(Komplett); Stecker(Komplett); Bloc de connexion(Comple)	1	135832	
03	Contactator compl.(48v) Kontaktor kompl.; Kontaktor kompl.; Contacteur compl.	1	136972	
04	Contact set Kontaktsats; Kontaktsatz; Jeux de contact	1	74458	
11	Handle Handtag; Handgriff; Poignée.	1	127482	
12	Cable Kabel; Kabel; Câble	1	137142	
13	Screw Skruv; Schraube; Vis	2	26956	
14	Nut Mutter; Mutter; Ecrou	2	26957	
15	Connector Handske; Stecker; Bloc de connexion	1	135830	
16	Wire Wire; Drahtseil; Filament	1	127488	
17	Cable clip Kabelsko; Anschlussklemme; Oeillet de cable	1	22389	
18	Coil Spole; Spule; Bobine	1	124905-016	

5430-017 Motor cables, resistors

[1996-06-19]

Effektkablar, effektmotstånd; Leistungskabeln, Widerstand; Cables moteur, resistances

			168 FRT2000 SE	399076 - 399141
Pos	Description	Pcs	Part No	Note
11	Copper bar Kopparskena; Kupferstab; Plaque de cuivre	2	65213	
12	Copper bar Kopparskena; Kupferstab; Plaque de cuivre	1	65212	
13	Copper bar Kopparskena; Kupferstab; Plaque de cuivre	1	65214	
14	Copper bar Kopparskena; Kupferstab; Plaque de cuivre	1	136978	Hydraulic steering Hydraulisk styrning; Hydraulische steuerung; Commande hydraulique
15	Copper bar Kopparskena; Kupferstab; Plaque de cuivre	1	63948	
16	Fuse(35 A) Säkring; Sicherung; Fusible	1	22011	
17	Cable Kabel; Kabel; Câble	1	135800	Hydraulic steering Hydraulisk styrning; Hydraulische steuerung; Commande hydraulique
18	Screw Skruv; Schraube; Vis	22	27500	
19	Nut Mutter; Mutter; Ecrou	16	20249	
20	Nut Mutter; Mutter; Ecrou	7	20045	
21	Washer Bricka; Scheibe; Rondelle	7	21393	
22	Washer Bricka; Scheibe; Rondelle	8	65184	
23	Insulator Isolator; Isolator; Isolateur	7	65183	
24	Copper bar Kopparskena; Kupferstab; Plaque de cuivre	1	136973	
25	Fuse(160 A) Säkring; Sicherung; Fusible	1	29223	
26	Copper bar Kopparskena; Kupferstab; Plaque de cuivre	1	135799	
27	Copper bar Kopparskena; Kupferstab; Plaque de cuivre	1	135798	
28	Copper bar Kopparskena; Kupferstab; Plaque de cuivre	1	135796	
29	Copper bar Kopparskena; Kupferstab; Plaque de cuivre	1	135797	
30	Cable Kabel; Kabel; Câble	1	84441	
31	Cable Kabel; Kabel; Câble	1	84443	
32	Cable Kabel; Kabel; Câble	1	84444	Hydraulic steering Hydraulisk styrning; Hydraulische steuerung; Commande hydraulique
33	Cable Kabel; Kabel; Câble	1	84442	
34	Cable Kabel; Kabel; Câble	1	84448	
35	Cable Kabel; Kabel; Câble	1	84447	Hydraulic steering Hydraulisk styrning; Hydraulische steuerung; Commande hydraulique

5750-037 Safety/ position probes/ sensors

[1996-10-30]

Skydds-/ läges-givare/-sensor; Schutz- / Positions-schalter/-geber; Emetteurs/capteurs (sondes) de sécurité/ position

			168 FRT2000 SE	399076 - 399141
Pos	Description	Pcs	Part No	Note
02	Cap Lock; Deckel; Couvercle	1	132577	Hydraulic steering Hydraulisk styrning; Hydraulische steuerung; Commande hydraulique
02	Switch Brytare; Schalter; Rupteur	1	137970	Electrical steering Elektrisk styrning; Elektrisch Steuerung; Direction mécanique
04	Limit switch Gränslägesbrytare; Grenzschalter; Limiteur de course	1	26894	Electrical steering Elektrisk styrning; Elektrisch Steuerung; Direction mécanique
11	Sign Skylt; Schild; Vignette	1	133414-009	
12	Push-button Tryckknapp; Druckknopf; Bouton	1	133418	
13	Bracket Fäste; Halterung; Support	1	133419	
14	Contact device Kontaktblock; Kontakteinheit; Unite de contact	1	133420	
26	Fitting Förskruvning; Verschraubung; Presse-étoupe	1	27659	Electrical steering Elektrisk styrning; Elektrisch Steuerung; Direction mécanique
27	Washer Bricka; Scheibe; Rondelle	1	106587	Electrical steering Elektrisk styrning; Elektrisch Steuerung; Direction mécanique
28	Screw Skruv; Schraube; Vis	2	28421	Electrical steering Elektrisk styrning; Elektrisch Steuerung; Direction mécanique
29	Washer Bricka; Scheibe; Rondelle	2	21035	Electrical steering Elektrisk styrning; Elektrisch Steuerung; Direction mécanique
30	Sensing device Induktivgivare; Fühler; Emetteur	3	27772	


6120-054 Hoses and pipes, connection, fixation

[1996-06-25]

Rör-/slangledning, koppl., fastsättning; Rohr/Schlauch/Verschraubung. befestig.; Tuyaux / flexibles raccords

Triplex			168 FRT2000 SE	399076 - 399141
Pos	Description	Pcs	Part No	Note
11	Hose Slang; Schlauch; Tuyau flexible	1	83877	
12	Hose Slang; Schlauch; Tuyau flexible	1	83877	
13	Connection Koppling; Kupplung; Raccord	2	83950	
14	Hose(Meter) Slang(Meter); Schlauch(Meter); Tuyau flexible(Metre)		83952	
15	Connection Koppling; Kupplung; Raccord	1	83951	
16	Connection Koppling; Kupplung; Raccord	6	83879	
19	Pipe Rör; Rohr; Tube	1	84044-480	
19	Pipe Rör; Rohr; Tube	1	84044-540	
19	Pipe Rör; Rohr; Tube	1	84044-570	
19	Pipe Rör; Rohr; Tube	1	84044-630	
19	Pipe Rör; Rohr; Tube	1	84044-700	
20	Pipe Rör; Rohr; Tube	1	84042-480	
20	Pipe Rör; Rohr; Tube	1	84042-540	
20	Pipe Rör; Rohr; Tube	1	84042-570	
20	Pipe Rör; Rohr; Tube	1	84042-630	
20	Pipe Rör; Rohr; Tube	1	84042-700	
21	Pipe Rör; Rohr; Tube	1	84041-480	
21	Pipe Rör; Rohr; Tube	1	84041-540	
21	Pipe Rör; Rohr; Tube	1	84041-570	
21	Pipe Rör; Rohr; Tube	1	84041-630	
21	Pipe Rör; Rohr; Tube	1	84041-700	
22	Connection Koppling; Kupplung; Raccord	1	83878	
23	Pipe Rör; Rohr; Tube	1	84039-480	
23	Pipe Rör; Rohr; Tube	1	84039-540	
23	Pipe Rör; Rohr; Tube	1	84039-570	
23	Pipe Rör; Rohr; Tube	1	84039-630	
23	Pipe Rör; Rohr; Tube	1	84039-700	
24	Hose Slang; Schlauch; Tuyau flexible	1	84047-480	
24	Hose Slang; Schlauch; Tuyau flexible	1	84047-540	
24	Hose Slang; Schlauch; Tuyau flexible	1	84047-570	

6140-007




6140-007 Hydraulic pump

Hydraulpump; Hydraulikpumpe; Pompe hydraulique

[1996-06-18]

			168 FRT2000 SE	399076 - 399141
Pos	Description	Pcs	Part No	Note
01	Pump Pump; Pump; Pumpe	1	100438	
11	O-ring O-ring; O-ring; Joint torique	1	26922	
12	Connector unit Kopplingsstycke; Kupplungsstück; Raccordement	1	51476	
13	Screw Skruv; Schraube; Vis	2	26407	
14	Washer Bricka; Scheibe; Rondelle	2	20404	

7320-005



7320-005 Tilt cylinders

[1996-06-10]

Tiltcylinder; Neigezylinder; Vérin d'inclinaison

			168 FRT2000 SE	399076 - 399141
Pos	Description	Pcs	Part No	Note
01	Tilting cylinder(Complete) Tiltcylinder(Komplett); Neigezylinder(Komplett); Vérin de inclination(Comple)	1	84048	
02	Packing set Packningssats; Packungssatz; Jeux d' étanchéité.	1	84055	
03	Cylinder pipe Cylinderrör; Zylinderrohr; Tube de cylindre	1	84049	
04	Piston Kolv; Kolben; Piston	1	84050	
05	Piston rod Kolvstång; Kolbenstange; Tige de piston	1	83786	
11	Locking ring Spårring; Schliessring; Circlip	1	20509	
12	Bearing Lager; Lager; Roulement	1	83778	
13	Top guide Toppstyrning; Topsteuerung; Guide de sommet	1	84051	
14	Screw Skruv; Schraube; Vis	1	83779	
15	Screw Skruv; Schraube; Vis	4	20044	
16	Sleeve Hylsa; Hülse; Douille	1	83902	
17	Axle Axel; Achse; Axe	1	83636	
18	Locking ring Spårring; Schliessring; Circlip	2	20041	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL