

821B Loader

Parts Catalog

Bur 8-9392

Reprinted

CASE

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

ALPHABETICAL INDEX

G

Gaskets
 Engine - cont'd
 Valve Grind..... 2-47,2-47D
 Equipment and Steering Pump 8-5
 Fill Cap - hydraulic oil..... 8-3
 Front Wiper 4-53
 Fuel Sediment Bowl 3-5
 Fuel Tank 3-7
 Injection Pump 3-13 - 3-13D
 Starter 4-39
 Transmission
 Control Valve 6-33,6-37
 Cover Plate..... 6-5
 Fill Tube..... 6-7
 Oil Feed Flange..... 6-13
 Pump 6-13
 Suction Tube 6-9,6-9B
 Window Lock..... 9-75

Gauges
 Bolt Length - cylinder head 2-47,2-47D
 Electrical 4-11
 Sight
 Hydraulic Oil 8-3
 Radiator Coolant Level..... 2-5
 Transmission Oil..... 6-7

Glass - cab 9-55,9-55B,9-69,9-73
 Grille 9-35

Guards
 Engine Cooling Fan 2-7
 Hose - loader control..... 8-57,8-63,8-67
 Hydraulic Oil Filter..... 8-11
 Radiator 9-35
 Return-to-Dig Harness 9-3
 Transmission Fill Tube..... 6-7

H

Harness - electrical
 Cab 4-17 - 4-21
 Canopy..... 4-23 - 4-27
 Front..... 4-13
 Pedestal 4-15,4-15B
 Rear - engine 4-29 - 4-31
 Rear - lamp 4-45
 Ride Control 4-27B

Head - cylinder 2-33 - 2-33F
 Heater Cable 4-9

Heaters
 Block - engine 2-39,2-39D
 Cab 9-77 - 9-81
 Oil Pan 2-27,2-27B

Hood 9-31
 Horn - electric 4-13,4-15

H

Horn Button.....5-3
 Horn/Turn Signal Combination Lever. 4-15,4-15B
 Hoses - radiator2-5
 Hoses - see fuel lines, brake assemblies,
 and hydraulic circuits

Hydraulic Circuits
 Auxiliary Cylinder to Control Valve8-17
 Auxiliary Steering 5-13,5-13B
 Clam Bucket8-19
 Cooler Bypass Valve to Filter8-9
 Loader Bucket8-15
 Loader Control Valve to Cooler
 Bypass Valve8-7
 Loader Lift 8-11,8-13
 Oil Filter to Reservoir.....8-11
 Pump to Steering Control Valve and
 Pressure Reducing Valve5-7
 Remote Loader Control Valve 8-53 - 8-69
 Reservoir to Pump and
 Loader Control Valve8-5
 Ride Control 8-85 - 8-89
 Steering Control Valve to Cylinders5-9
 Steering Return Lines.....5-11
 Transmission6-3

Hydraulic Reservoir.....8-3

I

Ignition Switch and Key.....4-9
 Index - numerical 10-1
 Indicator - restriction 4-31,8-11
 Induction System - air2-11
 Injection System - fuel..... 3-9,3-9B

Instrument Cluster
 Cluster4-9
 Panel 4-9,4-11


Insulation - cab..... 9-61D


K


Key - starting switch.....4-9


Kits
 Accumulator Valve - brake 7-21,7-21B
 Alternator Hardware4-3
 Armrest..... 9-49,9-53D
 Compressor.....9-93
 Connecting Rod - engine..... 2-45,2-45B
 Coolant Heater - cylinder block 2-39,2-39D
 Crankshaft..... 2-41,2-41B
 Cylinder Block Hardware.....2-39,2-39D
 Fuel Filter 3-11,3-11B
 Fuel Injection Nozzle 3-15,3-15B




Gasket
 Cylinder Block.....2-47B,2-47F
























































































CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below






- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL











ROTATED 180°
FOR CLARITY










































































NUMERICAL INDEX

PART NO.	PAGE	REF.	PART NO.	PAGE	REF.	PART NO.	PAGE	REF.
L125008	9-17	11	L125332	8-63	30	L125583	5-13B	45
L125009	9-17	19	L125332	8-67	30	L125583	8-5	4
L125012	6-67		L125335	8-57	9	L125607	8-7	13
L125016	9-7	10	L125335	8-63	9	L125621	4-39	5
L125019	9-7	12	L125335	8-67	9	L125636	9-37	23
L125021	9-7	13	L125336	8-57	8	L125718	9-57	14
L125033	9-7	8	L125336	8-63	8	L125726	9-11	4
L125051	9-7	24	L125336	8-67	8	L125732	8-17	9
L125100	9-7	31	L125342	9-41	11	L125734	8-17	8
L125100	9-17	9	L125343	9-41	12	L125736	8-17	16
L125105	4-39	26	L125344	8-5	1	L125741	9-9	5
L125136	9-9	3	L125345	8-13	15	L125741	9-11	5
L125136	9-13	17	L125349	8-5	27	L125746	8-17	15
L125145	9-9	4	L125353	8-7	12	L125772	9-11	3
L125159	2-5	5	L125356	8-5	3	L125774	4-33	25
L125171	9-9	8	L125363	3-7	8	L125787	9-89	47
L125171	9-11	8	L125365	8-15	14	L125787	9-89D	47
L125171	9-15	1	L125367	8-13	17	L125808	9-13	
L125172	9-9	9	L125369	8-15	12	L125814	9-9	10
L125172	9-11	9	L125371	8-15	6	L125821	3-3B	33
L125172	9-15	2	L125373	8-15	5	L125830	6-7	23
L125176	9-7	15	L125375	8-13	6	L125836	6-7	11
L125184	6-61	8	L125377	8-13	5	L125837	6-7	10
L125187	6-61	9	L125379	8-13	10	L125849	5-7	14
L125187	6-63	10	L125381	8-13	8	L125857	4-11	1
L125187	6-63	23	L125383	8-13	11	L125870	2-9	9
L125197	9-9		L125385	8-13	9	L125876	6-7	7
L125197	9-15		L125387	8-13	18	L125887	5-9	34
L125219	9-17	2	L125389	8-13	21	L125890	5-9	35
L125221	9-17	4	L125405	9-33	9	L125891	8-57	6
L125225	9-17	12	L125419	5-9	37	L125891	8-63	6
L125226	9-17	18	L125423	3-7	2	L125891	8-67	6
L125227	9-17	20	L125431	6-5	4	L125902	8-7	24
L125228	9-17	23	L125441	6-3	5	L125905	8-5	17
L125229	9-17	26	L125446	9-37	14	L125907	8-7	2
L125230	9-17	29	L125453	8-9	4	L125908	8-5	29
L125231	9-17	15	L125455	8-9	7	L125910	9-103	2
L125232	9-17	15	L125464	9-23	1	L125932	2-3	5
L125233	9-17	15	L125464	9-25	1	L125941	8-5	32
L125234	9-17	22	L125464	9-27	1	L125941	8-7	6
L125235	9-17	22	L125465	9-23	2	L125956	4-29	23
L125236	9-17	22	L125465	9-25	2	L125956	4-29B	23
L125237	9-17	28	L125465	9-27	2	L125956	9-85	35
L125238	9-17	28	L125466	9-25	3	L125956	9-85D	48
L125239	9-17	28	L125466	9-27	3	L125957	9-7	20
L125240	9-41	16	L125467	9-25	4	L125966	9-9	11
L125256	9-5	1	L125467	9-27	4	L125966	9-11	10
L125258	9-5	10	L125468	9-27	5	L125966	9-15	4
L125266	3-5	1	L125469	9-27	6	L125968	9-37	4
L125266	3-5B	1	L125486	9-21		L125969	9-37	6
L125271	9-17	10	L125487	9-19		L125970	9-17	28
L125272	9-39	8	L125491	9-37	10	L125971	9-7	18
L125273	9-39	9	L125498	9-9	13	L125972	9-7	4
L125282	8-5	28	L125498	9-11	12	L125973	9-7	2
L125284	8-7	5	L125532	3-5D	2	L125974	9-7	3
L125294	9-29	5	L125544	5-9	24	L125975	8-9	2
L125316	5-9	10	L125548	5-9	25	L125976	9-5	5
L125318	5-9	11	L125551	8-57	22	L125982	9-5	7
L125320	5-9	13	L125551	8-63	22	L125983	9-3	19
L125322	5-9	12	L125551	8-67	22	L125985	9-13	15
L125323	5-9	19	L125561	9-17	17	L125987	6-3	10
L125325	5-9	30	L125562	9-17	27	L125989	2-3	9
L125332	8-57	30	L125572	7-17	12	L125990	9-9	

NUMERICAL INDEX

PART NO.	PAGE	REF.	PART NO.	PAGE	REF.	PART NO.	PAGE	REF.
122553A1	9-85B	34	1276117C1	9-95B	16	130921A1	9-53B	16
122554A1	9-85B	7	1276117C1	9-95B	48	130921A1	9-53F	
122579A1	9-85B	22	1276337C2	9-79	1	131-1400	2-3	8
122965A1	8-91	10	1280291C1	7-7	2	131-1400	6-5	9
122971A1	8-91	11	128086A1	7-17	29	131-1402	4-43	6
123140A1	7-23B		128096A1	7-17	30	131-1402	4-45	3
123253A1	8-93	9	128191A1	7-11B	20	131-141	6-7	16
123254A1	8-93		128191A1	7-27		131-203	9-69	5
123549A1	6-45	31	1283403C1	9-59	1	131-203	9-71	26
123549A1	6-45	41	128483A1	9-85B	8	131-206	2-5	34
123549A1	6-55	32	128483A1	9-85B	30	131-219	9-7	32
123549A1	6-55	42	128483A1	9-85B	36	131-219	9-35	15
123598A1	6-47		128483A1	9-91	22	131-425	9-49	23
123598A1	6-49		128484A1	9-79	18	131-425	9-53	13
123599A1	6-47	1	128484A1	9-85B	10	131-425	9-53	31
123599A1	6-47B	1	128485A1	9-79	17	131-425	9-53D	28
123622A1	6-45	40	128485A1	9-85B	3	131-425	9-53H	6A
123622A1	6-55	41	128485A1	9-85B	19	131-425	9-53H	13
123625A1	6-43	2	128485A1	9-85B	29	131-425	9-53H	21
123735A1	6-55	15	128784A1	4-33B	14	131-431	9-103	15
123775A1	6-55	34	128785A1	4-33B	13	131-461	9-39	13
123969A1	9-51	8	129-119	9-59	15	131-475	9-21	5
123969A1	9-53F		129-187	4-39	18	131-510	8-3	9
124305A1	8-43		129-409	9-67	10	131-542	9-49	28
1250509C1	9-53F		129-667	8-11	3	131-573	4-39	20
1250522C3	9-83	30	129790A1	6-33	9	131-610	9-61	37
1250522C3	9-85D	42	129791A1	6-33	9A	131-610	9-61B	37
125058A1	4-33	1	129792A1	6-9	20	131-63	3-3	25
125058A1	4-33B	1	129792A1	6-9B	20	131-63	3-3B	38
1250594C1	9-83	21	129792A1	6-35B	28	131-637	9-33	28
1250594C1	9-85B	6	129792A1	6-37	16	131-837	9-65	15
1250594C1	9-85B	20	129792A1	6-37B	26	131-837	9-65	15
1250594C1	9-85B	31	129801A1	6-35B	34	131-852	9-87	18
1250594C1	9-89	34	129802A1	6-35B	34	131-856	9-5	15
1250594C1	9-89D	34	129803A1	6-35B	34	131-876	4-9	34
126-11	4-37	5	129804A1	6-35B	34	131080A1	6-37	24
126-112	2-35	8	129805A1	6-35	13	131082A1	6-37	20
127158A1	4-51	1	129808A1	6-37	2	131082A1	6-37B	21
127595A1	4-15	2A	129808A1	6-37B	2	131199A1	8-89	8
127595A1	4-15B	2A	129809A1	6-37	3	131200A1	8-89	4
127596A1	4-15	2B	129809A1	6-37B	3	131204A1	8-87	14
127596A1	4-15B	2B	129810A1	6-37	8	131225A1	8-85	15
1276051C1	4-9	15	1301128C2	4-9	35	131230A2	2-5	2A
1276051C1	4-53B	40	1301128C2	4-11	21	131235A1	8-87	10
1276051C1	9-61	31	130133A1	8-87	17	131248A1	4-27B	7
1276051C1	9-61B	31	1301342C1	9-81	5	131674A1	8-85	11
1276051C1	9-67	12	130134A1	8-87	18	131675A1	8-85	10
1276051C1	9-95B	53	130354A1	8-87	21	132024A1	4-55	20
1276057C1	4-15	34	130354A1	8-95		1327515C2	9-79	
1276057C1	4-15B	30	130404A1	4-29	1	1327574C1	9-65	5
1276117C1	4-53	17	130404A1	4-31	1	1327574C1	9-65	5
1276117C1	4-53B	36	130404A1	4-33B	26	132760	8-77	41
1276117C1	9-61	10	130417A1	4-27B	3	132760	8-77	46
1276117C1	9-61	23	130672A1	9-51	3	1327781C2	9-81	14
1276117C1	9-61	34	130672A1	9-53F		1327782C2	9-81	2
1276117C1	9-61	39	130673A1	9-53F		1327799C2	9-65	11
1276117C1	9-61B	10	130674A1	9-51		1327799C2	9-65	11
1276117C1	9-61B	23	130674A1	9-51	10	1327979C1	9-87	6
1276117C1	9-61B	34	130674A1	9-53F		1327979C1	9-89B	6
1276117C1	9-61B	39	130676A1	9-53		132905A1	4-27B	4
1276117C1	9-65	10	130676A1	9-53H		132906A1	4-27B	5
1276117C1	9-65	10	130921A1	9-49	12	1330108CX	9-87	
1276117C1	9-95	48	130921A1	9-53B		1330108CX	9-89B	

NUMERICAL INDEX

PART NO.	PAGE	REF.	PART NO.	PAGE	REF.	PART NO.	PAGE	REF.
237348A1	6-35	1	238-5111	2-47D	15	241954A1	6-29B	
237353A1	6-21	1	238-5112	8-3	6	241954A1	6-33	
237353A1	6-21	24	238-5115	2-29	13	241954A1	6-35	
237353A1	6-25	1	238-5115	2-29B	13	241954A1	6-35B	
237353A1	6-25	24	238-5115	2-47	13	241954A1	6-37B	
237353A1	6-29	1	238-5115	2-47D	13	241954A1	6-37D	
237358A1	6-27	6	238-5121	5-5B	26	241956A1	3-3B	47
237358A1	6-27	6	238-5132	8-29	6	241956A1	4-29B	27
237365A1	6-21	16	238-5132	8-29	24	241980A1	6-9B	5
237365A1	6-21B	16	238-5132	8-31	6	242136A1	6-27	21
237366A1	6-25	16	238-5132	8-31	16	242137A1	6-35	5
237366A1	6-25B	16	238-5132	8-33	6	242138A1	6-37B	16
237367A1	6-23	15	238-5132	8-33	16	242153A1	6-47B	
237369A1	6-29	17	238-5145	8-45	3	242154A1	6-49B	4
237370A1	6-15	23	238-5212	2-43	5	242155A1	6-49B	4
237370A1	6-15	23	238-5212	2-43B	5	242156A1	6-49B	4
237374A1	6-19	26	238-5212	2-47B	32	242157A1	6-49B	4
237374A1	6-23	23	238-5212	2-47F	12	242158A1	6-49B	4
238-5005	4-51	3	238-5225	5-5B	21	242159A1	6-49B	5
238-5011	8-11	6	238-5225	5-5D	21	242160A1	6-49B	8
238-5011	9-83	8	238-5228	8-5	5	242161A1	6-49B	10
238-5011	9-83	24	238-5235	5-19	7	242162A1	6-41	1
238-5011	9-85B	13	238-5235	5-19B	7	242163A1	6-41	4
238-5011	9-89	37	238-5238	8-47	15	242166A1	6-43	
238-5011	9-89	39	238-5238	8-49	17	242167A1	6-43	2A
238-5011	9-89D	37	238-5356	8-47	12	242167A1	6-45	43
238-5011	9-89D	39	238-5356	8-47	28	242167A1	6-53	9B
238-5012	5-5B	24	238-5362	8-49	29	242168A1	6-43	9
238-5012	5-5D	24	238-5442	8-3	7	242171A1	6-45	13A
238-5012	8-37	4	238-6011	5-5D	25	242171A1	6-53	14
238-5012	8-39	4	238-6020	5-11	21	242172A1	6-45	14
238-5012	8-41	5	238-6020	5-11	23	242178A1	6-57B	1
238-5013	2-21	25	238-6024	8-5	30	242179A1	6-57B	
238-5013	2-21B	17	238-6024	8-13	4	242180A1	6-59B	5
238-5013	9-79	6	238-6024	8-15	4	242187A1	6-51	1
238-5013	9-83	5	238-6024	8-17	7	242189A1	6-51	4
238-5013	9-89	33	238-6040	5-5D	20	242194A1	6-53	
238-5013	9-89D	33	238-6124	8-23	6	242196A1	6-53	2A
238-5015	9-79	5	238-6124	8-25	7	242198A1	6-53	9A
238-5015	9-83	3	238-6124	8-27	7	242205A1	6-53	10
238-5015	9-83	14	238-6128	8-23	7	242207A1	6-53	10
238-5015	9-83	20	238-6128	8-25	8	242209A1	6-53	10
238-5019	8-37	11	238-6128	8-27	8	242212A1	6-53	10
238-5019	8-37	16	238-7112	6-7	14	242214A1	6-53	10
238-5019	8-39	11	238-7112	8-3	12	242216A1	6-53	12
238-5019	8-39	16	238-7113	8-41	13	242221A1	6-55	26
238-5019	8-41	10	238-7115	2-21B	10	242222A1	6-55	27
238-5021	8-71	18	238270A1	4-15	38	242333A1	9-101	27
238-5021	8-71	26	238270A1	4-15B	2	242558A1	4-19	19
238-5021	8-73	50	239937A1	9-7		242558A1	4-25	13
238-5021	8-75	19	241728A1	3-3B	45	242586A1	9-65	8
238-5021	8-75	26	241954A1	6-5	1	242586A1	9-65	16
238-5021	8-79	8	241954A1	6-9B		242631A1	9-101	26
238-5021	8-81	14	241954A1	6-11		242952A1	6-25	26
238-5021	8-81	28	241954A1	6-13		242953A1	6-25	25
238-5022	2-25	9	241954A1	6-15		243353A1	6-49B	1
238-5022	2-25B	9	241954A1	6-17		243354A1	6-49B	6
238-5022	8-29	34	241954A1	6-19		243564A1	4-35	12
238-5022	8-41	20	241954A1	6-21B		243564A1	4-35	12A
238-5041	7-23	2	241954A1	6-23		243609A1	9-67	20
238-5111	2-31	13	241954A1	6-25B		244181A1	4-29B	1A
238-5111	2-31B	12	241954A1	6-27		244237A1	4-29	1
238-5111	2-47	15	241954A1	6-29		244237A1	4-29B	1

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL