

Spare parts catalogue **PAUL SMART**1000 Limited Edition **U.S.A.**

# DUCATI SPORTCLASSIC

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

DRAWING 001a WORKSHOP SPECIAL TOOLS


NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
1	88713.1096	Tool for overhauling SHOWA forks - assembling seal ring		1
2	8000.70139	Wrench for front wheel spindle		1
3	88713.1344	Tool for assembling chain		1
4	677.4.003.1A	Coupling		1
5	88713.1515	Frame/engine mount		1
6	88713.1072	Stopper for driving the half bearing of the steering head base		1
7	88713.1010	Union for exhaust gas suction		1
8	88713.1062	Tool for assembling the steering head bearings		1
9	88713.2776	Nipples tightening wrench		1
10	88713.2775	Spoke wheels truing tool		1
11	88713.2777	Nipples torque wrench		1

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
-----------	----------	-------------	----------	--

DRAWING 004

CLUTCH


NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
1	0659.16.555	Clutch spring		6
2	841.1.002.2A	Retainer		6
3	818.2.009.1A	Clutch control pin		1
4	771.5.043.8B	Screw		6
5	851.4.001.1A	Lock washer		1
6	764.1.003.1B	Rubber pad		12
7	162.1.001.1B	Plate holder hub		1
8	190.2.011.1A	Clutch plates set		1
9	851.1.001.1B	Lock washer		1
10	196.1.001.2B	Clutch drum		1
11	70610.8120	Screw		8
12	194.2.001.1B	Pressure plate		1
13	198.1.029.1A	Clutch housing		1
14	702.5.016.1A	Bearing		1
15	463.2.053.7A	O-ring		1
16	930.4.035.1A	Seal ring		1
17	170.2.020.1B	Clutch/crankshaft gears pair		1
18	75113.2566	Bearing		1
19	881.2.001.1A	Circlip - spacer		1
20	702.4.017.1A	Bearing		1
21	0660.16.145	Spacer		1
22	195.4.003.1A	Piston assembly		1
23	710.1.002.1A	Bush		1
24	74224.0570	Pin		1
25	750.1.002.1B	Nut		1
26	886.4.118.1A	O-ring		1

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
27	886.4.043.1A	O-ring		1
28	771.5.065.8B	Screw		3
29	117.2.006.1A	Clutch control rod		1
30	93823.2018	O-ring		2
31	713.1.012.1B	Spacer		1
32	93823.0128	O-ring		1

DRAWING 009


FILTERS AND OIL PUMP

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
1	174.2.025.6A	Complete oil pump		1
2	552.1.045.2A	Thermistor		1
3	852.5.024.1A	Gasket th.1		1
4	886.4.037.1A	O-ring		1
5	873.1.039.1A	Cap		1
6	852.1.120.1A	Aluminium gasket		1
7	780.1.018.1A	Bypass cap		1
8	771.5.129.8B	Screw		2
9	853.1.002.1A	Spring washer		2
10	771.5.069.8B	Screw		1
11	853.1.004.1A	Spring washer		1
12	174.1.025.2A	Pump drive gear		1
13	710.1.001.1A	Bush		1
14	799.2.077.2A	Bypass spring		1
15	0759.49.280	Locating bush		2
16	220.3.208.3A	Gasket		1
17	780.2.047.1A	Oil drain plug with magnet		1
18	852.5.005.1A	Gasket th.1,5		1
19	894.2.009.1A	Oil filter		1
20	444.4.003.4A	Oil filter cartridge		1
21	815.1.028.1A	Nipple		1
22	93827.0114	O-ring		1
23	779.1.198.2A	Cap		1
24	884.4.042.1A	Snap ring		1
25	884.5.036.1A	Circlip		1
26	0670.49.310	Reduction bush		1


NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
27	779.1.162.2A	Cap		1
28	852.1.195.1A	Gasket th.2		1
29	593.1.018.1A	Bypass valve		1
30	799.1.055.1A	Bypass spring		1

DRAWING 014 VERTICAL HEAD

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
1	301.2.092.1D	Complete vertical head		1
1	301.2.233.1A	Complete vertical head		1
2	304.1.042.1B	Intake valve seat		1
2	304.1.042.1BB	Oversize intake valve seat 0.03		1
2	304.1.042.1BC	Oversize intake valve seat 0.06		1
3	304.1.043.1B	Exhaust valve seat		1
3	304.1.043.1BB	Oversize exhaust valve seat 0.03		1
3	304.1.043.1BC	Oversize exhaust valve seat 0.06		1
4	303.1.041.1C	Intake valve guide		1
4	303.1.041.1CA	Intake valve guide magg. 0,03		1
4	303.1.041.1CB	Intake valve guide magg. 0,06		1
4	303.1.041.1CC	Intake valve guide magg. 0,09		1
5	303.1.040.1B	Exhaust valve guide		1
5	303.1.040.1BA	Exhaust valve guide magg. 0,03		1
5	303.1.040.1BB	Exhaust valve guide magg. 0,06		1
5	303.1.040.1BC	Exhaust valve guide magg. 0,09		1
6	764.1.002.1A	Rubber pad		2
7	799.1.061.3A	Closing rocker spring		2
8	0619.92.180	Shim th. 0.3		6
8	0670.92.190	Shim th. 2		3
8	0765.92.185	Shim th. 1		2
8	0765.92.190	Shim th. 0.5		4
8	0765.92.205	Shim th. 0.2		8
9	463.2.010.9A	O-ring		2
10	240.2.026.1B	Valve cover		2
11	771.5.066.8B	Screw		8

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
12	0647.70.010	Shim		4
13	0375.92.210	Spring		2
14	208.1.012.4A	Opening rocker		2
15	821.1.111.2A	Rocker shaft		4
16	209.1.041.1A	Closing rocker		2
17	840.2.002.1B	See table		2
18	669.1.001.1E	Split rings		4
19	840.2.001.1A	See table		2
20	463.2.026.1A	O-ring		4
21	211.1.040.1A	Exhaust valve		1
22	210.1.042.1A	Intake valve		1
23	852.5.023.1A	Gasket		1
24	779.1.133.1A	Screw		1
25	700.1.040.1A	Vibration damper pad		12

DRAWING 019 FUEL SYSTEM

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
1	160.2.366.1A	Flange		1
2	814.4.010.1A	Quick-coupling union		2
3	772.1.062.1A	Screw		6
4	886.4.072.1A	O-ring		2
5	886.4.073.1A	O-ring		2
6	886.5.048.1A	O-Ring		1
7	741.4.158.1A	Clamp		2
8	425.4.004.1B	Fuel filter		1
9	552.4.048.1A	Thermistor		1
10	741.4.092.1A	collar		2
11	699.2.345.1A	Clamps kit		1

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
-----------	----------	-------------	----------	--

DRAWING 024


L.H. FOOT RESTS

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
1	821.1.051.1AB	Pin		1
2	464.1.005.1B	Front L.H. foot peg (front) (L.H.)		1
3	247.1.184.1B	Protection		1
4	771.5.662.8B	Screw		2
5	884.5.003.1A	Ring		1
6	799.1.166.1A	Spring		1
7	886.4.116.1A	O-ring		2
8	848.5.001.1A	Ball joint		1
9	821.1.170.1A	Pin		1
10	771.5.667.8B	Screw		2
11	764.1.011.1A	Rubber pad		1
12	712.1.034.1A	Bush		1
13	456.2.033.1B	Gearchange lever		1
14	456.1.024.1B	Gearchange control lever		1
15	824.1.103.1A	L.H. bracket		1
16	852.1.151.1A	Washer		1
17	771.5.725.8B	Screw		2
18	848.5.002.1A	Ball joint		1
19	747.5.005.1B	Nut		1
20	117.1.030.1B	Gearbox transmission rod		1
21	749.4.004.1A	Nut		2
22	747.5.001.1AB	Nut		1
23	771.5.666.8B	Screw		1


NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
-----------	----------	-------------	----------	--

DRAWING 029 REAR HYDRAULIC BRAKE

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
1	771.5.665.8B	Screw		2
2	552.4.037.1C	Sensor		1
3	713.1.192.1A	Spacer		1
4	611.4.027.1A	Rear brake caliper		1
5	852.5.024.1A	Gasket th.1		4
6	779.1.366.1AB	Special screw		2
7	612.4.034.1A	Spring and plate		1
8	741.4.062.1A	Clip		1
9	0000.61078	Complete oil tank		1
10	893.4.005.1A	Cap		1
11	771.5.662.8B	Screw		1
12	741.4.043.1A	Hose guide		2
13	877.1.108.1A	Tube		1
14	539.4.003.1B	Switch		1
15	771.5.754.8B	Screw		1
16	117.1.044.1A	Adjuster rod		1
17	747.5.003.1A	Nut		1
18	184.1.005.1A	Fork		1
19	821.1.096.1AB	Pin		1
20	886.4.116.1A	O-ring		2
21	799.1.083.1B	Spring		1
22	829.1.078.1A	Holder		1
23	852.1.154.1A	Washer		1
24	8000.59056	Bush		1
25	764.1.011.2A	Rubber pad		1
26	457.2.036.1B	Brake control lever		1


NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
27	821.1.052.1AB	Pedal pin		1
28	884.5.016.1A	Circlip		1
29	747.5.005.1B	Nut		1
30	779.1.237.1B	Adjusting screw		1
31	772.5.029.1AB	Screw		2
32	625.4.004.1A	Rear brake pump		1
33	619.4.033.1A	Rear brake line		1
34	631.4.008.1A	Spare union		1
35	626.4.013.1A	Dust cover		1
36	612.4.030.1A	Dust cover		2
37	612.4.008.1A	Dust seal		1
38	631.4.028.1A	Spare bleed union		1
39	612.4.035.1A	Spare pins and spring		1
40	613.4.076.1A	Pads pair		1

DRAWING 034 FRONT HEAD-LIGHT

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
1	520.4.006.1C	Complete headlight		1
2	0796.38.305	Bulb 55/60W		1
3	0659.38.226	Bulb 4W		1
4	521.4.005.1A	Lamp holder		1
5	758.1.014.1A	Fairlead		1
6	723.1.003.1A	Cap		1
7	510.1.075.1A	Electric wiring		1
8	856.1.035.1A	Washer		2
9	771.5.725.8B	Screw		2
10	829.1.649.2AP	Front frame		1
11	771.5.078.8B	Screw		2
12	852.5.027.1A	Washer		2
13	748.1.042.1A	Nut		2

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
-----------	----------	-------------	----------	--

DRAWING 038 SEAT

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
1	779.1.104.1B	Special screw		1
2	247.1.281.1A	Cover		1
3	595.2.072.1A	Seat		1
4	483.1.050.1AE	Cover seat		1
5	775.1.008.3A	Screw		4
6	435.1.118.1A	Sticker "DUCATI"		1
7	435.1.117.1A	Sticker "Paul Smart1000"		2
8	772.5.037.1A	Screw		2
9	852.1.186.1A	Washer		2
10	829.1.673.2A	Mudflap		1
11	777.5.052.8B	Screw		2
12	598.1.006.1A	Flexible cable		1
13	913.7.109.1A	Owner's manual		1
14	697.2.020.1A	Tool bag		1
15	732.1.020.1A	Helmet anti-theft wire		1
16	866.1.061.1A	Rubber pad		2
17	736.5.003.1A	Shear rivet		2
18	598.1.005.1A	Seat lock		1
19	827.1.389.1A	Plate		1
20	852.1.156.1A	Spring washer		4
21	866.1.030.1A	Rubber pad		4

NOTES NO.	CODE NO.	DESCRIPTION	VALIDITY	Q.TY 
-----------	----------	-------------	----------	--

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL