



A TEREX BRAND

# *Parts Manual*

Serial Number Range

***Gyro-4020***

4020 from SN 12888 to 18910

***Gyro-4518***

4518 from SN 12508 to 19125

Part No. 645035

Rev D

April 2010

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Item	Part No.	Description	Qty.
1	09.4618.0113	LABEL.....	2
2	09.4618.0651	LABEL.....	2
3	09.4618.0435	LABEL.....	2
4	09.4612.0212	LABEL.....	2
5	09.4618.0271	LABEL.....	1
6	09.4618.0461	LABEL.....	1
7	09.4618.0504	LABEL.....	1
8	09.4618.0010	LABEL.....	1
9	09.4618.0561	LABEL.....	4
10	09.4618.0231	LABEL.....	-
11	09.4618.0361	LABEL.....	4
12	09.4616.0040	LABEL.....	2
13	09.4618.0682	LABEL.....	1
13	09.4618.0683	LABEL.....	1
13	09.4618.0684	LABEL.....	1
13	09.4618.0685	LABEL.....	1
13	09.4618.0686	LABEL.....	1
14	09.4618.0784	LABEL..... <i>Italian, French, Spanish, German, Portuguese, Dutch, Finnish</i>	1
14	09.4618.1349	LABEL..... <i>Bulgarian, Czech, Estonian, Latvian, Lithuanian, Polish, Romanian</i>	1
14	09.4618.1350	LABEL..... <i>Swedish, Greek, Hungarian, Slovak, Slovenian, Icelandic, Turkish</i>	1



## 204.1 604310 Transmission And Wheels

Item	Part No.	Description	Qty.
1	09.4632.0047	FRONT STEERING AXLE.....	1
2	09.4632.0048	REAR STEERING AXLE.....	1
3	09.4633.0017	REDUCTION GEAR.....	1
4	09.4635.0022	CARDAN SHAFT.....	1
5	09.4635.0021	CARDAN SHAFT.....	1
6	07.0738.0000	STAR WHEEL.....	4
7	55.0409.0086	COMPLETE RH FRONT/LH REAR MUD-GUARD.....	2
8	09.4635.0014	CARDAN JOINT ASSEMBLY KIT....	8
9	55.0409.0085	COMPLETE LH FRONT/RH REAR MUD-GUARD.....	2
10	55.0403.0039	WHEEL.....	4
11	51.0807.2300	SUPPORT.....	2
12	51.0807.2200	SUPPORT.....	2
13	09.0803.0281	MUD-GUARD.....	2
14	01.0001.0355	SCREW.....	16
15	09.4627.0014	TYRE.....	4
16	09.4629.0021	RIM.....	4
17	09.0803.0047	VALVE.....	4
18	51.0900.5300	GUARD.....	1
19	01.0031.0301	WASHER.....	16
20	01.4032.0004	WASHER.....	16
21	09.0803.0280	MUD-GUARD.....	2

209.1 604342 Front Axle Steering Cylinder

Item	Part No.	Description	Qty.
1	639671	SCREW.....	4
4	07.0709.0383	CYLINDER.....	1
5	07.0709.0497	ARTICULATED TIE ROD.....	2
8	07.0709.0419	JOINT KIT.....	1

Item	Part No.	Description	Qty.
1	07.0709.0398	SPACER.....	2
2	07.0709.0399	SPRING.....	4
3	07.0709.0400	PISTON.....	2
4	07.0709.0402	SEAL.....	2
5	07.0709.0401	SEAL.....	4
6	07.0709.0403	BACK-UP RING.....	4
7	07.0709.0404	COVER.....	2
8	633111	SEAL.....	2
9	07.0709.0405	BACK-UP RING.....	2
10	07.0709.0406	PISTON.....	2
11	07.0709.0407	BRAKE DISC.....	2
12	637622	SPRING.....	6
13	07.0709.0408	SCREW.....	6
14	639674	BRAKE DISC.....	8
15	639683	BRAKE DISC.....	8
16	07.0709.0409	SPACER.....	2
17	07.0709.0502	SCREW.....	4
18	07.0709.0411	SCREW.....	6
19	07.0709.0106	SPRING.....	6
20	638566	NUT.....	4
21	07.0709.0149	WASHER.....	4
22	630328	SCREW.....	4
23	638548	PLUG.....	4
24	07.0709.0412	THICKNESS.....	2
24	07.0709.0413	THICKNESS.....	2
24	07.0709.0414	THICKNESS.....	2
25	07.0709.0352	SCREW.....	4
26	07.0709.0351	SEALING WASHER.....	4

219.1 604302 Turret GYRO 4518

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	51.0108.6000	COLUMN.....	1	36	01.0031.0299	SPLUNGWASHER.....	6
2	51.0901.8000	CASING.....	1	37	09.4661.0014	PLUG.....	1
3	01.4006.0004	SCREW.....	5	38	01.0031.0055	PLAIN WASHER.....	34
4	09.0803.0011	WASHER.....	5	39	09.0803.0274	HINGE.....	2
5	09.4610.0028	DRIVING MIRROR..... <i>Up To Serial Number 18010</i>	2	40	52.1200.4100	COVER.....	1
5	09.4610.0033	DRIVING MIRROR..... <i>From Serial Number 18011</i>	1	41	52.1100.6400	BONNET.....	1
6	51.0810.7100	BAR..... <i>Up To Serial Number 18010</i>	1	42	01.4006.0010	SCREW.....	2
6	51.0810.9700	BAR..... <i>From Serial Number 18011</i>	1	43	01.0031.0055	PLAIN WASHER.....	2
7	01.0001.0256	SCREW.....	4	44	51.0600.3900	COVER.....	1
8	01.4032.0003	SPRING WASHER.....	4	45	51.0600.3800	COVER.....	1
9	54.0001.0040	PIN.....	1	46	01.0019.0104	STOP NUT.....	20
10	01.0031.0051	STOP NUT.....	8	47	01.0001.0045	PLAIN WASHER.....	20
11	01.4032.0006	SPRING WASHER.....	1	48	09.4661.0016	FILTER.....	2
12	01.0001.0605	SCREW.....	1	49	09.4661.0018	FILLER.....	1
13	09.4661.0015	PLUG.....	1				
14	01.0023.0054	NUT.....	3				
15	53.3301.0003	SEAL.....	2				
16	51.0600.3700	DIESEL OIL TANK.....	1				
17	09.4661.0005	LEVEL INDICATOR.....	1				
18	51.0600.3600	OIL TANK.....	1				
19	01.0031.0053	PLAIN WASHER.....	8				
20	01.0031.0151	PLAIN WASHER.....	8				
21	01.4001.0061	SCREW.....	8				
22	01.4032.0005	SPRING WASHER.....	8				
23	01.0001.0506	SCREW.....	8				
24	51.0807.8600	CASING.....	1				
25	51.0901.9400	CASING.....	1				
26	01.4032.0003	SPRING WASHER.....	34				
27	01.0001.0254	SCREW.....	34				
28	01.0023.0057	NUT.....	4				
29	01.0001.0357	SCREW.....	8				
30	09.4670.0006	INSULATOR.....	4				
31	01.4031.0001	PLAIN WASHER.....	4				
32	54.0100.0020	PROTECTION.....	4				
33	01.4032.0007	SPRING WASHER.....	4				
34	01.0001.0657	SCREW.....	4				
35	01.0001.0257	SCREW.....	3				



## 302.1 604317 Engine Supports And Accessories

Item	Part No.	Description	Qty.
1	09.4601.0026	DIESEL ENGINE.....	1
2	01.4001.0013	SCREW.....	4
3	07.4501.0086	INSULATOR.....	4
4	01.0023.0056	STOP NUT.....	4
5	07.4501.0070	OIL FILTER.....	1
6	07.4501.0071	DIESEL OIL FILTER.....	1
7	04.0227.0051	CLAMP.....	6
8	09.0805.0070	RUBBER HOSE.....	1.08-m
9	09.0805.0070	RUBBER HOSE.....	3.00-m
10	638747	PROTECTION.....	1
11	07.0700.0020	CARTRIDGE.....	1
1/1	07.4501.0092	SUPPORT.....	2
12	638748	ELASTIC JOINT.....	1
1/2	07.4501.0093	SUPPORT.....	2
13	01.0031.0299	PLAIN WASHER.....	2
14	01.4032.0003	SPRING WASHER.....	2
15	01.0001.0257	SCREW.....	2
16	09.0804.1400	HANDWHEEL ARRANGEMENT.....	1
17	07.0713.0056	STOP RING.....	1
18	634873	STOP RING.....	1
19	07.0713.0048	HUB.....	1
20	07.0713.0008	WASHER.....	8
21	07.0713.0024	SCREW.....	20
22	56.0013.0001	FUEL GAUGE.....	1
23	01.0031.0057	PLAIN WASHER.....	8
24	09.0805.0070	RUBBER HOSE.....	3.04-m
25	07.0713.0023	SPRING WASHER.....	12

403.1 604299 Cab (from SN 15155)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0066	FILTER.....	1	41	07.0740.0098	TANK.....	1
2	07.0740.0067	GRATE.....	1	42	07.0740.0099	GLASS.....	1
3	07.0740.0068	BALL-GRIP.....	2	43	07.0740.0100	STOP.....	1
4	07.0740.0069	SEAL.....	1	44	07.0740.0101	GUARD.....	1
5	07.0740.0070	SHEET.....	1	45	07.0740.0102	WASHER.....	1
6	07.0740.0026	WASHER.....	12	46	07.0740.0103	NUT.....	1
7	07.0740.0071	SCREW.....	18	47	07.0740.0104	DOOR STOP.....	1
8	07.0740.0072	WIPER MOTOR.....	1	48	07.0740.0105	SCREW.....	3
9	07.0740.0073	GLASS.....	1	49	07.0740.0106	SEAL.....	1
10	07.0740.0074	GLASS.....	1	50	07.0740.0028	HEX CAP.....	6
11	07.0740.0246	GLASS.....	1	51	07.0740.0006	WASHER.....	10
12	07.0740.0052	SEAL.....	1,5-m	52	07.0740.0005	STOP NUT.....	3
13	07.0740.0076	HANDLE.....	2	53	07.0740.0107	FRAME.....	1
14	07.0740.0217	SPLIT PIN.....	2	54	07.0740.0178	SUPPORT.....	1
15	07.0740.0078	HINGE.....	2	55	07.0740.0114	LOCK.....	1
16	07.0740.0079	SCREW.....	7	56	07.0740.0115	BRACKET.....	1
17	07.0740.0046	STOP NUT.....	7	57	07.0740.0116	SCREW.....	4
18	07.0740.0014	HEX CAP.....	7	58	07.0740.0117	WASHER.....	4
19	07.0740.0080	RUBBER.....	2	59	07.0740.0247	KIT.....	1
20	07.0740.0081	WASHER.....	3	60	07.0740.0202	DRIVING MIRROR.....	1
21	07.0740.0082	LOADSPEAKER FRAME.....	2	61	07.0740.0157	WIPER BLADE.....	1
22	07.0740.0083	SCREW.....	8	62	07.0740.0158	WIPER MOTOR.....	1
23	07.0740.0084	ROOF LAMP.....	1	63	07.0740.0210	RUBBER.....	1
24	07.0740.0064	SCREW.....	2	64	07.0740.0211	SPACER.....	1
25	07.0740.0085	GLASS.....	1	65	07.0740.0212	SCREW.....	2
26	07.0740.0009	RUBBER.....	3	66	07.0740.0213	BUSHING.....	2
27	07.0740.0086	RUBBER.....	1	67	07.0740.0214	RUBBER.....	2
28	07.0740.0032	WASHER.....	1	68	07.0740.0035	RUBBER.....	2
29	07.0740.0087	GLASS.....	1	69	07.0740.0215	SPACER.....	2
30	07.0740.0088	WIPER ARM.....	1	70	07.0740.0156	WIPER ARM.....	1
31	07.0740.0089	WIPER BLADE.....	1	71	07.0740.0209	KIT.....	1
32	07.0740.0090	THROUGH COUPLING.....	1	72	07.0740.0156	WIPER ARM.....	1
33	07.0740.0091	SEAL.....	1,5-m	73	07.0740.0163	SCREW.....	2
34	07.0740.0092	LOCK.....	1	74	07.0740.0117	BUSHING.....	2
35	07.0740.0012	WASHER.....	16	75	07.0740.0248	WIPER BLADE.....	1
36	07.0740.0093	STORAGE POCKET.....	1	76	07.0740.0016	RUBBER.....	2
37	07.0740.0094	SCREW.....	4				
38	07.0740.0095	SCREW.....	4				
39	07.0740.0096	STOP NUT.....	2				
40	07.0740.0097	ARM.....	2				



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Item	Part No.	Description	Qty.
1	51.1300.5100	PLATE.....	1
2	51.1301.2500	FORK.....	2
3	54.0000.0083	PIN.....	1
4	54.0100.0056	WASHER.....	1
5	01.0001.0409	SCREW.....	1
6	01.0023.0056	NUT.....	1
7	09.0803.0055	CHAIN.....	0,45-m
8	09.0803.0026	SPRING SPLIT PIN.....	2
9	07.0726.0051	PIN.....	2
10	01.4041.0005	SECURITY DOWEL.....	2
11	01.4019.0004	NUT.....	2
12	02.4115.0000	RIVET.....	2
13	09.4616.0109	NAME PLATE.....	1

## 506.1 605265 Chains Unit 3rd - 4th Boom Section

Item	Part No.	Description	Qty.
1	09.0803.0241	CHAIN.....	2
2	902993	SCREW.....	20
3	51.0806.4000	END PIECE.....	2
4	54.0004.0097	PIN.....	1
5	09.0801.0020	BUSHING.....	4
6	02.0017.0051	GREASE NIPPLE.....	2
7	09.0803.0253	CHAIN.....	4
8	51.0806.4100	END PIECE.....	4
9	54.0400.0021	PULLEY.....	1
10	54.0400.0023	PULLEY.....	1
11	51.0806.4500	SUPPORT.....	2
12	54.0000.0106	PIN.....	1
13	54.0002.0018	DOWEL.....	12
14	902671	SCREW.....	8
15	04.0600.0053	PIPE FITTING.....	1
16	51.0806.3200	END PIECE.....	4
17	01.4041.0002	SECURITY DOWEL.....	2
18	02.0117.0101	GREASE NIPPLE.....	1
19	52.0900.2800	PIPE.....	1
20	01.4006.0001	SCREW.....	2
21	01.4032.0009	SPRING WASHER.....	20
22	04.0600.0178	PIPE FITTING.....	2
23	01.4006.0013	SCREW.....	1

604.1 604322 Hydraulic Transmission

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	04.4238.0037	PUMP.....	1	41	07.0742.0009	SOLENOID.....	1
2	04.4235.0022	HYDRAULIC MOTOR.....	1	42	04.0605.0618	FLEXIBLE HOSE.....	1
3	06.0401.0219	SEAL.....	8	43		604327 POS. 59	
4	04.4229.0040	FLEXIBLE HOSE.....	1				
5	04.4229.0041	FLEXIBLE HOSE.....	1				
6	04.4223.0003	HALF FLANGE.....	16				
7	01.0001.0401	SCREW.....	32				
8	06.0442.0059	WASHER.....	2				
9	05.0401.0013	PIPE FITTING.....	1				
10	01.4032.0005	WASHER.....	1				
11		PLUG.....	1				
12	07.0742.0012	JOINT KIT.....	1				
13	04.0607.0107	PIPE FITTING.....	2				
14	04.0607.0180	PIPE FITTING.....	1				
15	04.4229.0043	FLEXIBLE HOSE.....	1				
16	04.0605.0450	FLEXIBLE HOSE.....	1				
17	04.0605.0527	FLEXIBLE HOSE.....	1				
18	04.0607.0182	PIPE FITTING.....	4				
19	04.0605.0487	FLEXIBLE HOSE.....	1				
20	04.0607.0130	PIPE FITTING.....	1				
21	06.0442.0107	WASHER.....	1				
22	04.4239.0033	VALVE.....	1				
23	04.0600.0066	PIPE FITTING.....	1				
24	04.0600.0059	PIPE FITTING.....	1				
25	04.0600.0156	PIPE FITTING.....	1				
26	04.0607.0036	PIPE FITTING.....	1				
27	04.0600.0171	DRILLED SCREW.....	1				
28	04.4210.0003	PRESSURE TUBE.....	1				
29	04.0605.0526	FLEXIBLE HOSE.....	1				
30	04.0607.0115	PIPE FITTING.....	2				
31	04.0607.0153	PIPE FITTING.....	1				
32	07.0742.0008	SOLENOID.....	2				
33	04.0605.0429	FLEXIBLE HOSE.....	1				
34	627043	SOLENOID.....	1				
35	04.0607.0166	PIPE FITTING.....	1				
36	04.0605.0513	FLEXIBLE HOSE.....	1				
37	04.4229.0042	FLEXIBLE HOSE.....	1				
38	07.0742.0013	VALVE.....	1				
39	07.0742.0010	JOINT KIT.....	1				
40	07.0742.0011	OIL SEAL.....	2				



609.1 604327 Suction System Hydraulic Pumps (to SN 16595)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	04.4224.0001	VALVE.....	1	44	04.0607.0192	PIPE FITTING.....	1
2	53.3001.2300	MANIFOLD.....	1	45		604326 pos.25	
3	04.0605.0619	FLEXIBLE HOSE.....	1	46	07.0700.0002	CARTRIDGE.....	1
4	04.0600.0134	FLANGE.....	1	47	04.0607.0190	PIPE FITTING.....	1
5	07.4529.0095	SEAL.....	2	48	04.0607.0111	PIPE FITTING.....	1
6	04.0607.0106	PIPE FITTING.....	1	49	07.4529.0099	SEAL.....	1
7	04.4238.0056	PUMP.....	1	50	04.4223.0006	FLANGE.....	1
8	04.4223.0010	FLANGE.....	1	51	01.0003.0158	SCREW.....	2
10	06.0442.0107	WASHER.....	1	52	01.4001.0046	SCREW.....	2
11	04.0600.0066	PIPE FITTING.....	1	53	07.0722.0013	SOLENOID.....	1
12	04.4239.0026	VALVE.....	1	54	01.4003.0015	SCREW.....	2
13	04.0607.0130	PIPE FITTING.....	1	55	07.4529.0098	SEAL.....	1
14		604324 pos.26		56	04.4239.0057	VALVE.....	1
15	04.0607.0153	PIPE FITTING.....	1	58		604325 pos.41	
16		604325 pos.28		59	04.0605.0596	FLEXIBLE HOSE.....	1
17	04.0607.0182	PIPE FITTING.....	1	60	04.4239.0098	PUMP.....	1
18	04.0605.0490	FLEXIBLE HOSE.....	1	61	04.4238.0074	SECURITY ELECTRICAL MOTOR.....	1
19	991896	SEAL.....	1	62	07.0722.0058	ELECTRIC MOTOR.....	1
20	04.0605.0497	FLEXIBLE HOSE.....	1				
21	04.4238.0040	PUMP.....	1				
22	07.0722.0054	JOINT KIT.....	1				
23	04.0607.0101	PIPE FITTING.....	1				
24		604321 pos.24					
25	04.0607.0169	PIPE FITTING.....	1				
26	04.0605.0468	FLEXIBLE HOSE.....	1				
27	04.0607.0145	PIPE FITTING.....	1				
28	04.4223.0007	FLANGE.....	1				
29	04.0600.0060	PIPE FITTING.....	1				
31	04.4239.0032	VALVE.....	1				
32		604324 pos.20					
33	04.4238.0048	PUMP.....	1				
34	09.4604.0005	FILTER.....	1				
35	01.0003.0159	SCREW.....	2				
36	04.0607.0172	PIPE FITTING.....	1				
37	04.0605.0496	FLEXIBLE HOSE.....	1				
38	04.0607.0183	PIPE FITTING.....	1				
39	04.0607.0117	PIPE FITTING.....	1				
41	04.0607.0059	PIPE FITTING.....	1				
42	04.0607.0185	PIPE FITTING.....	1				
43	04.0607.0194	PIPE FITTING.....	1				



## 614.1 605267 Stabilizer Hydraulic System GYRO 4020

Item	Part No.	Description	Qty.
1	01.0003.0155	SCREW.....	56
2	53.3401.9500	IRON PIPE.....	8
3	04.4239.0002	VALVE.....	4
4	04.0607.0117	PIPE FITTING.....	24
5	09.0803.0064	RETAINER PIPE.....	32
6	04.0605.0430	FLEXIBLE HOSE.....	20
7	04.0607.0111	PIPE FITTING.....	4
8	07.0728.0007	SOLENOID.....	16
9	04.4236.0053	HYDRAULIC BLOCK.....	2
10		605270 pos.33	
11	07.0728.0006	JOINT KIT.....	2
12	04.0605.0440	FLEXIBLE HOSE.....	8
13	04.0600.0022	PIPE FITTING.....	12
14		605270 pos.12	
15	01.0003.0207	SCREW.....	24
16	53.3400.4900	IRON PIPE.....	5
17	04.4239.0030	VALVE.....	4
18	04.0600.0089	PIPE FITTING.....	4
19	04.0607.0163	PIPE FITTING.....	8
20	04.0600.0069	PIPE FITTING.....	4
21		605270 pos.24	
22	04.0605.0552	FLEXIBLE HOSE.....	4
23	04.0605.0439	FLEXIBLE HOSE.....	4
24	04.0605.0438	FLEXIBLE HOSE.....	4
25	53.3402.1200	IRON PIPE.....	2
26	53.3402.1100	IRON PIPE.....	2
27	53.3402.1300	IRON PIPE.....	2
28	53.3402.1400	IRON PIPE.....	2
29	53.3402.1600	IRON PIPE.....	2
30	53.3402.1500	IRON PIPE.....	2
31	53.3402.1000	IRON PIPE.....	2
32	53.3402.0900	IRON PIPE.....	2
33		605270 pos.38	
34	07.0705.0087	JOINT KIT.....	1
35	07.0728.0008	SEAL.....	3
36	01.0003.0157	SCREW.....	8

## 619.1 604332 Lifting Hydraulic System GYRO 4518

Item	Part No.	Description	Qty.
1	53.0000.2400	LIFTING JACK.....	1
2	07.4529.0105	JOINT KIT.....	1
3	09.0801.0001	BUSHING.....	4
4	02.0017.0101	GREASE NIPPLE.....	2
5	07.0721.0099	LINER.....	1
6	04.4239.0078	VALVE.....	1
7	07.0721.0100	PLUG.....	1
8	01.4003.0007	SCREW.....	4
9	07.0721.0098	ROD.....	1
10	04.0607.0171	PIPE FITTING.....	2
11	04.0607.0186	PIPE FITTING.....	1
12	54.0000.0130	PIN.....	1
13	01.4032.0005	WASHER.....	2
14	01.0001.0506	SCREW.....	2
15	04.0607.0107	PIPE FITTING.....	2
16	04.0605.0493	FLEXIBLE HOSE.....	2
17	04.0605.0475	FLEXIBLE HOSE.....	1
18	04.0607.0173	PIPE FITTING.....	1
19	05.4239.0011	ACCUMULATOR.....	1
20	51.0803.0800	BRACKET.....	1
21	04.4236.0061	CONTROL VALVE..... <i>Up To Serial Number 16952</i>	1
21	04.4236.0076	CONTROL VALVE..... <i>From Serial Number 16953</i>	1
22	07.0741.0003	VALVE.....	2
23	01.0031.0055	PLAIN WASHER.....	2
24	07.0741.0006	SOLENOID.....	1
25	07.0741.0008	VALVE.....	1
26	56.0021.0091	MODULUS.....	1
27	56.0021.0090	MODULUS.....	1
28	07.0741.0028	JOINT KIT.....	1
29	51.0807.3100	PLATE.....	1
30	01.0031.0057	PLAIN WASHER.....	2
31	01.0001.0466	SCREW.....	1
32	01.0023.0054	NUT.....	1
33	01.0001.0254	SCREW.....	2
34	01.4032.0003	SPRING WASHER.....	2
35	56.0021.0089	MODULUS.....	1
36	56.0021.0088	MODULUS.....	1
37	56.0021.0087	MODULUS.....	1

703.1 604806 Front Under Carriage Electrical Line

Item	Part No.	Description	Qty.
1	55.0602.0267	WIRING HARNESS.....	1
2	56.0012.0016	MICROSWITCH.....	2
3	01.0001.0035	STOP NUT.....	4
4	01.0001.0100	PLAIN WASHER.....	16
5	01.4003.0025	SCREW.....	12
6	51.0807.9700	SUPPORT.....	1
7	51.0807.9600	SUPPORT.....	1
8	01.4006.0006	SCREW.....	4
9	56.0012.0010	MICROSWITCH.....	2
10	56.0021.0055	CONTROL UNIT.....	1
11	01.0001.0154	SCREW.....	4
12	09.0803.0344	SPRING CATCH.....	2
13	01.0031.0292	PLAIN WASHER.....	4
14	56.0013.0026	REEL.....	2
15	01.0023.0053	STOP NUT.....	4
16	01.0001.0156	SCREW.....	4
17	56.0023.0019	SWIVEL SOCKET.....	1
18	01.4032.0002	SPRING WASHER.....	4
19	07.0736.0020	ROTAX.....	1

708.1 605271 Central Under Carriage Electrical Line

Item	Part No.	Description	Qty.
1	55.0602.0268	WIRING HARNESS.....	1
2	56.0012.0012	LEVEL.....	1
3	01.0003.0158	SCREW.....	3
4	01.0031.0054	PLAIN WASHER.....	3
5	01.0019.0103	NUT.....	6
6		604323 pos.5	
7		604297 pos.2	
8		605270 pos.34 GYRO 4020 - 604296 pos. 34 GYRO 4518	
9		604810 pos.12	
10	56.0012.0021	PROXIMITY SWITCH.....	2
11		604310 pos.3	
12		604322 pos.2	
13		604320 pos.20	
14	07.0709.0730	PROXIMITY SWITCH.....	2

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

(  
 (BASE) END.....53, 55  
 1  
 1ST TELESCOPIC ELEMENT.....85  
 2  
 2ND TELESCOPIC ELEMENT.....85  
 3  
 3RD TELESCOPIC ELEMENT.....87  
 4  
 4TH TELESCOPIC ELEMENT.....87  
 6  
 604297 pos. 33.....155  
 604297 pos.19.....155  
 604297 pos.2.....151, 155  
 604297 pos.24.....115  
 604297 pos.27.....115  
 604297 pos.29.....107  
 604297 pos.39.....99  
 604297 pos.41.....97  
 604310 pos.3.....151  
 604320 pos.1.....153  
 604320 pos.20.....151  
 604320 pos.5.....103  
 604321 pos.22.....103  
 604321 pos.24.....111, 113  
 604322 pos.1.....143  
 604322 pos.16.....103  
 604322 pos.17.....109  
 604322 pos.2.....151  
 604322 pos.33.....97  
 604322 pos.36.....107  
 604323 pos.5.....151  
 604324 pos.20.....111, 113  
 604324 pos.26.....111, 113  
 604325 pos.25.....117  
 604325 pos.26.....105  
 604325 pos.27.....109  
 604325 pos.28.....111, 113  
 604325 pos.29.....105  
 604325 pos.41.....111, 113  
 604326 pos.22.....97  
 604326 pos.25.....111, 113  
 604327 POS. 59.....101  
 604327 pos.33.....143  
 604329 pos. 21.....153  
 604810 pos.12.....151  
 604957 pos.1.....149  
 605269 pos. 1 GYRO 4020 - 604332 pos.1  
 GYRO 4518.....153  
 605269 pos.21 GYRO 4020 - 604332 pos.21  
 GYRO 4518.....155  
 605270 pos.12.....121, 123  
 605270 pos.24.....121, 123  
 605270 pos.33.....121, 123  
 605270 pos.34 GYRO 4020 - 604296 pos. 34  
 GYRO 4518.....151  
 605270 pos.38.....121, 123  
 605272 pos.1.....155

**A**  
 ACCUMULATOR.....97, 99, 129, 131  
 ADHESIVE PROFILE.....77, 79  
 AIR INLET.....73, 77  
 ARM.....27, 39, 69, 71  
 ARTICULATED TIE ROD.....31, 43  
**B**  
 BACK-UP RING.....29, 41, 115  
 BALL-GRIP.....67, 69, 71, 73, 99  
 BAND.....109  
 BAR.....49, 51  
 BATTERY.....143  
 BEARING.....25, 27, 37, 39, 47  
 BEVEL GEAR SET.....25, 37  
 BONNET.....49, 51  
 BRACKET..15, 17, 57, 59, 65, 69, 71, 95, 103,  
 125, 127, 129, 131, 143, 145, 155  
 BRAKE DISC.....29, 41  
 BREATHER PLUG.....23, 35, 47  
 BUBBLE LEVEL.....67  
 BULB.....149  
 BUSHIN.....27, 33, 39, 45  
 BUSHING.....27, 33, 39, 45, 53, 55, 67, 69, 71,  
 77, 79, 83, 85, 87, 89, 91, 115, 129, 131  
**C**  
 CABLE.....57, 143, 145  
 CAP.....67  
 CARD.....137  
 CARDAN JOINT ASSEMBLY KIT.....21  
 CARDAN SHAFT.....21  
 CARTRIDGE.....61, 65, 111, 113  
 CASING.....15, 19, 49, 51, 53, 55  
 CHAIN.....57, 81, 89, 91, 93, 145  
 CHECK VALVE.....117  
 CLAMP.....59, 61, 63, 65, 73, 93, 145  
 CLIP.....77  
 COATING.....77, 79  
 COLUMN.....49, 51  
 COMPL. REAR DIFFERENTIAL GEAR.....37  
 COMPLETE FILTER.....65  
 COMPLETE JOINT.....103  
 COMPLETE LH FRONT/RH REAR  
 MUD-GUARD.....21  
 COMPLETE RADIATOR.....109  
 COMPLETE REEL.....145  
 COMPLETE RELIEF VALVE.....97  
 COMPLETE RH FRONT/LH REAR  
 MUD-GUARD.....21  
 CONNECTING ROD.....83  
 CONNECTION.....17, 19, 67  
 CONTACT.....67, 75, 155  
 CONTROL LEVER.....67  
 CONTROL PANEL.....67, 75  
 CONTROL UNIT.....139, 141, 143, 145, 149  
 CONTROL VALVE.....129, 131  
 CONVEYOR.....109  
 COTTER PIN.....89, 93  
 COVER.....19, 23, 35, 41, 47, 49, 51, 67, 143,  
 145  
 CYLINDER.....17, 31, 43, 47, 53, 55, 95, 119

**D**  
 DASH BOARD.....75  
 DASHBOARD.....67  
 DIESEL ENGINE.....61  
 DIESEL OIL FILTER.....61  
 DIESEL OIL TANK.....49, 51  
 DIFFERENTIAL.....25  
 DIFFERENTIAL CASE.....25, 37  
 DIFFERENTIAL PINION.....25, 27, 37, 39  
 DIFFERENTIAL SIDE GEAR.....25, 37  
 DISC.....25  
 DOOR LATCH.....15  
 DOOR STOP.....69, 71  
 DOWEL.....29, 47, 91  
 DRILLED SCREW.....97, 99, 101, 115  
 DRIVING MIRROR.....49, 51, 69, 71  
 DUCT.....93  
 DUST EXCLUDER.....27, 39  
**E**  
 ELASTIC JOINT.....61  
 ELECTRIC BOX.....139, 143  
 ELECTRIC MOTOR.....111, 113  
 EMERGENCY BUTTON.....67  
 END PIECE.....89, 91  
 EXHAUST MUFFLER.....63  
 EXTENSION CYLINDER.....53, 55, 125, 127  
**F**  
 FAN.....109  
 FEMALE COUPLING.....119  
 FILLER.....49, 51  
 FILTER.....49, 51, 69, 71, 111, 113  
 FLANGE.....25, 37, 47, 107, 111, 113  
 FLEXIBLE HOSE.....93, 95, 97, 99, 101, 103,  
 105, 107, 109, 111, 113, 115, 117, 119, 121,  
 123, 125, 127, 129, 131, 133, 135  
 FOOTSTEP BEARING.....19  
 FORK.....81  
 FORK COUPLING ATTACHMENT.....83  
 FORKS ARTICULATION CYLINDER.....115  
 FRAME.....19, 69, 71, 77, 79  
 FRONT STEERING AXLE.....21  
 FUEL GAUGE.....61  
 FUSE.....137, 143, 147  
 FUSE HOLDER.....143, 147  
**G**  
 GEAR.....47  
 GLASS.....69, 71, 75, 77, 79  
 GRATE.....17, 69, 71  
 GREASE NIPPLE.....27, 33, 39, 45, 77, 79, 85,  
 87, 89, 91, 129, 131  
 GUARD.....17, 21, 53, 55, 63, 69, 71, 109, 133,  
 135  
**H**  
 HALF FLANGE.....101  
 HANDLE.....15, 17, 19, 67, 69, 71, 77, 79  
 HANDWHEEL ARRANGEMENT.....61  
 HEATER.....73  
 HEX CAP.....69, 71, 73, 77, 79  
 HINGE.....15, 17, 19, 49, 51, 69, 71, 77, 79

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL