

PR 60-018.




**GMS 2800/3200
HYDRO-FLEX**

Skiveslåmaskine med crimper/Scheibenmäher Disc Mower/Faucheuses conditionneuses

Reservedelsliste/Ersatzteilliste Spare Parts List/Liste de pièces

3



Gyldig fra:	Maj 1991	Fabrikationsnr.:	GMS 2800	1311	GMS 3200	1359
Gültig ab:	Mai 1991	Maschinen Nr.:	GMS 2800	1311	GMS 3200	1359
Valid from:	May 1991	Serial No.:	GMS 2800	1311	GMS 3200	1359
Valable à partir de:	Mai 1991	No. de serie:	GMS 2800	1311	GMS 3200	1359

Notér nummeret på Deres maskine på omslagets inderside.

Notieren Sie die Nummer Ihrer Maschine auf der Innenseite des Umschlages.

Please note the serial number of Your machine at the inside of the cover.

Veuillez noter le numero de Votre machine sur la face interne de la couverture.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Fig. 3.

POS.	NUMMER	2800	3200	BETEGNELSE	BEZEICHNUNG	DESIGNATION	HERTIL, DAZU, TO THIS, A CECI:
1	2010-537x	2	2	Håndtag Handgriff		Handle Poignée	1399-0185 Ø 30 M 8 1
2	2226-190x	2	2	Spindel Spindel		Spindle Arbre	
3	2061-002x	2	2	Kugleskive Kugelscheibe		Ball washer Rondelle à balle	1434-0108 1
4	3226-776x	1	1	Aflastningsfjeder Entlastungsfeder		Relief spring Ressort de déchargement	
5	3226-439x	1	1	Holder Halterung		Support Support	
6	2228-354x	4	4	Tap Zapfen		Dowel Cheville	1251-3301 5x40 1 1251-5303 8x40 1
7	2226-408x	1	1	Tap Zapfen		Dowel Cheville	1251-5404 8x55 4 1251-8402 14x55 4
8	3226-725A	1	-	Ramme Rahmen		Frame Bâti	
	3226-114A	-	1	Ramme Rahmen		Frame Bâti	
9	3226-048x	1	1	Skærm, højre Schutz, rechts		Guard, right Protection, droite	1211-3328 M 10x90 1 1220-3321 M 10 1
10	2228-355x	2	2	Tap Zapfen		Dowel Cheville	1251-3301 5x40 1 1251-5303 8x40 1
11	3226-225x	1	1	Forbindelsesstang, højre Verbindungsstange, rechts		Connection rod, right Tige d'assemblage, droite	
12	3226-047x	1	1	Skærm, venstre Schutz, links		Guard, left Protection gauche	Se, see, siehe, voir pos. 9
13	1399-0242	2	2	Topstang Topstange		Top rod Barre supérieur	
14	2226-810x	2	2	Kæde Kette		Chain Chaîne	1213-4324 M 12x35 1 1220-4323 M 12 1
15	3226-229x	1	1	Forbindelsesstang, venstre Verbindungsstange, linke		Connection rod left Tige d'assemblage gauche	
16	1254-3102	2	2	Split Ø 8x55 Splint Ø 8x55		Special pin Ø 8x55 Goupille mécanindus Ø 8x55	
17	3226-762A	1	-	Stel Rahmen		Frame Bâti	
	3226-174A	-	1	Stel Rahmen		Frame Bâti	1214-3424 M 10x110 8 1220-3321 M 10 8
18	3226-777x	1	1	Aflastningsfjeder Entlastungsfeder		Relief spring Ressort de déchargement	
19	3226-440x	1	1	Holder Halterung		Support Support	

Fig. 6.

POS.	NUMMER	2800	3200	BETEGNELSE	BEZEICHNUNG	DESIGNATION	HERTIL,DAZU,TO THIS,A CECI:	
24	2226-301x	68	-	Holder	Halterung	Support	1219-0260 M 12x50	1
	2226-1624	-	80	Holder	Halterung	Support	1220-4323 M 12	1
25	3226-461x	1	1	Tap	Zapfen	Dowel		
						Cheville		
26	1338-0117	1	1	Pasfeder	Federkeil	Flat key		
						Clavette		
27	2226-192x	1	1	Lejestyr	Lagersteuer	Bearing guide	1220-4323 M 12	4
						Guidage de roulement		
28	1331-4309	1	1	Kugleleje	Kugellager	Ball bearing		
						Roulement		
29	1255-8104	1	1	Låsering	Schlossring	Locking ring		
						Anneau de verrouillage		
30	1361-9721	3	3	Kilerem	Keilriemen	V-belt		
						Courroie		
31	1255-5201	1	1	Låsering	Schlossring	Locking ring		
						Anneau de verrouillage		
32	2226-646x	1	1	Skive	Scheibe	Washer		
						Rondelle		
33	2226-082x	2	2	Spændebolt	Spannbolzen	Tightening bolt		
						Boulon à tendre		
34	3226-347x	1	-	Trykplade	Druckplatte	Thrust plate	1215-5522 M 16x50	2
						Plateau de pression	1220-5321 M 16	2
	3226-079x	-	1	Trykplade	Druckplatte	Thrust plate	1215-5522 M 16x50	2
						Plateau de pression	1220-5321 M 16	2
35	2226-800x	1	1	Trappeskive	Stufenscheibe	Stepped pulley	1213-5424 M 16x35	1
						Poulie étagée		
36	1255-5101	2	2	Låsering I 52	Sicherungsring I 52	Locking ring I 52		
						Anneau de verrouillage		

POS.	NUMMER	2800	3200	BETEGNELSE	BEZEICHNUNG	DESIGNATION
1	1165-0190	-	1	Afblandingsprop Abdeckplatten		Blank-off plug Bouchon de fermeture
2	2085-615x	-	8	Låsemøtrik Gegenmutter		Lock nut Ecrou de blocage
3	2085-616x	-	8	Tallerkenskive Tellerscheibe		Disc spring Rondelle de disque
4	2085-060A	-	16	Profil kniv Profilmesser		Profile knife Lame profile
5	1220-4323	-	16	Møtrik Mutter		Nut Ecrou
6	1219-0809	-	16	Knivbolt Klingenbolzen		Bolt for knife Boulon pour lame
7	3081-262A	-	1	Skive med medbringer Scheibe mit Mitnehmer		Washer with carrier Disque avec rabatteur
8	2085-610x	-	8	Låsering Schlossring		Lock ring Anneau de verrouillage
9	2085-609x	-	8	Kugleleje Kugellager		Ball bearing Roulement
10	2085-611x	-	8	Lejehus Lagergehäuse		Bearing housing Boîte de roulement
11	2085-204x	-	8	O-ring O-Ring		O-ring Anneau en O
12	2085-201x	-	32	O-ring O-Ring		O-ring Anneau en O
13	2085-202x	-	32	Stålskrue Stahlschraube		Steel screw Vis d'acier
14	3081-261A	-	6	Skive HD Scheibe HD		Washer HD Disque HD
15	3226-369x	-	1	Medbringer Mitnehmer		Carrier Rabatteur
16	3226-025A	-	1	Skive Scheibe		Washer Disque
17	2085-614x	-	4	Drivhjul Antriebsrad		Driving wheel Roue d'entraînement
18	2085-612x	-	4	Drivhjul Antriebsrad		Driving wheel Roue d'entraînement
19	2085-188x	-	14	Stålskrue Stahlschraube		Steel screw Vis d'acier
20	2085-182x	-	7	Mellemhjul Zwischenrad		Intermediate wheel Roue intermédiaire
21	2085-189x	-	28	Låsering Schlossring		Lock ring Anneau de verrouillage
22	2085-190x	-	14	Kugleleje Kugellager		Ball bearing Roulement
23	2085-191x	-	14	Nylonbøsning Nylon Buchse		Nylon bush Douille de nylon
24	2085-192x	-	14	Afstandsring Distanzring		Distance ring Anneau d'espacement
25	2085-183x	-	7	Mellemhjul Zwischenrad		Intermediate wheel Roue intermédiaire

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL