

755C CRAWLER LOADER



JOHN DEERE

PARTS CATALOG

755C CRAWLER LOADER

PC2887 (Oct-06) English

Worldwide Construction and Forestry Division

Worldwide Edition
Litho in U.S.A. (Revised)
COPYRIGHT © 2006
DEERE & COMPANY
Moline, Illinois
All rights reserved

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
CAB HEAD LINER SEALING TRIM.....	1813-4	CAB REAR WINDOW WIPER COVER.....	1810-8
CAB HEADLIGHTS.....	1673-2	CAB REMOVAL, EYEBOLT.....	2005-2
CAB HEATER (LOCATION).....	1810-4	CAB SIDE COMPARTMENT DOORS.....	1913-4
CAB HEATER AND A/C CONTROLS.....	1834-4	CAB SIDE WINDOW GLASS.....	1813-2
CAB HEATER AND AIR CONDITIONER MOUNTING PARTS.....	1830-2	CAB SLIDING SIDE WINDOW.....	1814-14
CAB HEATER COMPONENT PARTS.....	1830-4	CAB SLIDING SIDE WINDOW ADHESIVE.....	1814-14
CAB HEATER CONTROLS.....	1834-2	CAB SPEAKERS BRACKET.....	1810-14
CAB HEATER ELECTRICAL CONNECTORS.....	1674-28	CAB STORAGE COMPARTMENT.....	1810-10
CAB HEATER FAN SPEED CONTROL.....	1834-2	CAB STORAGE COMPARTMENT COVER, FOOTREST AND DOOR STOPS.....	1810-12
CAB HEATER FAN SWITCH.....	1834-2	CAB STORAGE COMPARTMENT LATCH.....	1810-10
CAB HEATER TEMPERATURE CONTROL.....	1834-2	CAB STORAGE COMPARTMENT MAT.....	1810-10
CAB INTERIOR DECALS AND LABELS.....	1322-4	CAB STORAGE COMPARTMENT SEALING TRIM.....	1810-10
CAB LIFT CYLINDER SEAL.....	1812-10	CAB STORAGE COMPARTMENT, FOOTREST, AND DOOR STOPS ANGLE BRACKET.....	1810-12
CAB LIGHT WIRING.....	1673-2	CAB TAIL LIGHT.....	1674-22
CAB OVERHEAD PANEL ELECTRICAL CONNECTOR TERMINAL (ROPS).....	1674-12	CAB TILT BEARING.....	1812-6
CAB OVERHEAD PANEL ELECTRICAL SOCKET (ROPS).....	1674-12	CAB TILT HAND PUMP (COMPONENTS).....	0360-54
CAB OVERHEAD PANEL FRAME (SERIAL NO. -006199).....	1674-14	CAB TILT LEVER.....	2005-2
CAB OVERHEAD PANEL FRAME (SERIAL NO. 006200-).....	1674-16	CAB TILT PUMP GASKET KIT.....	0360-54
CAB OVERHEAD PANEL FRAME (ROPS).....	1674-18	CAB TILT PUMP RELAY, BATTERY BOX, TRAY, AND CLAMP.....	1913-6
CAB OVERHEAD PANEL FUSES (SERIAL NO. -006199).....	1674-14	CAB TILT PUMP, HAND OPERATED CAB TILT.....	1913-6
CAB OVERHEAD PANEL FUSES (SERIAL NO. 006200-).....	1674-16	CAB TILT PUMP, BATTERY BOX, TRAY AND CLAMP.....	1913-6
CAB OVERHEAD PANEL FUSES (ROPS).....	1674-18	CAB TIPPING PROCEDURE DECAL.....	1322-2
CAB OVERHEAD PANEL LOUVER (SERIAL NO. -006199).....	1674-14	CAB WINDOW GLASS AND WEATHER STRIP.....	1814-10
CAB OVERHEAD PANEL LOUVER (SERIAL NO. 006200-).....	1674-16	CAB WINDOW GLASS AND WEATHER STRIP GUARD.....	1814-10
CAB OVERHEAD PANEL LOUVER (ROPS).....	1674-18	CAB WINDOW GLASS AND WEATHER STRIP, ISOLATOR.....	1814-10
CAB OVERHEAD PANEL SWITCHES (SERIAL NO. -006199).....	1674-14	CAB WINDOW GLASS AND WEATHER STRIP, WINDOWPANE.....	1814-10
CAB OVERHEAD PANEL SWITCHES (SERIAL NO. 006200-).....	1674-16	CAB WINDSHIELD WIPER MOTOR COVER.....	1810-14
CAB OVERHEAD PANEL SWITCHES (ROPS).....	1674-18	CAB WIPER, SHADE CURTAIN, MIRROR, AND LIGHT.....	1810-6
CAB OVERHEAD PANEL, FUSE HOLDER (SERIAL NO. -006199).....	1674-14	CAB WIRING HARNESS CAB LAMP.....	1674-22
CAB OVERHEAD PANEL, FUSE HOLDER (SERIAL NO. 006200-).....	1674-16	CAB WIRING HARNESS COMPONENTS.....	1674-22
CAB OVERHEAD PANEL, FUSE HOLDER (ROPS).....	1674-18	CAB WIRING HARNESS CONNECTORS.....	1674-24
CAB OVERHEAD PANEL, WIRING HARNESS AND RELAYS, ELECTRICAL SYSTEM (ROPS).....	1674-12	CAB WIRING HARNESS GROMMET.....	1674-22
CAB OVERHEAD PANEL, WIRING HARNESS AND RELAYS, ELECTRICAL SYSTEM (SN -006199).....	1674-8	CAB WIRING HARNESS LAMP BULB.....	1674-22
CAB OVERHEAD PANEL, WIRING HARNESS AND RELAYS, ELECTRICAL SYSTEM (SN 006200-).....	1674-10	CAB WIRING HARNESS SPEAKER COVERS.....	1674-22
CAB PLATFORM.....	1812-2	CAB WORK LIGHTS (LAMPS).....	1673-2
CAB PLATFORM FRONT MOUNTING LINK.....	1812-8	CAB WORK LIGHTS (LAMPS) BULB.....	1673-2
CAB PLATFORM FRONT MOUNTING LINK BUSHING.....	1812-8	CAB WORK LIGHTS (OPTIONAL).....	1673-6
CAB PLATFORM FRONT MOUNTING LINK RETAINER.....	1812-8	CAB WORK LIGHTS BULB (OPTIONAL).....	1673-6
CAB PLATFORM FRONT MOUNTING LINK BRACKET.....	1812-8	CAB WORK LIGHTS WIRING HARNESS.....	1673-2
CAB PLATFORM FRONT MOUNTING LINK HOUSING.....	1812-8	CAB WORKLIGHT FRAME.....	1810-14
CAB PLATFORM FRONT MOUNTING LINK PIN.....	1812-8	CABLE, CAB GROUND.....	1671-2
CAB PLATFORM FRONT MOUNTING SUPPORT.....	1812-8	CABLE, CAB STORAGE COMPARTMENT.....	1810-10
CAB PLATFORM ISOLATORS.....	1812-4	CABLE, CIRCUIT BREAKER TO BATTERY.....	1671-2
CAB PLATFORM PLATE.....	1812-6	CABLE, ENGINE THROTTLE CONTROL.....	0515-4
CAB PLATFORM PLATES AND TILT BEARING.....	1812-6	CABLE, GROUND.....	1671-2
CAB PROTECTION AND COMPONENT PARTS, LIMB RISERS.....	1810-22	CABLE, STARTER.....	1671-2
CAB PROTECTIVE SCREENS.....	1810-24	CABLE, STORAGE COMPARTMENT, CAB.....	1810-10
CAB REAR WINDOW WIPER (LOCATION).....	1810-8	CABLE, TOOLBOX.....	1810-10
		CABLE, ENGINE SPEED CONTROL.....	0515-4
		CABLE, ENGINE THROTTLE CONTROL.....	0515-6
		CABLES, BATTERY.....	1671-2
		CAMSHAFT, ENGINE.....	0402-2
		CANOPY, ROLLOVER PROTECTIVE STRUCTURE (ROPS).....	1810-2
		CAP (COVER) BUCKET CYLINDER.....	3143-6
		CAP, CRANKCASE BREATHER.....	0408-2
		CAP, RADIATOR FILLER (SERIAL NO. -006199).....	0510-6
		CAP, WASHER FLUID AND DOOR LATCHES.....	1813-2
		CAP, WINDOW WASHER RESERVOIR.....	1814-12
		CAP, WINDSHIELD WASHER RESERVOIR.....	1814-12

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
GEAR, FUEL INJECTION PUMP DRIVE	0413-2	GUIDE, TRACK CENTER	
GEAR, SPLITTER BOX	0841-2	(S.N. 006995-)	0138-4
GEAR, ENGINE INTERMEDIATE	0402-4	GUIDE, TRACK CHAIN ADJUSTER/TENSIONER	0134-4
GEARS AND HOUSING, FINAL DRIVE	0201-4	GUIDE, TRACK IDLER WHEEL	0134-2
GEARS, CRANKSHAFT PULLEY AND DAMPENER	0429-4	GUIDES, CYLINDER HEAD VALVES	0409-5A
GEARS, FINAL DRIVE	0201-2		
GLASS WINDOW AND WEATHER STRIP, CAB	1814-10	H	
GLASS, CAB SIDE WINDOW	1813-2	HAND PUMP HYDRAULIC HOSES AND FITTINGS	0360-50
GLOW PLUG/POWER SUPPLY CIRCUIT BREAKER	1671-2	HAND PUMP, HYDRAULIC (COMPONENTS)	0360-54
GLOW PLUG, INSTRUMENT PANEL RELAYS	1676-8	HAND PUMP, HYDRAULIC, GASKET KIT	0360-54
GLOW PLUG, STARTING AID	0505-2	HANDLE (GRAB BAR) (ON LOADER BUCKET LIFT	
GREASE FITTING, ADAPTER, FOR TRACK		ARM FRAME)	3143-2
ADJUSTMENT	2005-2	HANDLE, CAB DOOR LOCKS	1813-6
GREASE FITTING, TRACK CHAIN ADJUSTER/		HANDLE, CAB SLIDING SIDE WINDOW	1814-14
TENSIONER	0134-4	HANDLE, PILOT CONTROLLER	3115-4
GREASE FITTING, TRACK CHAIN ADJUSTER/		HANDLE, PILOT CONTROLLER (COMPONENTS)	3115-6
TENSIONER(S.N. 006734-)	0134-8	HARDWARE, FOOT PEDAL STEERING	
GREASE GUN EXTENSION HOSE	2005-2	POTENTIOMETER	0962-4
GRILLE COVER	1921-2	HARDWARE, FRONT AND REAR CONTROL LEVER	3163-15A
GRILLE GUARD	1921-2	HARDWARE, MAIN FRAME CROSSMEMBER PLATE	1740-6
GRILLE LABEL, REAR, LEAPING DEER	1322-2	HARNES, AIR CONDITIONING CONDENSOR	
GRILLE, AIR CONDITIONER VAPOR CONDENSOR	1833-4	WIRING	1833-2
GRILLE, SOUND INSULATION KIT	1921-4	HARNES, BACK UP ALARM WIRING	
GRILLE, RADIATOR	1921-2	(SERIAL NO. -006199)	2004-2
GROMMET, AIR CONDITIONER HOSE	1833-10	HARNES, BACKUP ALARM WIRING	
GROMMET, CAB ELECTRICAL PANEL MOUNTING	1810-20	(SERIAL NO. 006200-)	2004-4
GROMMET, CAB WIRING HARNESS	1674-22	HARNES, CAB OVERHEAD PANEL (SN -006199)	1674-8
GROMMET, AIR CONDITIONER VAPOR CONDENSER	1833-4	HARNES, CAB OVERHEAD PANEL (SN 006200-)	1674-10
GROUND CABLE, BATTERY	1671-2	HARNES, CAB WIRING, COMPONENTS	1674-22
GROUND CABLE, CAB	1671-2	HARNES, CAB WIRING, CONNECTORS	1674-24
GROUND STRAPS, TRANSMISSION CONTROL UNIT	0375-2	HARNES, CAB WORK LIGHTS (OPTIONAL)	1673-6
GUAGES, HOUR METER, FUEL QUANTITY,		HARNES, CAB WORK LIGHTS WIRING	1673-2
ENGINE COOLANT TEMP AND OIL PRESSURE	1676-4	HARNES, FINAL DRIVE MOTOR WIRING	0360-40
GUARD, AIR CONDITIONER COMPRESSOR	1832-6	HARNES, POTENTIOMETER WIRING	0962-4
GUARD, AIR CONDITIONER VAPOR CONDENSER	1833-4	HARNES, RADIO WIRING	2001-2
GUARD, ALTERNATOR DRIVE BELT W/OUT A/C	0423-4	HARNES, REVERSE TRAVEL ALARM WIRING	
GUARD, BOOM LIFT CYLINDER HOSE		(SERIAL NO. -006199)	2004-2
(SER. NO. 005447-)	3163-10	HARNES, REVERSE TRAVEL ALARM WIRING	
GUARD, BUCKET CYLINDER	3165-10	(SERIAL NO. 006200-)	2004-4
GUARD, CAB SLIDING SIDE WINDOW	1814-14	HARNES, ROPS WORK LIGHTS WIRING	1673-2
GUARD, CAB WINDOW GLASS AND WEATHER		HARNES, STEERING PEDAL WIRING	1674-2
STRIP	1814-10	HARNES, WIRE, AIR CONDITIONING	1675-2
GUARD, ENGINE FAN		HARNES, WIRING, TRANSMISSION CONTROL	
(SERIAL NO. -006199)	0511-2	UNIT	0375-2
GUARD, FAN, SERIES II		HEAD GASKET, ENGINE CYLINDER	0409-4
(SER. NO. 006200-)	0510-9C	HEAD LINER AND DOOR LATCH COVER, CAB	1813-4
GUARD, MULTI-PURPOSE BUCKET BOOM		HEAD, ENGINE CYLINDER	0409-2
CYLINDER	3165-12	HEADER, FUEL FILTER	0420-2
GUARD, REAR BUMPER	1740-14	HEADLIGHTS, CAB	1673-2
GUARD, REAR WINDOW	1810-24	HEADREST	1821-2
GUARD, TRACK	0138-6	HEAT EXCHANGERS AND BLOWERS, HOUSING	
GUARD, WINDOW	1810-24	(HEATER/AIR CONDITIONER)	1830-4
GUARD, WINDSHIELD	1810-24	HEATER AND A/C CONTROLS, CAB	1834-4
GUARD, RADIATOR GRILLE	1921-2	HEATER AND AIR CONDITIONER MOUNTING	
GUARDS, TRACK CHAIN SPROCKET	0133-4	PARTS, CAB	1830-2
GUIDE, CAB SLIDING SIDE WINDOW	1814-14	HEATER; CAB ELECTRICAL CONNECTORS	1674-28
GUIDE, CENTER TRACK		HEATER/AC COMPONENT PARTS	1830-4
(S.N. -006994)	0138-2	HEATER/AIR CONDITIONER VENT DUCTS	1830-8
GUIDE, HYDRAULIC CYLINDER ROD		HEATER, CAB (LOCATION)	1810-4
(RIPPER)	4265-6	HEATER, ENGINE COOLANT	0505-6
GUIDE, MAIN HYDRAULIC PUMP PISTON	2160-4	HEATING ELEMENT, ENGINE COOLANT	0505-6
GUIDE, RETURN TO DIG ADJUSTMENT (BUCKET		HINGE PIN, MULTI-PURPOSE BUCKET	3102-10
POSITION GUIDE) LOADER BUCKET	3143-2	HINGE, ENGINE COMPARTMENT DOOR	1910-2
GUIDE, ROD, BOOM LIFT CYLINDER	3165-2	HINGE, INSTRUMENT PANEL	1816-2
GUIDE, ROD, BUCKET CYLINDER	3165-4		
GUIDE, ROD, MULTI-PURPOSE BUCKET	3165-6		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
PUMP INLET, ENGINE OIL	0407-10	RADIATOR HOSE RETURN TUBE, LOWER (SER. NO. -006199)	0510-2
PUMP MOUNTING, TRANSMISSION HYDROSTATIC (S.N. -006199)	0360-18	RADIATOR HOSE RETURN TUBE, LOWER, SERIES II (SER. NO. 006200-)	0510-3A
PUMP PISTON GUIDE, MAIN HYDRAULIC	2160-4	RADIATOR HOSE, VAPOR CONDENSOR COMPONENT PARTS	1833-6
PUMP PISTONS, MAIN HYDRAULIC	2160-4	RADIATOR HOSES (SERIAL NO. -006199)	0510-4
PUMP POWER DIVIDER	0841-4	RADIATOR HOSES, SERIES II (SER. NO. 006200-)	0510-5A
PUMP PRESSURE SWITCH, (RIGHT) HYDROSTATIC	0360-4	RADIATOR MOUNTING (SERIAL NO. -006199)	0510-8
PUMP SWASH PLATE, MAIN HYDRAULIC	2160-4	RADIATOR MOUNTING ANGLE (SERIAL NO. -006199)	0510-8
PUMP TO PIVOT SHAFT HOSES, HYDROSTATIC	0360-24	RADIATOR MOUNTING BRACKETS SERIES II (SER. NO. 006200-)	0510-9A
PUMP, CHARGE, HYDROSTATIC TRANSMISSION (S.N. 006200-)	0360-20	RADIATOR MOUNTING BRACKETS SERIES II (SER. NO. 006200-)	0510-9C
PUMP, ENGINE OIL	0407-12	RADIATOR MOUNTING ISOLATORS (SERIAL NO. -006199)	0510-8
PUMP, FUEL INJECTION	0413-10	RADIATOR MOUNTING ISOLATORS SERIES II (SER. NO. 006200-)	0510-9A
PUMP, HYDROSTATIC AND TRANSMISSION PUMP, SERIES II (SER. NO. 006200-)	0360-3A	RADIATOR MOUNTING ISOLATORS SERIES II (SER. NO. 006200-)	0510-9C
PUMP, HYDROSTATIC CONTROL BASE MOUNT,	0360-16	RADIATOR MOUNTING WEATHER STRIP (SERIAL NO. -006199)	0510-8
PUMP, HYDROSTATIC SUPPLY HOSES	0360-24	RADIATOR PLATE SERIES II (SER. NO. 006200-)	0510-5A
PUMP, HYDROSTATIC, RETURN HOSES	0360-28	RADIATOR SHROUD, SERIES II (SER. NO. 006200-)	0510-9A
PUMP, MAIN HYDRAULIC	2160-2	RADIATOR SHROUD, SERIES II (SER. NO. 006200-)	0510-9C
PUMP, MAIN HYDRAULIC BEARING KIT	2160-4	RADIATOR TOP TANK (SERIAL NO. -006199)	0510-6
PUMP, TRANSMISSION CHARGE, (LEFT) AND HYDROSTATIC PUMP (SER. NO. -006199)	0360-2	RADIATOR TOP TANK (SERIAL NO. 006200-)	0510-7A
PUMP, TRANSMISSION CHARGE, (LEFT) AND HYD PUMP, SERIES II (SER. NO. 006200-)	0360-3A	RADIO	2001-2
PUMP, WINDSHIELD WASHER	1814-12	RADIO ANTENNA	2001-2
PUMP, (LEFT) HYDROSTATIC AND TRANSMISSION CHARGE PUMP (SER. NO. -006199)	0360-2	RADIO MOUNTING BRACKET	2001-2
PUMP, (RIGHT) HYDROSTATIC AND HYDRAULIC VARIABLE FLOW PUMP	0360-4	RADIO SPEAKER	2001-2
PUMP, WATER ASSEMBLY	0417-2	RADIO SPEAKERS	1674-22
PUSH ROD, ENGINE	0402-2	RADIO TRANSFORMER	2001-2
		RADIO WIRING HARNESS	2001-2
R		RAIL, CAB SLIDING SIDE WINDOW	1814-14
RADIATOR (SERIAL NO. -006199)	0510-6	REAR AUXILIARY HYDRAULIC WORK PORT HOSES	3163-16
RADIATOR (SERIAL NO. -006199)	0510-8	REAR AUXILIARY HYDRAULIC WORK PORT HOSES	4263-8
RADIATOR (SERIAL NO. 006200-)	0510-7A	REAR AUXILIARY VALVE CONNECTIONS	3163-16
RADIATOR BOTTOM COVER (SERIAL NO. -006199)	0510-6	REAR AUXILIARY VALVE CONNECTIONS	4263-8
RADIATOR BRACKETS (SERIAL NO. 006200-)	0510-7A	REAR BUMPER	1740-14
RADIATOR CAP DECAL	1322-2	REAR BUMPER	1749-2
RADIATOR COOLANT LEVEL SIGHT GAUGE SERIES II (SER. NO. 006200-)	0510-9A	REAR COUNTERWEIGHT PLATE	1749-2
RADIATOR COOLANT LEVEL SIGHT GAUGE SERIES II (SER. NO. 006200-)	0510-9C	REAR COUNTERWEIGHT SLEEVE	1749-2
RADIATOR COVER	1921-2	REAR COUNTERWEIGHT RETAINER	1749-2
RADIATOR FAN DRIVE MOTOR SERIES II (SER. NO. 006200-)	0510-9C	REAR GRILLE LABEL, LEAPING DEERE	1322-2
RADIATOR FAN GUARD (SERIAL NO. -006199)	0511-2	REAR LIMB RISERS AND COMPONENT PARTS	1810-22
RADIATOR FAN GUARD SERIES II (SER. NO. 006200-)	0510-9C	REAR MOUNTING LINK AND LIFT CYLINDER, PLATFORM	1812-10
RADIATOR FAN SHROUD (SERIAL NO. -006199)	0510-8	REAR PILOT CONTROLLER COMPONENTS	4263-12
RADIATOR FILLER CAP (SERIAL NO. -006199)	0510-6	REAR STEP	1921-2
RADIATOR FILLER CAP (SERIAL NO. 006200-)	0510-7A	REAR SUPPORT	1740-14
RADIATOR FRAME PANELS (SERIAL NO. -006199)	0510-6	REAR VIEW MIRROR	1810-6
RADIATOR GRILLE AND GRILLE COVER	1921-2	REAR VIEW MIRROR BRACKET	1810-6
RADIATOR GRILLE GUARD	1921-2	REAR WINDOW GUARD	1810-24
		REAR WINDOW SCREEN PROTECTION	1810-24
		REAR WINDOW WIPER COVER	1810-8
		REAR WINDOW WIPER, CAB (LOCATION)	1810-8
		REAR WINDSHIELD WIPER (COMPONENT PARTS)	1814-4

0130-1

WHEELS & TIRES & TRACKS 01

TRACK SYSTEMS 0130

MEMORANDA

0133-3

WHEELS & TIRES & TRACKS 01

ROLLERS 0133

TRACK CHAIN IDLER WEAR STRIPS AND IDLER SHAFT BEARING CAPS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	19M7889	CAP SCREW	4		M24 X 80, (SUB FOR AT274270, THIS APPLICATION)
2	AT275259	BEARING CAP	2		
3	AT275242	STRIP	2		
4	AT276367	STRIP	2		

0134-5

WHEELS & TIRES & TRACKS 01

RECOIL SYSTEM (IDLER & IDLER SPRING) 0134
TRACK ADJUSTER (COMPONENTS)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT276629	YOKE	1		
2	19M7409	CAP SCREW	4		M16 X 50
3	T116461	WASHER	4		(SUB FOR 24M7280)
4	AT300387	FLANGE	2		
5	19M7489	CAP SCREW	4		M16 X 45, (SUB FOR AT250289)
6	T116461	WASHER	4		(SUB FOR 24M7280)
7	AT276318	ADJUSTER	1	-006733	(TRACK CHAIN ADJUSTER/TENSIONER SPRING COMPLETE ASSEMBLY ONLY)(COMPONENTS ON SEPARATE PAGE)
	AT304619	ADJUSTER	1	006734-	(TRACK CHAIN ADJUSTER/TENSIONER SPRING COMPLETE ASSEMBLY ONLY) (COMPONENTS ON SEPARATE PAGE)
8	AT276577	GUIDE	2		
9	19M7946	CAP SCREW	4		M20 X 40
10	24M7396	WASHER	4		21 X 34 X 3 MM
11	AT276578	STOP	1	-005709	
	AT300500	STOP	1	005710-	
12	AT276579	STOP	1	-005709	
	AT300501	STOP	1	005710-	
13	19M7892	CAP SCREW	2	-005709	M20 X 80
	19M8722	CAP SCREW	2	005710-	M20 X 70
14	24M7396	WASHER	4		21 X 34 X 3 MM
15	19M7946	CAP SCREW	2		M20 X 40
16	AT301558	FITTING	1		(SUB FOR AT274768) (GREASE FITTING)
17	AT274332	SEAL	1		
18	19M7409	CAP SCREW	2	005710-	M16 X 50
19	AT300386	SUPPORT	1	005710-	

0138-5

WHEELS & TIRES & TRACKS 01

ROCK GUARDS & TRACK GUIDES 0138

CENTER TRACK GUIDES (S.N. 006995-)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT320085	GUIDE	1		
2	AT275224	BUSHING	6		
3	19M7759	CAP SCREW	6		

0260-3

AXLES, DIFFERENTIALS & SUSPENSION SYSTEMS 02

AXLES, DIFF. & SUSP. SYS. HYD 0260

PIVOT SHAFT AND COMPONENT PARTS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT276371	NUT	1		
2	AT276368	FLANGE	1		
3	SHAFT	1		(PIVOT)
4	AT276029	KEY	1		
5	AT274181	KEY	1		
6	AT276374	FLANGE	1		
7	AT276190	O-RING	2		
8	AT276518	BEARING	1		
9	AT276520	SPACER	1		
10	AT276517	BEARING	1		
11	AT276386	SPACER	1		
12	AT276178	O-RING	1		
13	AT276387	RING	1		
14	AT276372	NUT	1		
15	AT274806	PIN FASTENER	1		
16	AT276514	SHAFT	1		(COMPLETE) (PIVOT)
17	AT276519	SHAFT	1		PIVOT (COMPLETE)
18	19M7889	CAP SCREW	16		M24 X 80
19	AT275997	WASHER	16		
20	19M8224	CAP SCREW	6		M20 X 60
21	24M7396	WASHER	6		21 X 34 X 3 MM
22	AT276244	O-RING	1		

0360-3B

TRANSMISSION 03

LEFT HYDROSTATIC PUMP WITH TRANSMISSION CHARGE PUMP, SERIES II (SERIAL NO. 006200-)

TRANSMISSION HYDRAULICS 0360

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT266126	HYDRAULIC PUMP	1		
2	AT275262	WASHER	4		
3	AT250332	FITTING PLUG	1		
4	AT276363	ADAPTER FITTING	1		
5	AT274772	FLANGE	1		
6	AT274772	FLANGE	1		(INCLUDES AT320754, (4) 24M7055, (2) AT274141 AND (2) 19M8658)
7	AT274831	ELBOW FITTING	1		
8	AT276361	COUPLING	1		
9	AT276183	FITTING	1		
10	AT218901	REDUCER	1		
11	AT218623	FITTING	1		
12	AT218871	ELBOW FITTING	1		
13	AT275652	LINK	2		
14	19M9233	SCREW	2		M10 X 40
15	AT276187	COUPLING	1		
16	AT274812	FITTING	1		(INCLUDES AT250327, (2) 19M7603, (2) 19M8265 AND (4) 24M7088)
17	AT265376	FITTING	1		(INCLUDES AT250338, (2) AT274207, (2) AT266572 AND (4) 24M7088)
18	AT320754	O-RING	1		(FURNISH AT274538)
19	24M7055	WASHER	2		8.400 X 16 X 1.600 MM
20	AT274141	SOCKET HEAD SCREW	1		
21	19M8658	SCREW	1		M8 X 60
22	AT218875	TEE FITTING	1	-007671	
23	AT218902	UNION FITTING	1	-007671	
24	AT218871	ELBOW FITTING	1	-007671	
25	AT274522	FITTING	1		
26	14M7276	NUT	4		
27	AT266080	HYDRAULIC HOSE - FABRICATE	1		
28	AT266081	ADAPTER FITTING	1		
29	AT265713	ELBOW FITTING	1		
30	AT275694	PRESSURE SWITCH	1		

0360-15

TRANSMISSION 03

TRANSMISSION HYDRAULICS 0360

HYDROSTATIC DRIVE PUMP TOP COVER CONTROLS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	COVER	1	-006199	(SUB FOR AT266149) (SERVICE WITH ASSEMBLY AT318311) (PROPORTIONAL SOLENOID)
	COVER	1	006200-	(SUB FOR AT266147) (SERVICE WITH ASSEMBLY AT266147) (PROPORTIONAL SOLENOID)
2	AT266042	PISTON	1		
3	AT277214	SEAT	1		
	AT277259	SEAT	1		
4	AT266043	SPRING	2		
5	AT266044	SPRING	2		
6	AT274540	O-RING	2		
7	AT266211	ADAPTER FITTING	2		
8	AT277152	NUT	2		
9	AT266046	SCREW	2		
10	AT218834	NUT	2		
11	AT308661	LEVER	1	-006199	
	AT266150	BRACKET	1	006200-	
	AT266048	PIN	1	006200-	
13	AT274539	O-RING	1		
14	14M7158	NUT	1		M16, (SUB FOR AT274094)
16	AT250332	FITTING PLUG	1		
17	AT265114	PLUG	2		
18	AT275977	SEAL	1		
19	19M7300	CAP SCREW	1		M6 X 10
20	AT266205	PLUG	2		
21	AT276136	SEAL	1		
22	AT266206	PLUG	1		
23	AT276294	VALVE	2		
24	AT274541	O-RING	2		
25	AT274930	SOLENOID	2		
26	AT274196	SOCKET HEAD SCREW	8		
27	AT274047	SPRING PIN	2		
28	AT266207	PIN	2		
29	AT266208	SNAP RING	2		
30	24M7055	WASHER	2		
31	14M7273	NUT	2		
33	AT266209	PLUG	2		
34	AT277042	PISTON	1		
35	AT266039	SPRING	1		
36	AT277215	SCREW	2		
37	AT266038	HOUSING	1		
38	AT266148	GASKET	1		
39	AT266034	O-RING	1		
40	AT316502	WASHER	1	-006199	(SUB FOR AT277188)
	AT316501	WASHER	1	006200-	(SUB FOR AT277188)
41	19M9240	SCREW	6		M10 X 50, (SUB FOR AT266035)
42	19M8881	SCREW	4		M10 X 30, (SUB FOR AT274252)
50	AT266147	COVER	1		

0360-25

TRANSMISSION 03

TRANSMISSION HYDRAULICS 0360

DRIVE PUMP HYDRAULIC SUPPLY HOSES

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT276045	SCREW	4		
2	AT276043	SCREW	4		
3	AT276534	FLANGE	1		
4	AT218852	O-RING	4		
5	AT326441	FLANGE	8		(SUB FOR AT218518)
6	19M8423	CAP SCREW	16		M14 X 45
7	AT276334	HYDRAULIC HOSE - FABRICATE	2		
8	19M7493	CAP SCREW	16		M12 X 40
9	LW10286360	FLANGE	4		(SUB FOR AT218503, THIS APPLICATION)
10	AT218851	O-RING	4		
11	AT276323	HYDRAULIC HOSE	1		(NOT FABRICATED BY PARKER)
12	AT275054	HYDRAULIC HOSE - FABRICATE	1		
13	AT276533	FLANGE	1		
14	AT276324	HYDRAULIC HOSE - FABRICATE	1		

0360-37

TRANSMISSION 03

TRANSMISSION HYDRAULICS 0360

HYDROSTATIC DRIVE MOTOR (COMPONENT PARTS)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT276198	O-RING	1		
4	AT276287	HYD ACTUATED CONTROL VALVE	1		(DRIVE MOTOR REMOTE CONTROL VALVE) (COMPONENTS ON ANOTHER PAGE)
5	AT274541	O-RING	1		
6	AT276298	SOLENOID	1		(PROPORTIONAL SOLENOID)
6A	AT265629	SPRING	1		(INCLUDED W/ AT276298) 1.5 X 28 X 93 MM
	AT265630	SPRING	1		1.5 X 28 X 92.7 MM
	AT265631	SPRING	1		1.5 X 28 X 92.4 MM
	AT265632	SPRING	1		1.5 X 28 X 92 MM
7	AT274196	SOCKET HEAD SCREW	4		
8	AT303369	TUBE	1		
9	AT276256	RING	1		
10	AT303304	COMPRESSION SPRING	1		
11	AT303303	CYLINDER BLOCK	1		
12	AT276273	SNAP RING	2		
13	AT276031	SHIM	1		18 X 25 X 0.1 MM
	AT276044	SHIM	1		18 X 25 X 0.3 MM
14	AT276272	DRIVE SHAFT	1		(COMPONENTS ON FOLLOWING PAGE)
15	COUPLING	1		(AT274922 NOT SERVICED)
16	AT274539	O-RING	1		
17	AT274355	SENSOR	1		(SPEED SENSOR)
18	AT274563	SEAL	4		
19	AT276186	SEAL	1		
20	AT265362	O-RING	1		
21	AT276271	O-RING	1		(SUB FOR AT274914)
22	AT277260	BUSHING	1		
23	AT300377	SWASH PLATE	1		
24	AT276277	O-RING	4		(SUB FOR AT250414)
25	AT321542	HYDRAULIC MOTOR	1		(SUB FOR AT315083)
26	AT276285	PACKING	1		(SEAL KIT)
28	AT276248	SCREW	6		
29	AT265662	SCREW	8		
30	AT303283	COVER	1		
31	AT250332	FITTING PLUG	1		
32	AT277232	PLUG	2		
33	AT276848	PIN	1		
34	AT277037	PIN	1		
35	AT300378	FINGER	1		
36	AT300379	PISTON	1		
37	AT300380	SET SCREW	1		
38	AT300381	SOCKET HEAD SCREW	8		
39	AT265674	COVER	1		
40	AT277039	PIPE PLUG	1		
41	19M7496	CAP SCREW	1		M12 X 45, (SUB FOR 19M7303)
42	AT265371	LOCK NUT	1		
43	AT277215	SCREW	4		
44	AT218834	NUT	1		
45	AT320728	O-RING	1		

0360-53

TRANSMISSION 03

TRANSMISSION HYDRAULICS 0360

HYDRAULIC CONTROL MANIFOLDS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT218872	TEE FITTING	1		
2	AT274796	ELBOW FITTING	1		
3	24M7055	WASHER	7		8.400 X 16 X 1.600 MM
4	19M8504	CAP SCREW	3		M8 X 80
5	MANIFOLD	1		HYDRAULIC, CONTROL, (COMPONENTS ON ANOTHER PAGE)
6	19M7663	CAP SCREW	2		M8 X 70
7	19M8183	CAP SCREW	4		M10 X 90
8	MANIFOLD	1		HYDRAULIC, COLD START UNIT, (COMPONENTS ON ANOTHER PAGE)
9	AT276293	HYDRAULIC HOSE	1		
10	AT274811	CLAMP	2		
11	19M7374	CAP SCREW	2		M6 X 40
12	AT274801	COVER	1		
13	19M8008	CAP SCREW	1		M8 X 35
14	LW7362606	COVER	1		(SUB FOR AT274800)
15	AT275002	CLAMP	2		
16	AT274182	FITTING	1		
17	AT274680	COUPLING	1		
18	AT274299	FITTING	1		
19	AT274234	NUT	1		
20	AT274681	UNION FITTING	4		
21	AT274336	FITTING	4		
22	R44302	TIE BAND	15		(SUB FOR AT274490)
23	HYDRAULIC ACCUMULATOR	1		(COMPONENTS ON ANOTHER PAGE)

0375-3

TRANSMISSION 03

AUTOMATIC CONTROL CIRCUITS 0375

TRANSMISSION CONTROL UNIT

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT196781	TRANSMISSION CONTROLLER	1	-006199	
	AT266104	CENTRAL CONTROL UNIT	1	006200-	
2	AT264750	GROUND CABLE	3		
3	AT274981	ISOLATOR	3		
4	14M7272	NUT	6		M6
5	24M7088	WASHER	6		6.600 X 12 X 1.600 MM
6	AT276505	WIRING HARNESS	1	-006199	(VEHICLE MAIN WIRING HARNESS)
	AT266186	WIRING HARNESS	1	006200-	(VEHICLE MAIN WIRING HARNESS)
7	AT318442	ELEC. CONNECTOR CAVITY PLUG	1		

0402-7

ENGINE 04

CAMSHAFT AND VALVE ACTUATING MEANS 0402 ENGINE FRONT COVER,COVER GASKET AND ENGINE OIL FILLER NECK

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT274491	HAND OPERATED VALVE	1		
2	AT274733	O-RING	1		
3	AT275438	GASKET	1		
4	AT275352	SPACER	1		
5	AT274029	SOCKET HEAD SCREW	1		
6	19M7604	SCREW	1		M8 X 80
7	AT274719	PIPE PLUG	1		
8	AT314883	SELF-LOCKING SCREW	1		
9	AT218824	SEALING WASHER	1		
10	19M7561	SCREW	1		M8 X 30
11	AT274135	SOCKET HEAD SCREW	2		
12	AT274261	SOCKET HEAD SCREW	12		
13	AT276703	COVER	1	-006199	
	AT265356	COVER	1	006200-	
14	AT275911	FITTING	1		
15	AT274285	SEAL	1		
16	AT275440	BOLT	1		
17	AT274045	SCREW	1		
18	AT275311	BUSHING	2		
20	AT275315	GASKET	1		
21	AT275313	COVER	1		
22	AT276403	FILLER NECK	1		
23	AT275447	GASKET	1		
24	12M5442	WASHER	2		8.400 X 15 X 0.800 MM
25	19M7407	CAP SCREW	2		M8 X 25
26	AT276081	O-RING	1		
27	AT276402	COVER	1		
28	12M5442	WASHER	2		8.400 X 15 X 0.800 MM
29	19M7881	SCREW	2		M8 X 20, (SUB FOR 19M7139)
30	AT277832	LINE	1		
31	AT218825	SEALING WASHER	1		
32	AT274534	PIPE PLUG	1		

0407-3

ENGINE 04

ENGINE OILING SYSTEM 0407

ENGINE OIL PAN,DIPSTICK AND DIPSTICK TUBE AND DRAIN VALVE

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT276432	OIL PAN	1		
	AT275303	KIT	3		
3	AT276417	GASKET	1		
4	R104558	O-RING	1		(SUB FOR AT218828)
5	AT218659	SEALING WASHER	1		
6	AT218722	CAP	1		
7	AT274692	O-RING	1		
	AT320748	O-RING	1	007092-	
8	19M7513	CAP SCREW	34		M8 X 30
9	12M5442	WASHER	34		8.400 X 15 X 0.800 MM
10	AT276418	DIPSTICK	1	-007091	
	AT320257	DIPSTICK	1	007092-	
11	AT218506	DRAIN VALVE	1		
12	AT218825	SEALING WASHER	1		
13	AT275373	DIPSTICK TUBE	1		
14	AT218623	FITTING	1		
15	AT260902	RING	1		

0408-3

ENGINE 04

VENTILATING SYSTEM 0408

CRANKCASE BREATHER,BREATHER PIPE AND HOSE

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT218492	HOSE CLAMP	2		
2	AT275892	HOSE	1		
3	AT275430	BREATHER	1		
4	AT274707	O-RING	1		
5	AT274595	CAP	1		
6	AT218492	HOSE CLAMP	2		
7	AT275431	HOSE	1		
8	AT275920	LINE	1		
9	19M7407	CAP SCREW	1		M8 X 25
10	24M7055	WASHER	1		8.400 X 16 X 1.600 MM
11	AT274717	CLAMP	1		
12	24H1621	WASHER	1		11/32" X 1" X 0.220"

0410-3

ENGINE 04

EXHAUST MANIFOLD 0410

EXHAUST MANIFOLD AND GASKET

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT279805	EXHAUST MANIFOLD	2		END SECTION
2	AT279806	GASKET	4		
3	AT279804	EXHAUST MANIFOLD	1		MIDDLE SECTION
4	AT279803	CAP SCREW	24		
5	24M7055	WASHER	24		8.400 X 16 X 1.600 MM
6	AT275418	GASKET	6		

0413-11

ENGINE 04

FUEL INJECTION SYSTEM 0413 FUEL INJECTION PUMP, SHUT-OFF SOLENOID AND FUEL TRANSFER PUMP

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT279915	O-RING	1		(SUB FOR AT276153)
2	AT276161	SHAFT KEY	1		
3	AT277723	GEAR	1		
4	AT304316	LOCK WASHER	1		
5	AT304317	NUT	1		
6	AT276399	WASHER	4		
7	19M7382	CAP SCREW	4		M10 X 40
8	AT274597	SEAL	2		
9	AT279909	FUEL LINE	1		
10	AT276046	BOLT	1		
11	AT274557	CLIP	1		
12	AT198032	PUMP	1		TRANSFER. (SUB FOR AT276096)
13	AT276194	GASKET	1		(TRANSFER PUMP)
14	AT302201	SPACER	2		
15	AT279936	FUEL INJECTION PUMP	1	-006199	
	AT301911	FUEL INJECTION PUMP	1	006200-	
16	AT276080	FLOW CONTROL HYD. VALVE	1		
17	LW10116837	KIT	1		(FUEL SHUT OFF SOLENOID) (SUB FOR AT263615)
	AT265696	WIRING HARNESS	1		(NOT ILLUSTRATED) (FUEL SHUTOFF SOLENOID HARNESS)
					(AT302205 NLA)
18	BOLT	2		
19	AT276444	FITTING	1	006200-	
20	AT274247	SEAL	2	006200-	
21	AT302202	STOP	1		
22	AT302206	NUT	1		
23	LW6001661	STARTING AID SOLENOID	1		
24	LW10117294	KIT	1		

0416-3

ENGINE 04

TURBOCHARGER 0416

ENGINE TURBOCHARGER AND OIL LINES

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT260902	RING	2		
2	AT218623	FITTING	2		(SUB FOR AT275975)
3	AT276442	OIL LINE	1	-006199	
	AT301905	OIL LINE	1	006200-	
4	19M8708	SCREW	2		M8 X 18
5	AT275353	FLANGE	1		
6	AT275385	GASKET	1		
7	AT276099	TURBOCHARGER	1	-006199	
	AT301904	TURBOCHARGER	1	006200-	
8	12M5442	WASHER	2		8.400 X 15 X 0.800 MM
9	19M7407	CAP SCREW	2		M8 X 25
10	AT276441	OIL LINE	1		
11	AT274237	HOSE CLAMP	2		
12	AT275433	HOSE	1		
13	AT275306	FITTING	1		
14	AT274600	SEAL	1		
15	AT275386	GASKET	1		
16	AT276196	SCREW	4	-006199	
	AT314123	SCREW	4	006200-	
	AT314124	WASHER	4	006200-	(NOT ILLUSTRATED)
17	AT276434	GASKET	1		

0418-7

ENGINE 04

THERMOSTATS, HOUSING & WATER PIPING 0418
ENGINE COOLANT OUTLET COVER

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT311904	COVER	1		(SUB FOR AT274037)
2	AT275447	GASKET	1		
3	19M7407	CAP SCREW	2		M8 X 25
4	12M5442	WASHER	2		8.400 X 15 X 0.800 MM

0420-7

ENGINE 04
FUEL FILTER 0420

FUEL FILTER FUEL LINES SERIES II (SERIAL NO.006200-)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
2	AT308944	FUEL LINE	1		(SUB FOR AT279906)
3	AT301976	FUEL LINE	1		(SUB FOR AT279907)
6	AT266629	FITTING	6		
7	AT218623	FITTING	2		(SUB FOR AT275975)
8	AT274247	SEAL	2		
12	AT265105	PLUG	5		

0423-5

ENGINE 04

ALTERNATOR & GENERATOR MOUNTING 0423
ALTERNATOR DRIVE BELT GUARD

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT263587	GUARD	1		
2	AT263588	ISOLATOR	8		
3	AT263589	SPACER	4		
4	AT263590	WASHER	4		
5	19M7169	CAP SCREW	4		M10 X 35

0452-3

ENGINE 04

ENGINE GASKET AND SEAL KIT

GASKET/SEAL REPLACEMENT KITS 0452

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT275438	GASKET	1		
5	AT279912	GASKET	2		
6	AT279913	GASKET	1		
7	AT274733	O-RING	1		
11	AT275351	O-RING	1		
12	AT274706	O-RING	1		
13	AT279914	O-RING	1		
14	AT274702	O-RING	1		
16	AT279915	O-RING	1		(SUB FOR AT276153)
18	AT279915	O-RING	1		
20	AT279916	O-RING	1		
26	AT265625	O-RING	1		
29	AT218824	SEALING WASHER	1		
30	AT275339	COVER	1		(INCLUDES AT274546 AND AT265311)
	AT274546	SEAL	1		(NOT ILLUSTRATED)
	AT265311	RETAINER	1		(NOT ILLUSTRATED)
31	AT275349	O-RING	1		
34	AT279918	O-RING	1		
36	AT277733	O-RING	1		
38	AT279919	O-RING	1		
40	AT276081	O-RING	1		
42	AT274707	O-RING	1		
44	AT279920	GASKET	1		
45	AT276417	GASKET	1		
46	AT275377	GASKET	1		
47	AT218825	SEALING WASHER	3		
48	AT279895	SEAL KIT	1		

0510-3

ENGINE AUXILIARY SYSTEM 05

ENGINE COOLING SYSTEMS 0510

LOWER RADIATOR HOSE RETURN TUBE (SERIAL NO. -006199)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	19M9233	SCREW	2		
2	AT218846	FITTING PLUG	1		
3	AT275601	TUBE	1		
4	24M7055	WASHER	2		8.400 X 16 X 1.600 MM
5	19M7938	CAP SCREW	2		M10 X 20
6	AT274286	GASKET	1		
7	AT274247	SEAL	2		
8	AT274953	FUEL SUPPLY BANJO FITTING	1		
9	AT274024	HOLLOW SCREW	1		

0510-7B

ENGINE AUXILIARY SYSTEM 05

ENGINE COOLING SYSTEMS 0510

RADIATOR, TOP TANK, AIR COOLER AND HYDRAULIC OIL COOLER (SERIAL NO. 006200-)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT266173	TANK	1		
2	AT266174	BRACKET	2		
3	AT266175	BRACKET	1		
4	LW10337418	HEAT SINK	1		(SUB FOR AT266176)
5	AT266177	RADIATOR	1		
6	AT266178	OIL COOLER	1		
7	19M7407	CAP SCREW	8		
8	24M7055	WASHER	16		
9	14M7273	NUT	4		
10	AT265169	ISOLATOR	2		
11	AT322829	ISOLATOR	2		
12	AT277179	CLIP	1		
13	AT266167	HOSE	AR		(CUT TO LENGTH 1.64M)
14	AH77724	CLIP	3		
15	AT274267	SOCKET HEAD SCREW	3		
16	AT309038	FILLER CAP	1		(TOP MOUNTED)
17	AT309039	FILLER CAP	1		(SIDE HOSE MOUNT)

0512-3

ENGINE AUXILIARY SYSTEM 05

FAN 0512

ENGINE COOLING FAN (SERIAL NO. -006199)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT276461	FAN	1		
2	14M7273	NUT	6		M8
3	24M7055	WASHER	6		8.400 X 16 X 1.600 MM

0521-5

ENGINE AUXILIARY SYSTEM 05

AIR CLEANER & PIPING 0521

AIR FILTER PIPES AND HOSES, SERIES II (SERIAL NO. 006200-)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT266121	LINE	1		
2	AT274042	STUD	2		
3	19M7383	CAP SCREW	1		(SUB FOR AT274009, THIS APPLICATION)
4	14M7274	NUT	3		M10
5	AT266122	HOSE	2		
6	AT266123	HOSE CLAMP	4		
7	AT276440	GASKET	1		
8	24M7028	WASHER	4		10.500 X 20 X 2 MM
10	AT266124	LINE	1		

0563-7

ENGINE AUXILIARY SYSTEM 05

FUEL TANK TO WATER SEPARATOR FUEL HOSES (SERIAL NO. 006824-

FUEL LINES & FITTINGS 0563
)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT316582	HOSE	1		(SUB FOR AT266190)
5	AT266191	HYDRAULIC HOSE	1		
10	AT274821	CLAMP	16		
11	LW7362606	COVER	8		(SUB FOR AT274800, THIS APPLICATION)
12	19M8008	CAP SCREW	8		M8 X 35

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

0869-3

TRANSFER DRIVE 08

GEAR FLUID 0869

SPLITTER OIL FILL TUBE, CAP AND DIPSTICK

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT275239	TUBE	1		
2	AT261739	TUBE NUT	1		
3	AT274233	FERRULE	1		
4	AT218623	FITTING	1		
5	AT276460	TUBE	1	-007368	(FURNISH AT322832)
	AT322832	DIPSTICK TUBE	1	007369-	
6	AT276426	DIPSTICK	1	-007368	(FURNISH AT322833)
	AT274692	O-RING	1	-007368	(FURNISH AT320748)
	AT322833	DIPSTICK	1	007369-	
	AT320748	O-RING	1	007369-	
7	AT274522	FITTING	1		
8	AT275238	UNION FITTING	1		
9	AT274318	HOSE CLAMP	2		
10	AT274762	HOSE	1		(CUT TO LENGTH 0.550M FROM 0.640M ROLL)
11	AT275679	FILLER NECK	1		
12	24M7055	WASHER	2		8.400 X 16 X 1.600 MM
13	14M7273	NUT	1		M8
14	AT274764	CAP	1		
15	AT261793	CLAMP	1		
16	19M7881	SCREW	1		M8 X 20

1011-3

SERVICE BRAKES 10

SERVICE BRAKES ACTIVE ELEMENTS 1011

BRAKE PEDAL ASSEMBLY

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT275157	NEEDLE BEARING	2		BEARING
2	AT275814	SPRING	1		
3	AT275813	SPRING	1		
4	AT274226	SPRING PIN	1		
5	AT275812	PIN FASTENER	1		
6	AT275810	PEDAL	1		
7	AT275818	STOP	1		
8	AT274012	NUT	1		M20 X 1.5
9	AT274165	SOCKET HEAD SCREW	2		M4 X 12
10	21M7216	SCREW	2		M4 X 20
11	AT275500	ROD	1		
12	24M7117	WASHER	2		4.300 X 9 X 0.800 MM
13	AT275820	PLATE	1		
14	14M7275	NUT	1		M12
15	AT275528	BOLT	1		M12 X 25
16	AT302644	SPRING	1		(SUB FOR AT275817)
17	AT275816	PIN	1		
18	AT275815	SLEEVE	1		

1333-5

MISCELLANEOUS VEHICLE 13

REPLACEMENT PARTS PACKAGING 1333

O-RING SERVICE KIT

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	LW10290520	O-RING	5		(SUB FOR AT274678)
2	AT218851	O-RING	5		
3	AT276177	O-RING	5		
4	AT274624	O-RING	5		(SUB FOR AT250419)
5	AT218852	O-RING	5		
6	AT280447	O-RING KIT	1		(SUB FOR AT276366)

1672-5

VEHICLE ELECTRICAL SYSTEMS 16

ALTERNATOR, REGULATOR & CHARGING SYSTEM WIRING 1672
ALTERNATOR AND PULLEY (SERIAL NO. 005763-)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT274384	ALTERNATOR	1		(24-VOLT) (55 AMP) (INCLUDES AT279847 AND 24M7053)
	AT266538	ALTERNATOR	1		(24 VOLT) (80 AMP) (INCLUDES AT279847 AND 24M7053)
2	AT265358	FAN	1		
4	AT265308	PULLEY	1		
5	AT279847	NUT	1		
6	24M7053	WASHER	1		17 X 30 X 3 MM

1674-11

VEHICLE ELECTRICAL SYSTEMS 16

WIRING HARNESS & SWITCHES 1674

ELECTRICAL SYSTEM CAB OVERHEAD PANEL WIRING HARNESS (SERIAL NO. 006200-)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT275870	PANEL	1		
2	WIRING HARNESS	1	-008068	(AT266192 NLA) (ORDER LW9413877)
	LW9413877	WIRING HARNESS	1	008069-	
3	AT275680	LABEL	1		
4	AT275552	WIRING LEAD	1		
5	AT274187	SCREW	1		
6	19M7008	CAP SCREW	1		
7	CONSOLE	1	-008068	(AT266116 NLA) (ORDER LW9413930)
	LW9413930	BRACKET	1	008069-	(COMPLETE)
10	AT322276	RELAY	1		(SUB FOR AT274418)
12	AT274439	RELAY	4		
14	AT274420	DIODE	1		(COMBINATION)
15	AT265617	SOCKET	1		
17	21M7278	SCREW	5		
22	AT274256	SCREW	4		
23	14M7166	LOCK NUT	4		M8, (SUB FOR AT265058)
24	24M7055	WASHER	8		8.400 X 16 X 1.600 MM
25	AT274224	SCREW	4		
26	AT274993	WASHER	4		

1674-23

VEHICLE ELECTRICAL SYSTEMS 16
WIRING HARNESS & SWITCHES 1674

CAB WIRING HARNESS (COMPONENTS)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	19M7373	CAP SCREW	2		M5 X 20, (SUB FOR AT218425)
2	24M7027	WASHER	2		5.300 X 10 X 1 MM
3	AT274765	BUSHING	1		
4	AT274437	LAMP	1	-006199	
5A	AT274436	BULB	1	-006199	
5B	AT265623	LAMP	1	006200-	
6	AT274438	GROMMET	6		
7	AT274333	GROMMET	7		
8	AT274225	SCREW	8		
9	AT300930	COVER	2		SPEAKER, (SUB FOR AT218568, THIS APPLICATION)
10	AT274483	BUSHING	5		
11	AT261791	CLAMP	2		
12	19M8425	CAP SCREW	2		M6 X 16
20	AT265614	COVER	1		
21	LW9403726	LABEL	1		(SUB FOR AT265613)
30	AT265622	CONVERTER	1		
31	AT274165	SOCKET HEAD SCREW	2		
32	24M7117	WASHER	2		4.300 X 9 X 0.800 MM

1674-33

VEHICLE ELECTRICAL SYSTEMS 16

WIRING HARNESS & SWITCHES 1674

TRAVEL MOTOR, SUPPORT SHAFT, AND DIESEL ENGINE RPM SENSOR ELECTRICAL CONNECTORS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	57M8679	ELEC. CONNECTOR HOUSING	1		8 WAY RCPT, PIN CONTACTS (TRAVEL MOTOR)
2	57M7541	ELEC. CONNECTOR TERMINAL	1		SOLID TERM M,14-16 GA.
3	57M7680	ELEC. CONNECTOR TERMINAL	1		RECPT. LOCKING WEDGE, 8 PIN
4	57M8746	ELEC. CONNECTOR HOUSING	1		8WAY PLUG (TRAVEL MOTOR)
5	57M7542	ELEC. CONNECTOR TERMINAL	1		
6	57M7679	ELEC. CONNECTOR TERMINAL	1		LOCKING WEDGE, 8 SOCKET
7	57M9024	ELEC. CONNECTOR SEAL	1		8WAY INTERFACIAL SEAL (NOT ILLUSTRATED)
8	57M8679	ELEC. CONNECTOR HOUSING	1		8 WAY RCPT, PIN CONTACTS (TRAVEL MOTOR/SUPPORT SHAFT)
9	57M7541	ELEC. CONNECTOR TERMINAL	1		SOLID TERM M,14-16 GA.
10	57M7680	ELEC. CONNECTOR TERMINAL	1		RECPT. LOCKING WEDGE, 8 PIN (NOT ILLUSTRATED)
11	57M8680	ELEC. CONNECTOR HOUSING	1		8 WAY PLUG, SOC CONTACTS (TRAVEL MOTOR/SUPPORT SHAFT)
12	57M7542	ELEC. CONNECTOR TERMINAL	1		
13	57M7679	ELEC. CONNECTOR TERMINAL	1		PLUG LOCKING WEDGE, 8 SOCKE (NOT ILLUSTRATED)
14	57M9024	ELEC. CONNECTOR SEAL	1		8WAY INTERFACIAL SEAL (NOT ILLUSTRATED)
15	57M8671	ELEC. CONNECTOR HOUSING	1		3 WAY HOUSING, SOCKET CONTACT (TRAVEL MOTOR SENSOR)
16	57M9017	ELEC. CONNECTOR TERMINAL	1		FEMALE CONTACT
17	57M8620	ELEC. CONNECTOR HOUSING	1		3 WAY FEM. CONNECTOR (RPM SENSOR)
18	57M8699	ELEC. CONNECTOR TERMINAL	1		1 MM2 JR TIMER CONTACT
19	57M7400	ELEC. CONNECTOR TERMINAL	1		SEAL PTS 1.2-2.1 (NOT ILLUSTRATED)

1676-7

VEHICLE ELECTRICAL SYSTEMS 16
INSTRUMENTS & INDICATORS 1676

INSTRUMENT PANEL FUSES

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT274402	FUSE HOLDER	10		
2	AT274407	FUSE	2		10 AMPS
3	AT274395	FUSE	1		8 AMPS
4	AT274406	FUSE	4	-006199	5 AMPS, (IN POS. 3,6,& 10)
	AT274406	FUSE	3	006200-	5 AMPS, (IN POS. 6 & 10)
5	AT274412	FUSE	2		20 AMPS
6	AT274393	FUSE	1		2 AMPS
7	AT274401	FUSE HOLDER	3		
8	AT302641	FUSE	1	006200-	6.3 AMPS

1740-7

FRAME, CHASSIS OR SUPPORTING STRUCTURE 17

FRAME INSTALLATION 1740

MAIN FRAME CROSSMEMBER PLATE AND HARDWARE

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT276596	PLATE	1		
2	19M7397	CAP SCREW	8		M16 X 50
3	24H1367	WASHER	4		21/32" X 1-1/4" X 1/4"
4	AT274150	SCREW	4		
5	24M7280	WASHER	8		17 X 30 X 4 MM

1810-3

OPERATOR'S STATION 18

OPERATOR ENCLOSURE 1810

CAB AND/OR ROLLOVER PROTECTIVE STRUCTURE (ROPS-CANOPY)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT275742	CAB	1	-006199	COMPLETE UPPER CAB INCLUDES WINDOWS, DOORS, WIRING HARNESS, WIPERS, A/C CONDENSER, LIGHTS AND HEADLINER (COMPONENTS ARE ON ANOTHER PAGE)
	AT278566	ROPS	1		(NOT ILLUSTRATED)(COMPLETE ROPS) (INCLUDES WIRING HARNESS AND LIGHTS) (CANOPY)
	AT304925	CAB	1	006200-	(COMPLETE UPPER CAB INCLUDES WINDOWS, DOORS, WIRING HARNESS, WIPERS, A/C CONDENSER, LIGHTS AND HEADLINER (COMPONENTS ARE ON ANOTHER PAGE)

1810-13

OPERATOR'S STATION 18

OPERATOR ENCLOSURE 1810

CAB STORAGE COMPARTMENT COVER, FOOTREST AND DOOR STOPS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT275868	COVER	1		
2	AT275562	STRIP	1		
3	AT274229	SCREW	4		
4	14M7528	LOCK NUT	4	M6	
5	AT275062	STOP	4		
6	24M7054	WASHER	4	6.400 X 12 X 1.600 MM	
7	24M7088	WASHER	2	6.600 X 12 X 1.600 MM	
8	14M7272	NUT	2	M6	
9	AT275175	CAP	2		
10	AT275873	FOOTREST	1		
11	AT275561	FOOTREST	1	STANDARD CAB	
	AT278585	FOOTREST	1	ROPS	
12	AT275855	ANGLE	2	STANDARD CAB	
	AT278523	BRACKET	2	ROPS	
13	19M7881	SCREW	4	M8 X 20	
14	24M7055	WASHER	4	8.400 X 16 X 1.600 MM	
15	AT275138	NUT	4		
16	AT274224	SCREW	4	M8 X 20. (STANDARD CAB)	
	AT261220	CAP SCREW	4	M8 X 16, (ROPS)	
17	AT261220	CAP SCREW	4	M8 X 16	
18	AT309040	STORAGE COMPARTMENT	1	(USED ON BOTH CAB AND ROPS)	
19	AT264906	PLUG	4		
20	AT264852	PIN	4		
21	AT309041	STRAP WITH BUCKLE	1		

1810-25

OPERATOR'S STATION 18
OPERATOR ENCLOSURE 1810

WINDSHIELD AND REAR WINDOW PROTECTIVE SCREENS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT304312	SCREEN SHIELD	1		(REAR SCREEN)
2	AT304306	SCREEN SHIELD	1		(FRONT SCREEN)
4	19M7496	CAP SCREW	4		M12 X 45. (SUB FOR 19M7303)
5	14M7275	NUT	4		M12
6	24M7240	WASHER	4		13 X 25 X 3 MM
7	19M7364	CAP SCREW	4		M12 X 80
8	24M7249	WASHER	8		60 X 75 X 2.800 MM
9	14M7275	NUT	4		M12
10	14M7275	NUT	4		M12
11	AT304307	COVER	1		(WINDSHIELD WIPER MOTOR COVER)
12	19M7402	CAP SCREW	2		M10 X 25, (SUB FOR 19M7167)
13	24M7028	WASHER	2		10.500 X 20 X 2 MM
14	AT304536	FIELD INSTALLATION KIT	1	-005782	(FIELD EQ. PROVIDED BY DUBUQUE) (INCLUDES PARTS NOT ILLUSTRATED)
	AT304398	COVER	1	-005782	(INCLUDED WITH AT304536 FIELD KIT) (BRACKET THAT MOUNTS TO TOP OF CAB AND TO SCREEN TO COMPLY WITH STANDARDS) (NOT ILLUSTRATED)
	19M1767	SCREW	2	-005782	(INCLUDED WITH AT304536 FIELD KIT) (NOT ILLUSTRATED)
	24M7028	WASHER	4	-005782	10.500 X 20 X 2 MM, (INCLUDED WITH AT304536 FIELD KIT) (NOT ILLUSTRATED)
	14M7274	NUT	2	-005782	M10, (INCLUDED WITH AT304536 FIELD KIT) (NOT ILLUSTRATED)
	AT274652	NUT	2	-005782	(INCLUDED WITH AT304536 FIELD KIT) (NOT ILLUSTRATED)
	AT304309	FIELD INSTALLATION KIT	1	005783-	(FIELD EQ. PROVIDED BY DUBUQUE)
15	AT304311	FIELD INSTALLATION KIT	1		(FIELD EQ. PROVIDED BY DUBUQUE)

1812-11

OPERATOR'S STATION 18

PLATFORM 1812

PLATFORM REAR MOUNTING LINK AND LIFT CYLINDER

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT275231	BUSHING	2		
2	AT274827	CYLINDER	1		
3	AT274188	SPRING WASHER	2		
4	AT275518	SLEEVE	1		
5	19M7519	CAP SCREW	1		M20 X 120
6	AT274064	WASHER	1		
7	AT275520	PLATE	1		
8	24H1621	WASHER	1		11/32" X 1" X 0.220"
9	19M7964	CAP SCREW	1		M8 X 12
10	AT275517	BRACKET	1		
11	AT274177	PIN FASTENER	1		B20X90X82
12	11M7028	COTTER PIN	1		5 X 32 MM
13	AT276673	BRACKET	1		(SUB FOR AT275805)
14	AT274100	WASHER	1		
15	AT275581	STOP	1		RUBBER SPRING
16	AT275775	PLATE	1		
17	24M7088	WASHER	4		6.600 X 12 X 1.600 MM
18	19M7660	SCREW	4		M8 X 20
19	AT275519	PIN	1		
20	14M7158	NUT	2		M16, (SUB FOR AT274094)
21	24M7053	WASHER	2		17 X 30 X 3 MM
22	AT275584	BRACKET	1		
23	AT275521	LINK	1		MOUNTING LINK
24	19M8011	CAP SCREW	4		M12 X 30, (NOT INCLUDED IN KIT)
25	24H1272	WASHER	4		9/16" X 1-1/4" X 1/4", (NOT INCLUDED IN KIT)
26	19M7489	CAP SCREW	2		M16 X 45, (NOT INCLUDED IN KIT)
27	M1976T	WASHER	2		18.263 X 31.750 X 9.525 MM, (NOT INCLUDED IN KIT)
28	PACKING	1		(SEAL KIT) (AT274841 NO LONGER AVAILABLE)
29	FITTING	2		(AT279849 NO LONGER AVAILABLE)

1814-3

OPERATOR'S STATION 18
WINDSHIELD & WIPERS 1814

FRONT WINDSHIELD WIPER (COMPONENT PARTS)

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT275139	WIPER MOTOR	1		
2	AT275140	WIPER ARM	1		
3	AT275191	WIPER BLADE	1		(SUB FOR AT310671)
4	AT274659	ELBOW FITTING	1		
5	AT274334	NOZZLE	1		
6	AT274658	CLAMP	4		
7	AT274989	HOSE	1		(0.850M)
8	AT318413	KIT	1		(FASTENING KIT)

1814-15

OPERATOR'S STATION 18
WINDSHIELD & WIPERS 1814

CAB SLIDING SIDE WINDOW

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT275150	FRAME	1		(RH)
	AT275141	FRAME	1		(LH)
2	AT275142	GUARD	1		
3	AT275151	FRAME	1		(RH)
	AT275143	FRAME	1		(LH)
4	AT275144	FRAME	1		
5	AT275145	FRAME	1		
6	AT275152	GUIDE	1		(RH)
	AT275146	GUIDE	1		(LH)
7	AT275147	WINDOWPANE	1		(FIXED)
8	AT275148	WINDOWPANE	1		(FIXED)
9	AT275149	WINDOWPANE	1		(SLIDING)
10	AT275137	HANDLE	1		(WITH SCREWS)
11	AT274585	SHEET	2		
12	AT265090	BRUSH	2		
13	ISOLATOR	3		(CUT TO LENGTH 3.000M FROM AT218793)
14	ISOLATOR	1		(CUT TO LENGTH 0.580M FROM AT218794)
15	ISOLATOR	1		(CUT TO LENGTH 0.960M FROM AT218795)
16	AT275133	RAIL	1		
17	AT274965	STOP	1		
18	AT274966	SCREW	2		
19	AT218658	GUIDE	7		
20	AT218437	SET SCREW	3		
21	ISOLATOR	3		(CUT TO LENGTH 3.300M FROM AT218889)
22	AT311220	SCREW	3		(SUB FOR AT274063)
23	ADHESIVE	1		(AT274957 NO LONGER AVAILABLE) (USE DEERE ADHESIVE AS REPLACEMENT)
24	PM37521	LIQUID GASKET	1		(SUB FOR TY24345) (NOT ILLUSTRATED)
25	AT275129	WINDOWPANE	1		(RH)
	AT275128	WINDOWPANE	1		(LH)

1830-3

OPERATOR'S STATION 18

HEATING & AIR CONDITIONING 1830

CAB HEATER / AIR CONDITIONER AND MOUNTING PARTS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	HOSE	AR		(CUT TO LENGTH 0.220M FROM TY22328 ROLL)
2	AT274265	HOSE CLAMP	8		
3	19M8359	CAP SCREW	1		M8 X 45
4	AT274755	PLATE	1		
5	AT274769	CLAMP	2		
6	AT274362	HEATER	1		
7	14M7273	NUT	4		M8
8	24M7207	WASHER	4		8.400 X 24 X 2 MM
9	24M7055	WASHER	8		8.400 X 16 X 1.600 MM
10	19M7881	SCREW	4		M8 X 20
11	AT275656	STRIP	2		
12	19M7407	CAP SCREW	4		M8 X 25
13	24M7213	WASHER	4		HEATER AND A/C TEMPERATURE AND FAN SPEED
14	19M7938	CAP SCREW	4	-005599	M10 X 20
	19M7402	CAP SCREW	4	005600-	M10 X 25
15	HOSE	AR		(CUT TO LENGTH 0.400M FROM TY22328 ROLL)
16	HOSE	AR		(CUT TO LENGTH 4.450M FROM TY22328 ROLL)
17	HOSE	AR		(CUT TO LENGTH 4.650M FROM TY22328 ROLL)

1832-7

OPERATOR'S STATION 18

AIR CONDITIONING SYSTEM & DRIVE 1832
AIR CONDITIONER COMPRESSOR BELT GUARD

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT263593	GUARD	1		
2	AT263588	ISOLATOR	8		
3	AT263590	WASHER	4		
4	AT263589	SPACER	4		
6	AT263594	SPACER	1		
7	AT263595	CLAMP	1		
8	AT263596	CLAMP	2		
10	19M8003	CAP SCREW	1		M10 X 140
11	19M8504	CAP SCREW	1		(SUB FOR 19M7325)
12	12M5442	WASHER	1		8.400 X 15 X 0.800 MM
13	19M7169	CAP SCREW	5		
14	12M1645	WASHER	2		10.500 X 21 X 1 MM

1833-11

OPERATOR'S STATION 18

CONDENSER, EVAPORATOR & LINES 1833

AIR CONDITIONING HOSES

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT196777	REFRIGERANT HOSE	1		
2	AT196778	REFRIGERANT HOSE	1		
3	AT276677	REFRIGERANT HOSE	1	-005225	
	AT275752	REFRIGERANT HOSE	1	005226-	
4	R113050	O-RING	2		(SUB FOR AT314116)
5	AT164892	HYDRAULIC CYLINDER PORT	1		(SUB FOR AT318769 OR AT314117)
6	R10093	O-RING	2		(SUB FOR AT265380)
10	AH21762	HYDR.QUICK COUPLER PLUG	2		(SUB FOR AT274792)
12	T143169	O-RING	2		(SUB FOR AT274530 OR AT306576)
14	AT274888	NUT	2		
15	AT274967	ADAPTER FITTING	1		
16	AT274968	ADAPTER FITTING	1		
18	AT275002	CLAMP	4		
19	LW7362606	COVER	2		(SUB FOR AT274800, THIS APPLICATION)
20	19M8008	CAP SCREW	2		
21	R33259	O-RING	1		(SUB FOR AT265381)
22	T143169	O-RING	1		(SUB FOR AT265381)
23	AT164903	FITTING	1		(SUB FOR AT265367 OR AT318767)
24	AT265627	BULK HOSE	1		(CUT TO LENGTH 0.32M)
25	AT275000	CLIP	4	-005225	
	AT275000	CLIP	2	005226-	
26	AT274755	PLATE	2	-005225	
	AT274755	PLATE	1	005226-	
27	19M8359	CAP SCREW	2	-005225	
	19M8359	CAP SCREW	1	005226-	
34	AT276200	GROMMET	1		
35	AT274646	CLIP	2	005226-	
36	24M7055	WASHER	2	005226-	8.400 X 16 X 1.600 MM
37	19M7660	SCREW	1	005226-	M8 X 20
38	19M7761	SCREW	1	005226-	M8 X 16
39	R57637	WASHER	2		
40	R44302	TIE BAND	10		(SUB FOR AT218613)

1913-5

SHEET METAL & STYLING 19

MISCELLANEOUS SHIELDS 1913

SIDE COMPARTMENT DOORS AND DOOR CYLINDERS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT274862	RIVET	6		
2	AT274672	KEY	2		
3	AT266603	ISOLATOR	AR		(CUT TO LENGTH 1.420M FROM 1.960M ROLL)
4	AT266603	ISOLATOR	AR		(CUT TO LENGTH 0.740M FROM 1.960M ROLL)
5	AT266603	ISOLATOR	AR		((CUT TO LENGTH 0.790M FROM 1.960M ROLL)
6	AT274982	BALL JOINT	4		
7	AT263604	CYLINDER	2		(SUB FOR AT274677)
8	24M7055	WASHER	4		8.400 X 16 X 1.600 MM
9	14M7273	NUT	4		M8, LEFT
10	19M7881	SCREW	4		M8 X 20
11	24M7055	WASHER	8		8.400 X 16 X 1.600 MM
12	AT275578	STRIP	2		
13	AT275575	DOOR	1		LH
14	AT274867	STOP	4		
15	AT275583	ANGLE	2		
16	19M7938	CAP SCREW	4		M10 X 20
17	24M7213	WASHER	4		10.500 X 25 X 4 MM
18	14M7272	NUT	4		M6
19	AT275576	DOOR	1		RH
20	AT274687	LOCK	1		

2001-3

SAFETY, CONVENIENCE & MISCELLANEOUS 20

RADIO 2001

RADIO, RADIO ANTENNA AND SPEAKERS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT264516	FIELD INSTALLATION KIT	1		(WITH INSTALLATION INSTRUCTIONS)
2	14M7297	NUT	1	-XXXXXX	
	14M7297	NUT	2	XXXXXX-	
3	24M7138	WASHER	1		
4	AT275565	BUSHING	1	-XXXXXX	
5	AT279800	RADIO SPEAKER WRG HARNESS	1		
6	AT274446	WIRING HARNESS	1		
7	AT274457	ELEC. CONNECTOR TERMINAL	2		
10	AT274423	TRANSFORMER	1		
11	AT274165	SOCKET HEAD SCREW	2		
12	24M7117	WASHER	2		
15	AT274836	SPEAKER	2		
16	AT274468	ADAPTER FITTING	2		
17	AT274392	ADAPTER FITTING	2		
20	AT278464	ANTENNA CABLE	1		
21	R44302	TIE BAND	AR		
25	AT275738	CLAMP	1	-XXXXXX	
26	LW226016702	ISOLATOR	AR	-XXXXXX	(CUT TO LENGTH (0.14M)) (SUB FOR AT264803, THIS APPLICATION)
27	AT274212	SCREW	1	-XXXXXX	
28	AT275173	WASHER	1	-XXXXXX	
29	AT274056	WASHER	1		
30A	AT274560	ANTENNA	1	-005083	(ROOF MOUNT)
30B	AT263569	ANTENNA	1	005084-	(SUB FOR AT263603) (SIDE MOUNT)

2005-3

SAFETY, CONVENIENCE & MISCELLANEOUS 20

TOOLBOX 2005

BASIC SERVICE TOOLS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT275232	LEVER	1		(CAB TILT LEVER)
2	AT274435	FUSE	1		(SPARE FUSES)
3	AT274393	FUSE	2		02 AMP
4	AT274412	FUSE	2		20 AMP
5	AT274406	FUSE	3		05 AMP
6	AT274395	FUSE	5		08 AMP
7	AT274407	FUSE	3		10 AMP
8	AT274405	FUSE	3		16 AMP
9	AT274415	FUSE	2		25 AMP
10	AT274249	EYEBOLT	3		(FOR CAB REMOVAL)
11	AT274481	KEY	1		(DOOR KEY)(12MM)
12	AT275202	ADAPTER FITTING	1		
13	AT317444	HOSE	1		(INCLUDES AT275202)
14	AT263586	HOSE	2		(JUMP HOSES FOR MACHINE TOWING)
15	AT275807	ADAPTER FITTING	1		(DUO CONE REFILLING HOSE)(USE ONLY)
16	AT277194	FITTING	1		
17	ADAPTER FITTING	1		(SUB FOR AT319308) (SERVICE WITH ASSEMBLY AT275807)
18	AT264907	QUICK COUPLER	1		
19	AT274182	FITTING	1		
20	AT275808	ADAPTER FITTING	1		(DUO CONE SEAL CAVITY DRAIN HOSE) (USE ONLY)
21	AT275228	HOSE	1		
22	AT274265	HOSE CLAMP	1		
23	AT218866	FITTING	1		
24	AT274777	HOSE	1		

2163-11

VEHICLE MAIN HYDRAULIC SYSTEM 21
HYDRAULIC LINES AND HOSES 2163

MAIN HYDRAULIC CONTROL VALVE

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT265190	COMPRESSION SPRING	4		
2	AT280136	PLATE	4		
3	AT300832	VALVE SPOOL	2	-006199	(BOOM RAISE/LOWER AND BUCKET TILT)
	AT266087	VALVE SPOOL	2	006200-	(BOOM RAISE/LOWER AND BUCKET TILT)
4	AT280144	PRESSURE RELIEF VALVE	1	-006199	
	AT266091	PISTON	1	006200-	
5	AT280145	PLUG	1	-006199	
	AT266092	SELF-LOCKING SCREW	1	006200-	
6	AT278405	PRESSURE RELIEF VALVE	3		(CIRCUIT RELIEF VALVE) (INCLUDES AT280153)
	AT278399	SEAL KIT	1		(NOT ILLUSTRATED) (SEAL KIT FOR AT278405)
7	LW7369482	FITTING PLUG	4	-006803	(SUB FOR AT280137)
	AT316496	VALVE	4	006804-	
8	AT280133	COVER	4		
9	19M7768	SCREW	8		M6 X 16
10	AT300830	SOLENOID VALVE	1		(FLOAT) (INCLUDES AT280153)
	AT280154	GASKET KIT	1		(NOT ILLUSTRATED) (SEAL KIT)
11	AT265102	PLUG	2	-006199	
	AT266090	PLUG	2	006200-	
12	AT280143	CHECK VALVE	2		(CHECK VALVE)
13	LW7369482	FITTING PLUG	1	-006199	(SUB FOR AT280137)
	AT266088	PLUG	1	006200-	
14	AT280147	PRESSURE RELIEF VALVE	1		(SYSTEM RELIEF VALVE) (INCLUDES AT280151)
	AT280151	SEAL KIT	1		(NOT ILLUSTRATED) (SEAL KIT FOR AT280147)
15	AT266093	PISTON	1		
16	AT280148	SOLENOID VALVE	1		(FLOAT) (INCLUDES AT280153 AND AT311707)
	AT311707	SOLENOID	1		(NOT ILLUSTRATED) (INCLUDED IN AT280148)
	AT280153	GASKET KIT	1		(NOT ILLUSTRATED) (SEAL KIT) (INCLUDED IN AT280148)
17	AT280138	FITTING	2		
18	AT280140	SPRING	2		
19	AT280139	PLUNGER	2		
20	AT280142	PLUG	1	-006199	
	AT266089	SELF-LOCKING SCREW	1	006200-	
21	AT311439	CONTROL VALVE	1		(SUB FOR AT266086 AND AT274375)
22	AT265062	CAP SCREW	4	-006199	
	AT266094	CAP SCREW	4	006200-	
23	AT265660	WASHER	4		
24	AT265131	COVER	1		
25	AT263581	O-RING KIT	1	-006199	
	AT266096	O-RING KIT	1	006200-	(INCLUDES ALL SEALS IN KEY 26)
26	AT196491	O-RING KIT	1	-006199	
	AT266096	O-RING KIT	1	006200-	(INCLUDES ALL SEALS IN KEY 25)
27	AT265103	PLUG	1		
28	AT265104	PLUG	1		

3102-7

LOADER 31

BUCKET (INCLUDING TEETH) 3102

STANDARD BUCKET WEARPLATES

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT276660	WEAR PLATE	1		
2	AT276661	WEAR PLATE	1		
3	AT276662	WEAR PLATE	1		
4	AT276663	WEAR PLATE	2		
5	AT276664	WEAR PLATE	1		
6	AT276665	WEAR PLATE	2		
7	AT276666	WEAR PLATE	1		
8	AT276667	WEAR PLATE	1		
9	AT276668	WEAR PLATE	1		

3115-3

LOADER 31

CONTROLS LINKAGE 3115

PILOT CONTROLLER AND FITTINGS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT274638	FITTING	1		
2	AT274796	ELBOW FITTING	1		
3	AT274794	TEE FITTING	1		
4	AT274803	COUPLING	1		
5	AT261740	FERRULE	2		(SUB FOR AT274523)
6	AT261739	TUBE NUT	2		
7	AT218872	TEE FITTING	1		
8	AT218871	ELBOW FITTING	1		
9	AT218837	FITTING	5		
10	AT275506	HYDR./PILOT CONTROL VALVE	1	-006199	(STANDARD BUCKET) (COMPONENTS ON FOLLOWING PAGES)
	AT304503	HYDR./PILOT CONTROL VALVE	1	006200-	(STANDARD BUCKET) (SUB FOR AT266098) (COMPONENTS ON FOLLOWING PAGES)
	AT278513	HYDR./PILOT CONTROL VALVE	1		(FOUR IN ONE)BUCKET W/SWITICH, (COMPONENTS ON FOLLOWING PAGES)

3143-7

LOADER 31

MOVEABLE FRAME 3143

BUCKET CYLINDER, OIL LINES AND CLAMPS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT276586	BRACKET	1		
2	AT276717	HYDRAULIC CYLINDER	1	-006251	
	AT303783	CYLINDER	1	006252-	
3	AT276588	U-BOLT	2		
4	AT275211	CAP	2		
5	AT218851	O-RING	2		
6	19M7943	CAP SCREW	8		M12 X 90
7	AT276587	OIL LINE	2		
8	AT276589	BRACKET	2		
9	14M7166	LOCK NUT	4		M8
10	AT276185	CLAMP	4		
11	AT274761	PLATE	2		
12	19M7479	CAP SCREW	2		M10 X 80
13	AT276590	PLATE	1		
14	19M8183	CAP SCREW	2		M10 X 90
15	AT198498	FIELD INSTALLATION KIT	1		(WHOLE GOODS) (TILT GUARD KIT) (NOT ILLUSTRATED)

3163-11

LOADER 31

BOOM LIFT CYLINDER HOSE GUARD (SERIAL NO. 005447-) LINES, HOSES & FITTINGS 3163

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT304606	COVER	1		
2	AT304607	STRAP	4		
5	24H1272	WASHER	4		9/16" X 1-1/4" X 1/4"
6	19M7073	CAP SCREW	2		M12 X 50
7	14M7275	NUT	4		M12
11	19M7415	CAP SCREW	2		M12 X 130
12	AT279866	CLAMP	1		
13	AT304609	SUPPORT	1		
14	AT275979	SOCKET HEAD SCREW	2		
15	AT304610	BRACKET	1		(RUBBER)
16	AT304611	PLATE	1		
17	19M7402	CAP SCREW	4		M10 X 25. (SUB FOR 19M7167)
18	24M7028	WASHER	4		10.500 X 20 X 2 MM
19	AT304612	PLATE	1		

3163-23

LOADER 31

LINES, HOSES & FITTINGS 3163

FRONT AUXILIARY HYDRAULIC LINES, HOSES AND CLAMPS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT278652	LINE	2		
2	19M7875	CAP SCREW	8		M10 X 70, (SUB FOR 19M7328)
3	AT278613	HYDRAULIC HOSE - FABRICATE	1		
4	AT278612	HYDRAULIC HOSE - FABRICATE	1		
5	LW10286360	FLANGE	8		(SUB FOR AT218503, THIS APPLICATION)
6	AT218851	O-RING	4		
7	19M7496	CAP SCREW	16		M12 X 45
8	AT277868	PLUG	2		
9	AT276185	CLAMP	8		
10	AT274761	PLATE	4		
..	AT264532	KIT	1		(WHOLE GOODS) (HYDRAULIC LINES FOR FRONT ATTACHMENTS) (INCLUDES ALL COMPONENTS NECESSARY TO ADD FRONT AUXILIARY HYDRAULICS) (ALSO INCLUDE AT194074 AUXILIARY HYDRAULIC CONTROLS FOR FRONT ATTACHMENTS)

3165-7

LOADER 31

HYDRAULIC CYLINDERS 3165

MULTI-PURPOSE BUCKET CYLINDER COMPONENTS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT218839	SEAL	4		
2	AT219295	BUSHING	2		
3	AT278627	HYDRAULIC CYLINDER BARREL	1		
4	AT219273	LUBRICATION FITTING	2		
5	AT278489	HYDRAULIC CYLINDER ROD	1		
6	AT278591	CAP SCREW	9		M12 X 70
7	LW9600923	BEARING	1		(SUB FOR AT278631)
8	AT278364	SNAP RING	1		
9	AT278628	PISTON	1		
10	AT278588	NUT	1		
11	AT278658	HYDRAULIC CYLINDER	1		(COMPLETE)
13	PISTON RING	2		(AT278499 NO LONGER AVAILABLE)
14	AT313848	O-RING	1		
15	AT313853	SEALING RING	1		
16	PISTON RING	1		(AT278602 NO LONGER AVAILABLE)
17	AT278630	SEAL KIT	1		
21	BEARING	1		(LW9600924 NO LONGER AVAILABLE)
22	LW7006262	RAIL	2		(GUIDE RING)
23	LW10097242	BACK-UP RING	1		
24	LW10099923	O-RING	1		
25	SCRAPER RING	1		(AT319250 NO LONGER AVAILABLE) (SUB TO AT300536)
26	LW7010666	SEAL	1		
27	AT313851	O-RING	2		
28	O-RING	1		(AT278597 NO LONGER AVAILABLE) (SUB TO AT300536)
29	SEAL	1		
30	AT278629	SEAL KIT	1		
31	AT265552	WASHER	9		

4263-3

GROUND CONDITIONING TOOL 42

LINES, HOSES, AND FITTINGS 4263

HYDRAULIC HOSES AND FITTINGS, THREE SHANK RIPPER

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT264638	CAP SCREW	2		M16 X 20, (SUB FOR AT218440, THIS APPLICATION)
2	24H1380	WASHER	2		11/16" X 1-3/4" X 0.194"
3	AT278648	PIN	2		
4	AT275211	CAP	4		DUST CAP
5	LW10290520	O-RING	4		(SUB FOR AT274678)
6	LW10286359	FLANGE FITTING	8		(SUB FOR AT274302, THIS APPLICATION)
7	19M7550	CAP SCREW	16		M10 X 35
8	AT278439	HYDRAULIC HOSE - FABRICATE	2		
9	19M8539	CAP SCREW	8	-005969	M8 X 90, BLOCK
10	LW10290520	O-RING	4	-005969	(SUB FOR AT274678)
11	AT278659	HYDRAULIC CYLINDER	2		(COMPONENTS ON A SEPARATE PAGE)
12	AT278580	RETAINER	1		
13	R113500	WASHER	3		
14	19M7610	CAP SCREW	3		M20 X 40
15	AT278647	TUBE	1	-005969	HYDRAULIC, LEFT CYLINDER
16	AT276016	SCREW	8	-005969	M10 X 75
17	AT278438	HYDRAULIC HOSE - FABRICATE	2		
18	AT278533	RETAINER	1		
19	AT278368	CAP SCREW	2		M30 X 50
20	AT278646	LINE	1	-005969	HYDRAULIC, RIGHT CYLINDER
39	AT304095	JUNCTION BLOCK	1	005970-	LEFT
40	AT304105	JUNCTION BLOCK	1	005970-	RIGHT
41	AT304751	LINE	2	005970-	
42	LW10290520	O-RING	6	005970-	(SUB FOR AT274678)
43	19M8081	CAP SCREW	8	005970-	M10 X 80
44	19M8539	CAP SCREW	8	005970-	M8 X 90
45	AT304752	PLATE	2	005970-	
47	AT218491	FITTING	2	005970-	
48	AT304111	SLEEVE FITTING	2	005970-	
49	AT304109	TUBE NUT	2	005970-	

4265-3

GROUND CONDITIONING TOOL 42

HYDRAULIC CYLINDER 4265

RIPPER CYLINDER COMPONENT PARTS

KEY	PART NO.	PART NAME	QTY.	SERIAL NO.	REMARKS
1	AT274640	SEAL	4		
2	AT274648	PIPE PLUG	1		
3	AT276413	BUSHING	2		
4	AT219273	LUBRICATION FITTING	2		
5	AT278626	HYDRAULIC CYLINDER BARREL	1		
6	AT274097	NUT	1		
7	AT274102	SNAP RING	1		
8	AT278625	ROD	1		
9	19M8350	CAP SCREW	9		M16 X 85
10	AT304753	HYDR. CYLINDER ROD GUIDE	1		(SUB FOR AT278661)
	GREASE	1		(AT315965 NLA)
	RUST INHIBITOR	1		(AT315966 NLA)
11	AT275360	PISTON	1		(INCLUDES O-RING)

00II-5

755C CRAWLER LOADER

NUMERICAL INDEX - CONTINUED

PART NO.	KEY	PAGE	PART NO.	KEY	PAGE	PART NO.	KEY	PAGE
AT274012	8	1011-3	AT274113	17	0360-21	AT274219	9	1810-9
AT274018	10	0404-5	AT274115	5	0401-3	AT274220	6	3115-7
AT274019	6	1816-3	AT274116	14	1813-11	AT274223	40	1830-5
AT274024	9	0510-3	AT274117	3	0360-9D	AT274224	19	1674-9
AT274024	2	0510-3B	AT274118	21	0360-19	AT274224	25	1674-11
AT274026	6	0423-3	AT274119	3	0962-3	AT274224	7	1674-13
AT274027	12	0403-3	AT274120	2	0401-3	AT274224	16	1810-13
AT274027	7	0413-3	AT274123	20	0564-3	AT274225	8	1674-23
AT274029	5	0402-7	AT274127	13	0315-7	AT274226	4	1011-3
AT274029	3	0521-3	AT274127	2	3163-17	AT274228	6	0962-7
AT274030	2	0401-5	AT274127	2	4263-9	AT274229	3	1810-13
AT274030	12	0407-13	AT274135	11	0402-7	AT274232	9	0531-3
AT274030	15	0407-13	AT274140	18	3143-5	AT274233	3	0869-3
AT274030	13	0413-7	AT274140	10	3165-13	AT274233	11	2004-3
AT274030	2	0413-9	AT274141	2	0360-3	AT274234	74	0360-51
AT274030	8	0505-5	AT274141	20	0360-3	AT274234	19	0360-53
AT274033	5	0433-5	AT274141	6	0360-3B	AT274235	9	0201-3
AT274035	4	0429-5	AT274141	20	0360-3B	AT274237	11	0416-3
AT274036	2	0404-5	AT274141	5	0420-9	AT274237	3	0416-5
AT274037	1	0418-7	AT274141	16	0515-3	AT274247	20	0413-11
AT274040	11	0433-5	AT274142	1	0413-5	AT274247	8	0420-5
AT274041	14	0404-5	AT274142	4	0419-3	AT274247	8	0420-7
AT274042	2	0521-5	AT274150	4	1740-7	AT274247	16	0420-9
AT274043	13	0404-5	AT274155	2	0422-3	AT274247	50	0452-5
AT274044	3	0404-5	AT274155	3	0429-3	AT274247	7	0510-3
AT274045	17	0402-7	AT274158	14	1813-7	AT274247	3	0510-3B
AT274047	14	0360-9D	AT274165	7	0962-3	AT274249	10	2005-3
AT274047	27	0360-15	AT274165	9	1011-3	AT274250	4	0401-3
AT274051	8	0962-5	AT274165	31	1674-23	AT274252	42	0360-15
AT274052	5	0407-17	AT274165	11	2001-3	AT274252	17	1832-3
AT274053	8	1812-5	AT274169	1	0360-41	AT274254	8	0521-3
AT274056	29	2001-3	AT274170	39	0360-33	AT274256	16	1674-9
AT274058	11	1830-9	AT274170	13	0360-41	AT274256	22	1674-11
AT274059	16	1674-15	AT274170	10	0360-59	AT274256	4	1674-13
AT274059	19	1674-17	AT274170	11	2164-5	AT274256	34	1812-7
AT274063	22	1814-15	AT274170	13	2164-5	AT274261	12	0402-7
AT274064	6	1812-11	AT274170	12	3163-29	AT274265	1	0510-5
AT274064	15	1913-3	AT274171	13	0531-3	AT274265	59	0510-5B
AT274064	12	3163-3	AT274177	11	1812-11	AT274265	2	1830-3
AT274066	14	0531-3	AT274181	5	0260-3	AT274265	22	2005-3
AT274067	5	0404-5	AT274182	71	0360-51	AT274267	15	0510-7B
AT274067	11	0418-3	AT274182	16	0360-53	AT274267	9	0515-5
AT274067	14	0418-9	AT274182	19	2005-3	AT274267	18	0531-3
AT274071	4	0433-5	AT274185	6	1812-9	AT274270	1	0133-3
AT274076	7	3165-3	AT274187	6	1674-9	AT274270	2	1740-3
AT274087	3	0360-19	AT274187	5	1674-11	AT274273	18	0515-3
AT274087	3	0360-21	AT274188	3	1812-11	AT274273	35	1913-3
AT274087	3	0422-3	AT274190	1	1676-3	AT274275	7	0417-3
AT274088	15	0417-3	AT274191	5	0510-7	AT274278	5	0407-11
AT274090	6	0413-15	AT274194	30	0360-35	AT274279	11	0409-5
AT274090	9	0417-3	AT274195	31	0360-35	AT274279	4	0418-3
AT274091	21	0201-5	AT274196	26	0360-15	AT274281	2	3163-15B
AT274094	14	0360-15	AT274196	7	0360-37	AT274281	21	4263-9
AT274094	3	0418-9	AT274199	11	1812-5	AT274284	23	0417-3
AT274094	20	1812-11	AT274207	17	0360-3B	AT274285	15	0402-7
AT274095	13	1812-5	AT274207	24	0510-9D	AT274286	48	0452-5
AT274096	9	0404-7	AT274207	28	0510-9D	AT274286	6	0510-3
AT274097	6	4265-3	AT274207	17	2164-5	AT274286	8	0510-3B
AT274100	14	1812-11	AT274209	4	1810-11	AT274290	20	0429-3
AT274101	7	0201-3	AT274209	6	1810-11	AT274291	2	0429-3
AT274102	7	4265-3	AT274211	12	1921-3	AT274292	2	0402-3
AT274103	12	3165-3	AT274212	27	2001-3	AT274293	25	0417-3
AT274103	8	3165-5	AT274213	3	1678-3	AT274294	6	0402-3
AT274106	3	0409-7	AT274213	33	1830-5	AT274295	2	0403-3
AT274108	14	0201-5	AT274215	20	1816-3	AT274296	9	0423-3
AT274111	8	2164-3	AT274217	5	1830-9	AT274296	16	1832-3
AT274113	20	0360-19	AT274218	2	1830-9	AT274297	23	1832-3

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL