

MASCAR



Spare parts catalogue



Round baler **CORSA 320-320L**

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Pos.	Code	Description	Quantity
41	50006116	CORSA STROKE COUNTER STAFF	1
42	054.001	ZINCED TORSION SPRING 0,5X5X29	1
43	022.140	EYE TIE-ROD M12 L=90 6058 ZB	2
44	056.452	DRIVE SPRING (7X50X290) ZBD	2
45	50003046	SAFETY CATCH HOOK RIGHT	1
46	50003047	SAFETY CATCH HOOK LEFT	1
47	020.082	SCREW TTQST M6X20 4.6 5731 ZB	2
48	50003216	INDICATOR CABLE CONNECTION STUFF 120-125	1
49	020.013	TE M6x25 8.8 ISO 4017 ZB SCREW	1
50	61006252	PIN D=10-14 ZB	1
51	50003219	ROPE CONNECTION	1
52	021.002	NUT E 6S M 6 5588 ZB	2
53	023.008	FLAT WASHER M 5= 5.3X10X1 6592 ZB	2
54	020.492	TCEI M5x40 8.8 ISO 4762 ZB SCREW	2
55	076.377	MICRO SWITCH CONNECTOR AND CABLE	1
56	023.770	TAPER WASHER EL.D.10,2X20X2,7 ZBD	2
57	021.112	SELFBLOCKING NUT M 10 7473 ZB	2
58	021.100	SELFBLOCKING NUT M 5 7474 ZB	2
59	50003226	PRESSIO REGULATION 120-150	1
60	021.004	NUT E 6S M 10 5588 ZB	1
61	020.103	SCREW TE M 10X35 8.8 5739 ZB	1
62	020.105	SCREW TE M 10X45 8.8 5737 ZB	1
63	50003215	INDICATING ARROW PIN ZB	1
64	50003210	COMP.S. INDICATING ARROW ZB	1
65	052.160	SELFLUBR. BUSHING FRIMIX 14-16-15 TFP	1
66	50003078	REAR DOOR HOOKING BUSH	1
67	028.095	SEEGER RING E D. 6 7435/471	1
68	50003142	BLADE BEATING SQUARE TUBE (PET)	1
69	50003114	PIN FOR SPRING	1
70	020.014	SCREW TE M 6X30 8.8 5739 ZB	1
71	50003233	SYMM. PRESSION REGULATION STIRRUP120-150	1
72	021.505	KNURLED NUT AND FLANGE M 6 D.6923 ZB	5
73	020.961	SCREW TE M6X16 8.8 6921 ZB	2
74	53006911	WIRING "CORSA - TUAREG"	1
75	076.432	MONITOR M50 *	1
76	076.433	MONITOR M100	1
77	53006910	BATTERY FEEDING CABLE	1
78	50003190	MONITOR UNIT	1
79	020.009	SCREW TE M6X12 8.8 5739 ZB	1
80	095.311	MAGHET D.76 H.12 (SEE DRAW)	1

S.N.

Pos.	Code	Description	Quantity
1	028.112	SEEGER RING E D. 35 7435/471	136
2	050.050	BEARING RC 07 2RS (LR 207 RHB)	68
3	50002309	WHEELBASE BAR 1270	34
4	021.114	SELFBLOCKING NUT M 8 7473 ZB	7
5	50002216	FIXED END PINION VIR CL	2
6	50002280	SUPPORT ZB	2
7	028.263	SEEGER RING E D. 45 7436 (HEAVY)	1
8	050.003	BEARING 6007-2RS	4
9	028.029	SEEGER RING I D. 85 7437/472	2
10	027.503	GROOVE-AND-TONGUE JOINT 14X9X56 6604/A	2
11	50003014	PIN ZB	1
12	50002317	PROTECTION ZB	2
13	062.626	WASHERS CYL. 50003010	1
14	50002050	COMP.M. REDUCER	1
15	032.014	P.T.O. SHAFT CORSA "STD-6 C.LT" 1050 NM	1
15	032.015	P.T.O. SHAFT CORSA "OPT-6 C.LT" 1050 NM	1
16	024.233	COVER D. 4 X 20 ZB 1336	4
17	020.150	SCREW TE M12X 20 8.8 5739 ZB	2
18	023.040	FLAT WASHER M12=13 X24X2,5 6592 ZB	2
19	50003012	CYLINDER STIRRUP	1
20	020.547	SCREW TCEI M10X 50 8.8 5931 ZB	1
21	50002064	TRANSMISS. CLUTCH RIGHT	1
22	050.009	BEARING 25X62X17 6305-2RS	1
23	50003026	FORK FULCRUM SHAFT ZB	1
24	020.501	SCREW TCEI M 6X 20 8.8 5931 ZB	2
25	50002068	SHAFT EXTENSION	1
26	021.103	SELF-BLOCKING NUT M10 UNI 7474 ZB	4
27	50002052	BEARING SUPPORT LF VIR CL	1
28	050.088	BEARING INA 208 NPPB (40X80X18)	1
29	50002096	SPACER 40X51X12 ZB	1
30	023.110	FLAT WASHER 36X45X2 ZN	136
31	50002233	SCRAPER RH ZB	1
32	020.602	SCREW TTQST M 8X 30 4.6 5731 ZB	4
33	50002210	COMP. S. FIXEND END	1
34	50002234	SCRAPER LF ZB	1
35	50003038	PIN ZB	1
36	50003010	CONNECTION CYLINDER	1
37	50003016	COMP.S. DISCONNECTION FORK ZB	1
38	50002070	CONNECTION SPRING ZBD	1
39	50002066	TRANSIMISS. CLUTCH LEFT	1

S.N.

Pos.	Code	Description	Quantity
1	028.253	SEEGER RING E D. 29 7436 (HEAVY)	4
2	028.322	"PS" 30x42x1 DIN988 RING	3
3	028.257	SEEGER RING E D. 34 7436 (HEAVY)	2
4	08500211	CHAIN ISO 56 LINKS	1
5	08500210	GEAR Z=34 3/4" ISO	2
6	08500215	CONTROL SPACER DX 35X12	1
7	028.112	SEEGER RING E D. 35 7435/471	4
8	08500223	SUPPORT SHAFT 72	2
9	050.008	BEARING 6207-2RS	2
10	08500204	TRANSMISSION SHAFT	1
11	08500222	BAND EXTENSION SP"N25T"	2
12	020.961	SCREW TE M6X16 8.8 6921 ZB	88
13	08500220	GUIDING BAND SP SV 729	10
14	08501054	SPRING SUPPORT TUBE	4
15	08500219	GUIDING BAND SV 729	12
16	021.103	SELF-BLOCKING NUT M10 UNI 7474 ZB	13
17	023.302	GROWER WASHER A M10-D.10,5 1751 ZBD	8
18	020.101	SCREW TE M 10X25 8.8 5739 ZB	8
19	08500203	SIDE DX	1
20	028.250	SEEGER RING E D. 25 7436 (HEAVY)	1
21	023.094	FLAT WASHER 28X42X4 ZN	2
22	021.114	SELFBLOCKING NUT M 8 7473 ZB	53
23	500.091	PLATE "U" DW.88.107/1	4
24	500.090	SPRING "U25R D.5.5" SP CL "C"	4
25	023.020	FLAT WASCHER M 8=8,4X16X1,6 6592 ZB	48
26	020.056	SCREW TE M8X45 8.8 5737 ZB	48
27	8500209		4
28	020.104	SCREW TE M10X 40 8.8 5739 ZB	8
29	023.020	FLAT WASCHER M 8=8,4X16X1,6 6592 ZB	8
30	08500218	CHAIN TIGHTENER PLATE	2
31	08500216	CHAIN TIGHTENER	2
32	08500217	LOWER PLATE CHAIN TIGHTENER	2
33	050.103	BEARING 30X62X13 6206-2RS1	6
34	500.008	NYON BUSHING (PICK-UP ROLL)	24
35	50001420		1
36	08500212	CHAIN ISO 64 LIKS	1
37	021.030	NUT E 6S M 12 5589 ZB	4
38	08501055	SMALL WHEEL LR5201 NPPU	4
39	023.017	FLAT WASCHER M8=9 X24X2 6593 ZB	8
40	021.113	SELFBLOCKING NUT M 12 7473 ZB	4

S.N.

Pos.	Code	Description	Quantity
121	027.214	GROOVE-AND- TONGUE JOINT 8X7X16 6604/A	1
122	028.102	SEEGER RING E D. 17 7435/471	1
123	028.104	SEEGER RING E D. 18 7435/471	1
124	028.112	SEEGER RING E D. 35 7435/471	1
125	031.020	BELT Z 34 1/4" (10X6) L=870	1
126	050.040	FREE WHEEL BEARING CSK. P 17X40X12	1
127	052.100	SELFLUBR. BUSCHING MU TFP 20-23-20	3
128	095.057	LOCK NYLON CABLE	1
129	10001912	SEED COVER SPRING ZB	1
130	50005302	COMP.M. BINDING STARTING ROPE L=4MT	1
131	50005783	NET BINDING LEVER PIN	1
132	50005784	TIE-ROD PULLEY PIN	1
133	50005785	TIGHTENER PULLEY	1

S.N.

Pos.	Code	Description	Quantity
41	027.099	GROOVE-AND-TONGUE JOINT 6X6X10 6604/A	1
42	027.104	GROOVE-AND-TONGUE JOINT 6X6X35 6604/A	1
43	028.001	SEEGER RING I D.42 7437/472	3
44	020.013	TE M6x25 8.8 ISO 4017 ZB SCREW	8
45	020.082	SCREW TTQST M6X20 4.6 5731 ZB	6
46	020.678	SCREW TSPEI M 8X16 10.9 5933 ZB	2
47	021.101	SELFBLOCKING NUT M 6 7474 ZB	4
48	023.010	FLAT WASCHER M6=6,3X12X1,6 6592 ZB	8
49	50005040	DRIVE SPRING 1,2X11,8X36,6 ZBD	2
50	50005048	SLIDING BLOCK (NYLON 66)	4
51	50005054	SPACER ZB	2
52	50005440	GUIDE 2007	2
53	50005441	EYES HOOKING	2
54	50005442	HOOK	2
55	50005444	COMP.S. TWINE GUIDE WYE ZB	2
56	020.026	SCREW TE M 8X55 8.8 5737 ZB	2
57	020.736	SCREW TTQST M 6X50 4.6 5731 ZB	2
58	021.115	SELFBLOCKING NUT M 6 7473 ZB	4
59	022.310	EYE OF TIE-ROD M8X60 DX ZB	2
60	024.342	ELASTIC PIN D.6X16 6873 NE	2
61	024.344	ELASTIC PIN D.6X30 6873 NE	2
62	028.010	SEEGER RING I D. 55 7437/472	2
63	028.022	SEEGER RING I D. 72 7437/742	2
64	028.110	SEEGER RING E D. 30 7435/471	2
65	028.237	SEEGER RING E D. 18 7436 (HEAVY)	5
66	033.300	FREE WHEEL Z=16 1/2X1/8	2
67	050.002	BEARING 6006-2RS	2
68	056.100	DRIVE SPRING (2X15X75) ZB	2
69	50005092	BUSHING	2
70	50005096	FREE WHEEL PIN ZB	2
71	50005100	SPACER	1
72	50005110	MOTOR SHAFT ZB	1
73	50005420	BINDING SYSTEM CASE 2007	1
74	50005421	TWINE PRESS LEVER WITH SPRING	2
75	50005422	TWINE PRESS LEVER	2
76	50005423	ANTI-EXIT PROFILE ZB	1
77	50005425	TWINE DRIVING SMALL WHEEL 2007	2
78	50005426	TWINE MOTOR SMALL WHEEL ZB	2
79	50005427	BINDING CASE PIN	1
80	50005428	TWINE PRESS PIN	2

S.N.

Pos.	Code	Description	Quantity
1	08543137	NEUTRAL TUBE D.4X2,5	1
2	08543137	NEUTRAL TUBE D.4X2,5	1
3	08543137	NEUTRAL TUBE D.4X2,5	1
4	08543137	NEUTRAL TUBE D.4X2,5	1
5	08543136	BLACK TUBE D.6 X3	1
6	08543136	BLACK TUBE D.6 X3	1
7	08543136	BLACK TUBE D.6 X3	1
8	08543138	BLUE TUBE D. 8X6	1
9	020.005	SCREW TE M 6X8 8.8 5739 ZB	1
10	020.007	SCREW TE M 6X45 8.8 5739 ZB	2
11	020.012	TE M6x20 8.8 ISO 4017 ZB SCREW	4
12	020.013	TE M6x25 8.8 ISO 4017 ZB SCREW	2
13	020.014	SCREW TE M 6X30 8.8 5739 ZB	4
14	020.020	TE M6x60 8.8 ISO 4014 ZB SCREW	1
15	020.021	SCREW TE M 6X60 8.8 5739 ZB	1
16	020.022	SCREW TE M 6X 70 8.8 5737 ZB	1
17	020.052	SCREW TE M 8X25 8.8 5739 ZB	2
18	020.102	SCREW TE M10X30 8.8 5739 ZB	1
19	021.114	SELFBLOCKING NUT M 8 7473 ZB	2
20	021.115	SELFBLOCKING NUT M 6 7473 ZB	12
21	023.829	D 4X12 ALUMINIUM RIVET	3
22	024.320	ELASTIC PIN D.5X16 6873 NE	1
23	025.400	COLLAR RUBBER TUBE TIGHTENING"ABA"D.18	4
24	060.701	TANK 4L EXIT 90° D8	1
25	08543003	BLOCKAGE 5/162 24UNF 2+2V	1
26	08543007	STOPPER (05.001.0)	3
27	08543025	TUBE-FASTENING CLAMP D=6mm	3
28	08543027	CONNECTION BLOCK (01.050.0)	1
29	08543037	PUSH-IN 90° 1/8" G-D8	1
30	08543038	PUSH-IN 90° 1/8" K-D6	1
31	08543039	PUSH-IN DIRITTO 5/16" 24 UNIF-D6	5
32	08543045	LONG SLEEVE F-F M10-1/8"G	2
33	08543046	BRUSH D20 H50+PROTEZIONE	4
34	08543047	BLOCK 5/16" 24UNF 2+1 V	1
35	08543050	PUMP PS-R A ECCENTRIC CONTROL	1
36	08543052	VALVE DOS. N°2 5/16" 24 UNF-D4	3
37	08543053	VALVE DOS. N°3 5/16" 24UNF-D4	1
38	50003250	SHORT SPACER BRUSH	2
39	50003251	LONG SPACER BRUSH	1
40	50003252	CAM PS-R ZB	1

S.N.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL