


MASCAR

Spare parts catalogue



Precision planter
MAXI 5.1 "S3" F.18

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Pos.	Code	Description	Quantity
1	020.204	SCREW TE M14X 70 8.8 5737 ZB	6
2	020.261	SCREW TE M 16X140 8.8 5737 ZB	1
3	020.263	SCREW TE M 16X80 8.8 5737 ZB	1
4	021.120	SELFBLOCKING NUT M 14 7473 ZB	6
5	021.123	SELFBLOCKING NUT M 14 7473 ZB	2
6	023.035	FLAT WASHER M14=15 X28X2,5 6592 ZB	6
7	023.045	FLAT WASHER M16=17X30X3 6592 ZB	4
8	024.010	CLICK PIN D. 10 B=60 ZG	2
9	024.346	ELASTIC PIN D. 6X50 6873 NE	2
10	024.348	ELASTIC PIN D. 6X22 6873 NE	1
11	040.006	RUBBER WHEEL 10.0/75-15.3 6F 10 PR	1
12	10000016		1
13	10000032		1
14	10010240		1
15	10010242		1
16	10010260		1
17	10010262		1
18	10010266		1
19	10046170	CULINDER TUFFANTE VE.NERO	1

S.N.

Pos.	Code	Description	Quantity
1	028.022	SEEGER RING I D. 72 7437/742	2
2	028.110	SEEGER RING E D. 30 7435/471	1
3	050.111	BEARING 6306-2RS C3 (1° QUALITY)	2
4	10023220	P.T.O. SHAFT	1
5	10023221	SHAFT SPACER PTO ZB	1
6	10033101	COMP.S. TURBINE SUPPORT VIR	1

S.N.

Pos.	Code	Description	Quantity
1	019.135	SCREW TE M 4X 35 8.8 5739 ZB	1
2	020.010	SCREW TE M 6X10 8.8 5739 ZB	1
3	020.213	SCREW TE M14X200 8.8 5737 ZB	2
4	020.601	SCREW TTQST M 8X 25 4.6 5731 ZB	8
5	020.656	SCREW TSPEI M 6X 12 10.9 5933 NE	1
6	021.099	SELFBLOCKING NUT M 4 7473 ZB	1
7	021.102	SELFBLOCKING NUT M 8 7474 ZB	9
8	021.120	SELFBLOCKING NUT M 14 7473 ZB	2
9	023.005	FLAT WASHER M 6= 6,6X18X2 6593 ZB	1
10	023.007	FLAT WASHER M 4= 4,3X 9X0,8 6592 ZB	2
11	023.020	FLAT WASHER M 8=8,4X16X1,6 6592 ZB	8
12	023.035	FLAT WASHER M14=15 X28X2,5 6592 ZB	4
13	023.045	FLAT WASHER M16=17X30X3 6592 ZB	1
14	023.756	WASHER EL.SHAFT D.6	2
15	023.829	RIVET ALL. 3.8X12-4X12	3
16	024.227	COVER D.4 X 30 ZB 1336	1
17	051.100	SUPPORT 205 KRRB AH 02- PFL205	2
18	095.001	HABD WGEEK NAKE M8X15 TECNOPOLIM	1
19	095.095	COMPLETE RUBBER TIE-ROD (GAMM)	1
20	10002701	MOBILE PIN ZB	1
21	10002714	COMP.S.BUSHING WITH 3 PINIONS ZB	1
22	10002718	CHAIN 5/8"X3/8" 49 LINKS+JOINT	1
23	10002760	COMP.S.ASS.TENDICHAIN CAMBIO VIR	1
24	10012724	COVER BOX	1
25	10012726	PIVOT SHAFT	1
26	10012740		1
27	10022707	COMP.S. BUSHING WITH 6 PINIONS ZB	1
28	10022730	COMP. M. FLANGE PFL 205 +BEAR. EX.19,1	2
29	10022735	SUPPORT SHIMING FLANGE ZB	3
30	10022738	COMP.S. GEAR CHAIN TIGHTNER LEVER ZB	1
31	10022740		1
32	30031340	SPRING A TRAZIONE 3,2X21X160 ZBD	1

S.N.

Pos.	Code	Description	Quantity
1	020.243	SCREW TE M 14X50 8.8 5739 ZB	36
2	021.120	SELFBLOCKING NUT M 14 7473 ZB	60
3	021.123	SELFBLOCKING NUT M 14 7473 ZB	24
4	023.035	FLAT WASHER M14=15 X28X2,5 6592 ZB	60
5	023.045	FLAT WASHER M16=17X30X3 6592 ZB	24
6	10000185		4
7	10011030		24
8	10017102	FRONT LINKAGE	20
9	10030330	SCREW TE M16X220 12.9 5737 ZB	24
10	30061042		12
11	30061043		6

S.N.

Pos.	Code	Description	Quantity
79	30031618	SPRING TIGHTENER ZB	1
80	30031624	PULLEY Z=12 1/2" X 3/16 PA 6	1
81	30031638	CHAIN 118 STEP 083-1 (1/2"X 3/16")	1
82	30031640		1
83	30031648		1
84	30031670	ANTERIOR CASE MAXI-5 VER	1
85	30031672		1
86	30031674		1
87	30031676		1
88	30031715	WHEEL EXCLUSIO PLATE ZB	2
89	30031720	COMPENSATORE BUSH ZB	4

S.N.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Pos.	Code	Description	Quantity
1	020.011	SCREW TE M6X16 8.8 5739 ZB	2
2	020.013	SCREW TE M6X25 8.8 5739 ZB	1
3	020.072	SCREW TE M 5X8 8.8 5739 ZB	2
4	020.490	SCREW TCEI M 4X16 8.8 5931 ZB	4
5	020.656	SCREW TSPEI M 6X 12 10.9 5933 NE	1
6	023.005	FLAT WASHER M 6= 6,6X18X2 6593 ZB	1
7	023.010	FLAT WASCHER M6=6,3X12X1,6 6592 ZB	1
8	023.921	RIVET TC UNI 9201-A M6-8	2
9	023.925	RIVET TC UNI 9201-B M6-8	1
10	028.095	SEEGER RING E D. 6 7435/471	1
11	046.026	RING OR 2025	1
12	10004128	SPRING D.9,6X20 ZB	1
13	10004602		1
14	10004611	DISTRIBUTOR OPENING PVC-CRYSTAL	1
15	10004612		1
16	10004624	DISTRIBUTOR BRUSH 5,2 X 25 L=168	1
17	10004625		1
18	10004626		4
19	10004627		1
20	10004629		1
21	10004637	DRILLED FRONT CLOSURE PETG	1
22	10004640		1
23	10004652		1
24	10004657		1
25	10004660	EJECTOR SEED REMOVER PA6	1
26	10004664		1
27	10004666		1
28	10004671		1
29	10034139	WINDOW BUSH INSPECTION D. 6 - M4 INOX	1
30	30001176		1
31	30001177		1

S.N.

Pos.	Code	Description	Quantity
1	020.013	SCREW TE M6X25 8.8 5739 ZB	2
2	020.100	SCREW TE M10X 20 8.8 5739 ZB	2
3	020.115	SCREW TE M 10X40 8.8 5737 ZB	3
4	021.112	SELFBLOCKING NUT M 10 7473 ZB	3
5	021.115	SELFBLOCKING NUT M 6 7473 ZB	2
6	023.030	FLAT WASHER M10=10,5X20X2 6592 ZB	3
7	10031620	COMP.S. PLOUGH SHARE "170"	1
8	10031622	ADJUSTABLE KNIFE BLADE V.3 VER	1
9	30031425	COMP.S.PLOUGH SHARE SUPPORT MAXI 15MM V.	1

S.N.

Pos.	Code	Description	Quantity
1	020.050	SCREW TE M 8X16 8.8 5739 ZB	2
2	022.001	GREASE DEVICE M 6X1 UNI 7663A DIR.ZB	1
3	023.020	FLAT WASCHER M 8=8,4X16X1,6 6592 ZB	2
4	023.301	GROWER WASHER A M8-D. 8,4 1751 ZBD	2
5	028.306	RING "PS" 16X22X1 DIN 988	2
6	30001098		1
7	30031068	SCRAPER PLATE L=60 ZB	1
8	30031134		1
9	30031138		1

S.N.

Pos.	Code	Description	Quantity
1	020.066	SCREW TE M 8X30 8.8 5737 ZB	2
2	021.114	SELFBLOCKING NUT M 8 7473 ZB	2
3	023.020	FLAT WASCHER M 8=8,4X16X1,6 6592 ZB	2
4	076.679	ELETTOVALVE ROWS EXCLUSION + 2 MAN.	1
5	083.601	PIPE WIND WITH SPIRAL PVC DI.40	1
6	30031434		2
7	30031452		1

S.N.

Pos.	Code	Description	Quantity
1	020.011	SCREW TE M6X16 8.8 5739 ZB	1
2	020.100	SCREW TE M10X 20 8.8 5739 ZB	1
3	020.601	SCREW TTQST M 8X 25 4.6 5731 ZB	4
4	021.114	SELFBLOCKING NUT M 8 7473 ZB	4
5	021.406	SELFBLOCKING NUT M 6 7473 INOX	18
6	021.816	SCREW TE M 6X20 8.8 5739 A2.70 INOX	18
7	022.706	FLAT WASHER M6=6,3X12X1,6 6592 INOX	18
8	023.005	FLAT WASHER M 6= 6,6X18X2 6593 ZB	1
9	023.020	FLAT WASHER M 8=8,4X16X1,6 6592 ZB	4
10	023.027	FLAT WASHER M 10=11 X30X2,5 6593 ZB	1
11	024.236	COVER D.5 X32 ZB 1336	2
12	024.335	ELASTIC PIN D.6X35 6873 INOX	2
13	024.344	ELASTIC PIN D.6X30 6873 NE	1
14	028.009	SEEGER RING I D.52 7437/472	1
15	028.108	SEEGER RING E D. 25 7435/471	2
16	050.010	BEARING 6205-2RS	1
17	051.101	BEARING WITH PLATE FLANGE PFL205 ZB	1
18	10022567		1
19	10022568		1
20	10027116		2
21	10027126		1
22	10027132		1
23	10027134		1
24	10027192		1
25	10027206	COMP.M. FERTILIZER DITRIBUTOR D.40	3
26	10027278	BODY JOINT BUSHING ZB	2
27	10039722	LABEL.S. FERTILISER TABLE (BIG SPIRAL)	1
28	89003021	LABEL.S. "MASCAR 2C" 9X60 (B)	2

S.N.

Pos.	Code	Description	Quantity
1	021.113	SELFBLOCKING NUT M 12 7473 ZB	2
2	023.040	FLAT WASHER M12=13 X24X2,5 6592 ZB	2
3	10027947		1
4	47002133		1

S.N.

Pos.	Code	Description	Quantity
1	023.842	RIVET FE TT D.6X16 UNI 748	6
2	050.105	BEARING 3204-2RS1	1
3	050.500	RING NILOS JV 6204	1
4	10037604	COULTER DISC D.354-S.3(27.8)VEN	1
5	30031204	DISC HUB	1

S.N.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL