

MODEL
R2H-2

ENGINE KUBOTA V3307-DI (No.60101~)

3-WHEEL ROLLER

SAKAI®

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

×毛 ---memo---

05吸気装置
1R5 60101 ~ 99999

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	4422-22000-0	エアクリーナ	AIR CLEANER	1	INC.2 3 11
2	4422-22002-0	エレメント	ELEMENT	1	INNER
3	4422-22003-0	エレメント	ELEMENT	1	OUTER
4	4411-18000-0	キャップ	CAP	1	
5	2100-08025-1	ボルト	BOLT	2	
6	2170-08016-0	ワッシャ	WASHER	2	
7	2171-08020-0	スプリングワッシャ	SPRING WASHER	2	
8	2291-00060-0	ホースバンド	HOSE CLAMP	1	
9	1634-04012-0	ホース	HOSE	1	
10	2291-00075-0	ホースバンド	HOSE CLAMP	1	
11	4400-84007-0	インジケータ	INDICATOR	1	
12	2100-08020-1	ボルト	BOLT	2	
13	2170-08016-0	ワッシャ	WASHER	2	
14	2171-08020-0	スプリングワッシャ	SPRING WASHER	2	
15	3100-05076-0	ボルト	BOLT	1	
16	2170-08016-0	ワッシャ	WASHER	1	
17	2171-08020-0	スプリングワッシャ	SPRING WASHER	1	
18	1634-04010-0	スペーサ	SPACER	1	
19	1634-04011-0	ブラケット	BRACKET	1	
20	4422-22004-0	カバー	COVER	1	
21	4419-42005-0	バキューエータバルブ	VACUATOR VALVE	1	

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	2215-14001-0	プラグ	PLUG	2	
2	2501-06318-4	ボールベアリング	BALL BEARING	1	
3	2100-16050-3	ボルト	BOLT	8	
4	2170-16045-2	ワッシャー	WASHER	8	
5	2100-12040-1	ボルト	BOLT	2	
6	2171-12030-0	スプリングワッシャー	SPRING WASHER	2	
7	3952-15026-0	エンドプレート	END PLATE	1	
8	2194-19040-1	C-スナップリング	RETAINING RING	1	
9	1630-27004-0	ケース	CASE	1	
10	1634-27001-1	ロール	ROLL	1	
11	2100-20070-3	ボルト	BOLT	16	
12	2170-20060-2	ワッシャー	WASHER	16	
13	2100-20060-3	ボルト	BOLT	16	
14	2170-20060-2	ワッシャー	WASHER	16	
15	2100-20060-3	ボルト	BOLT	11	
16	2170-20060-2	ワッシャー	WASHER	11	
17	1634-27002-0	プレート	PLATE	1	

14油圧装置(70ドライブ)

1R5 60101 ~ 99999

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	4216-01000-0	モータ	MOTOR	1	
2	2100-16060-3	ボルト	BOLT	16	
3	2170-16045-2	ワッシャ	WASHER	16	
4	2265-06006-3	アダプタ	ADAPTER	1	INC.5
5	2630-02024-0	リング	O-RING	1	
6	2341-14206-7	ホース	HOSE	1	
7	2341-11060-7	ホース	HOSE	1	
8	2341-11046-7	ホース	HOSE	1	
9	2261-03003-2	アダプタ	ADAPTER	1	
10	3380-01019-0	バルブ	VALVE	1	
11	3417-04006-1	Uボルト	U-BOLT	1	
12	2170-08016-0	ワッシャ	WASHER	2	
13	2120-08065-0	ナット	NUT	2	
14	2261-03003-2	アダプタ	ADAPTER	1	
15	4216-01000-0	モータ	MOTOR	1	
16	2100-16060-3	ボルト	BOLT	16	
17	2170-16045-2	ワッシャ	WASHER	16	
18	2265-06006-6	アダプタ	ADAPTER	1	INC.19
19	2630-02024-0	リング	O-RING	1	
20	2341-14235-7	ホース	HOSE	1	
21	2341-24072-7	ホース	HOSE	1	
22	2265-06006-3	アダプタ	ADAPTER	1	INC.23
23	2630-02024-0	リング	O-RING	1	
24	2341-24065-7	ホース	HOSE	1	
25	2265-06006-3	アダプタ	ADAPTER	1	INC.26
26	2630-02024-0	リング	O-RING	1	
27	1402-36007-0	ブロック	BLOCK	1	
28	2109-11063-4	ボルト	BOLT	4	
29	2631-02024-0	リング	O-RING	1	
30	2265-03003-3	アダプタ	ADAPTER	1	INC.31
31	2630-02014-0	リング	O-RING	1	
32	2341-12074-7	ホース	HOSE	2	
33	1634-36018-0	ブロック	BLOCK	1	
34	2109-11076-4	ワッシャ ナット ボルト	BOLT	4	
35	2631-02024-0	リング	O-RING	1	
36	2265-03003-6	アダプタ	ADAPTER	1	INC.37
37	2630-02014-0	リング	O-RING	1	
38	2265-06006-2	アダプタ	ADAPTER	1	INC.39
39	2630-02024-0	リング	O-RING	1	

17油圧装置(リヤドライブ)
1R5 60101 ~ 99999

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	2265-04004-3	アダプタ	ADAPTER	1	INC.2
2	2630-02018-0	Oリング	O-RING	1	
3	2265-02002-3	アダプタ	ADAPTER	1	INC.4
4	2630-02011-0	Oリング	O-RING	1	
5	2265-02002-3	アダプタ	ADAPTER	1	INC.6
6	2630-02011-0	Oリング	O-RING	1	
7	1634-36001-0	クランプ	CLAMP	1	
8	1634-36002-0	クランプ	CLAMP	1	
9	1630-36031-0	シム	SHIM	1	
10	2100-10060-1	ボルト	BOLT	2	
11	2171-10025-0	スプリングワッシャー	SPRING WASHER	2	
12	2100-08040-1	ボルト	BOLT	2	
13	2171-08020-0	スプリングワッシャー	SPRING WASHER	2	
14	1634-36004-0	パイプ	PIPE	1	
15	1632-36007-0	パイプ	PIPE	1	
16	1632-36006-0	パイプ	PIPE	1	
17	1632-36004-0	パイプ	PIPE	1	
18	1632-36005-0	パイプ	PIPE	1	
19	2341-12130-1	ホース	HOSE	1	
20	2341-10130-1	ホース	HOSE	1	
21	1630-36022-0	クランプ	CLAMP	1	
22	1634-36003-0	クランプ	CLAMP	1	
23	2100-10060-1	ボルト	BOLT	2	
24	2171-10025-0	スプリングワッシャー	SPRING WASHER	2	
25	2341-10154-1	ホース	HOSE	1	
26	2341-14110-7	ホース	HOSE	2	
27	2265-06006-6	アダプタ	ADAPTER	2	INC.28
28	2630-02024-0	Oリング	O-RING	2	
29	2100-10070-1	ボルト	BOLT	2	
30	2171-10025-0	スプリングワッシャー	SPRING WASHER	2	
31	2100-08040-1	ボルト	BOLT	2	
32	2171-08020-0	スプリングワッシャー	SPRING WASHER	2	
33	1634-36001-0	クランプ	CLAMP	1	
34	1634-36002-0	クランプ	CLAMP	1	
35	1630-36031-0	シム	SHIM	1	
36	4222-77000-0	モータ	MOTOR	1	

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	1630-61034-0	カバー	COVER	1	
2	2100-10020-1	ボルト	BOLT	4	
3	2170-10020-0	ワッシャ	WASHER	4	
4	1634-61199-0	フレ-ム	FRAME	1	
5	1634-61063-0	カバー	COVER	1	
6	2100-10020-1	ボルト	BOLT	6	
7	2170-10020-0	ワッシャ	WASHER	6	
8	1634-61065-0	カバー	COVER	1	
9	2100-10020-1	ボルト	BOLT	6	
10	2170-10020-0	ワッシャ	WASHER	6	
11	1634-61071-0	カバー	COVER	1	
12	2100-10020-1	ボルト	BOLT	3	
13	2170-10020-0	ワッシャ	WASHER	3	
14	4703-61000-0	ハトメ	DRAG	2	
15	3156-23030-0	ピン	PIN	1	
16	2157-50045-0	ワリピン	SPLIT PIN	1	
17	1402-61047-1	ア-ム	ARM	1	
18	1402-61056-0	ロックピン	LOCK PIN	1	
19	3956-00004-0	Rピン	R-PIN	1	
20	1634-61066-0	カバー	COVER	1	
21	2100-10020-1	ボルト	BOLT	4	
22	2170-10020-0	ワッシャ	WASHER	4	
23	2100-10020-1	ボルト	BOLT	3	
24	2170-10020-0	ワッシャ	WASHER	3	
25	1634-61068-0	カバー	COVER	1	

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	4712-33000-0	シート	SEAT	2	
2	2100-08020-3	ボルト	BOLT	8	
3	2170-08016-1	ワッシャ	WASHER	8	
4	2171-08020-0	スプリングワッシャ	SPRING WASHER	8	
5	2120-08065-1	ナット	NUT	8	
6	4713-15000-0	シートベルト	SEAT BELT	2	

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	2100-12030-1	ボルト	BOLT	4	
2	2170-12032-2	ワッシャ	WASHER	4	
3	2100-12040-1	ボルト	BOLT	4	
4	2170-12032-2	ワッシャ	WASHER	8	
5	2120-12100-0	ナット	NUT	4	
6	1634-71014-0	ブラケット	BRACKET	2	
7	2100-12030-1	ボルト	BOLT	4	
8	2170-12032-2	ワッシャ	WASHER	4	
9	3100-02062-0	ボルト	BOLT	4	
10	2120-10080-0	ナット	NUT	4	
11	1634-71002-0	ブラケット	BRACKET	1	
12	1634-71004-1	ブラケット	BRACKET	1	
13	1634-71012-0	ブレード	BLADE	1	
14	2100-10030-1	ボルト	BOLT	4	
15	2120-10080-0	ナット	NUT	4	
16	1634-71015-0	ブラケット	BRACKET	1	
17	1634-71003-0	ブラケット	BRACKET	1	
18	1634-71012-0	ブレード	BLADE	1	
19	2100-10030-1	ボルト	BOLT	4	
20	2120-10080-0	ナット	NUT	4	
21	3910-04014-0	スプリング	SPRING	2	
22	2100-10035-1	ボルト	BOLT	6	
23	2171-10025-0	スプリングワッシャ	SPRING WASHER	6	
24	2120-10080-0	ナット	NUT	6	
25	1632-71077-0	プレート	PLATE	2	
26	3910-04014-0	スプリング	SPRING	2	
27	2100-10035-1	ボルト	BOLT	6	
28	2171-10025-0	スプリングワッシャ	SPRING WASHER	6	
29	2120-10080-0	ナット	NUT	6	
30	1632-71077-0	プレート	PLATE	2	
31	2171-12030-0	スプリングワッシャ	SPRING WASHER	4	
32	2120-12100-0	ナット	NUT	4	
33	1632-71138-0	弁-	COLLAR	4	
34	2100-12045-1	ボルト	BOLT	4	
35	2293-12002-2	ホース	HOSE	4	

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	4710-37000-0	プラグ	PLUG	2	
2	2834-12002-0	ライセンスランプ	LICENCE LAMP	1	
3	4911-24000-0	ヘッドランプ	HEAD LAMP	2	
4	4706-87000-0	ミラー	MIRROR	2	
5	1634-09022-0	ステー	STAY	1	
6	2170-12025-0	ワッシャー	WASHER	1	
7	3120-01083-0	ナット	NUT	1	
8	4915-16000-0	コンビネーションランプ	COMBINATION LAMP	2	
9	4911-83000-0	ミラー	MIRROR	2	
10	1634-09023-0	ステー(R)	STAY(R)	1	
11	2100-10020-1	ボルト	BOLT	2	
12	2170-10020-0	ワッシャー	WASHER	2	
13	4915-19000-0	ヘッドランプ	HEAD LAMP	2	
14	2170-14025-0	ワッシャー	WASHER	2	
15	1634-09021-0	ステー	STAY	1	
16	2170-12025-0	ワッシャー	WASHER	1	
17	3120-01083-0	ナット	NUT	1	
18	1634-09024-0	ステー(L)	STAY(L)	1	
19	2100-10020-1	ボルト	BOLT	2	
20	2170-10020-0	ワッシャー	WASHER	2	
21	4911-24000-0	ヘッドランプ	HEAD LAMP	2	
22	4915-17000-0	コンビネーションランプ	COMBINATION LAMP	1	
23	4913-74000-0	リフレクタ	REFLECTOR	2	
24	2171-06015-0	スプリングワッシャー	SPRING WASHER	2	
25	2170-06016-0	ワッシャー	WASHER	2	
26	2120-06050-0	ナット	NUT	2	
27	1634-09044-0	ブラケット	BRACKET	1	
28	2100-08012-1	ボルト	BOLT	4	
29	2171-08020-0	スプリングワッシャー	SPRING WASHER	4	
30	2170-08016-0	ワッシャー	WASHER	4	
31	4915-18000-0	コンビネーションランプ	COMBINATION LAMP	1	
32	2100-08012-1	ボルト	BOLT	1	
33	2171-08020-0	スプリングワッシャー	SPRING WASHER	1	
34	2170-08016-0	ワッシャー	WASHER	1	
35	2100-08016-1	ボルト	BOLT	1	
36	2171-08020-0	スプリングワッシャー	SPRING WASHER	1	
37	2170-08016-0	ワッシャー	WASHER	1	
38	4908-86000-0	ホーン	HORN	1	
39	2100-08020-1	ボルト	BOLT	1	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL