



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

燃料関係 FUEL SYSTEM

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	1406-02004-0	カバー	COVER	1	
2	1406-02006-0	パッキン	PACKING	2	
3	3100-00064-0	ボルト	BOLT	16	
4	2170-10020-0	ワッシャ	WASHER	16	
5	2898-00007-0	バンド	BAND	2	
6	1406-02001-0	カバー	COVER	1	
7	2100-10014-1	ボルト	BOLT	2	
8	2171-10025-0	スプリングワッシャ	SPRING WASHER	2	
9	4417-05000-0	フューエルユニット	FUEL GAUGE UNIT	1	
10	2182-05010-3	ナベコネジ	SCREW	5	
11	2171-05013-0	スプリングワッシャ	SPRING WASHER	5	
12	1406-02005-0	カバー	COVER	1	
13	4416-66001-0	フィラーキャップ	FILLER CAP	1	
14	4400-03002-0	ストレーナ	STRAINER	1	
15	3215-02011-0	プラグ	PLUG	1	
16	3680-11021-0	パッキン	PACKING	1	
17	2291-00016-0	ホースバンド	HOSE CLAMP	4	
18	3416-02002-0	クランプ	CLAMP	2	
19	2100-08012-1	ボルト	BOLT	2	
20	2170-08016-0	ワッシャ	WASHER	2	
21	3416-02001-1	クランプ	CLAMP	1	
22	2100-08012-1	ボルト	BOLT	1	
23	2170-08016-0	ワッシャ	WASHER	1	
24	2293-09164-5	ホース	HOSE	1	
25	2293-09124-5	ホース	HOSE	1	
26	2898-20070-5	スパイラルチューブ	SPIRAL TUBE	2	
27	2292-06200-0	ホースニップル	HOSE NIPPLE	2	
28	2291-00032-0	ホースバンド	HOSE CLAMP	2	
29	2298-19060-1	ホース	HOSE	1	

コントロール関係 (前後進) CONTROL SYSTEM (REVERSING)

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	2552-00204-0	ベアリングユニット	BEARING UNIT	1	
2	2100-10040-1	ボルト	BOLT	2	
3	2170-10020-0	ワッシャ	WASHER	2	
4	2120-10080-0	ナット	NUT	2	
5	3180-20020-0	コネジ	SCREW	4	
6	1406-12017-0	シャフト	SHAFT	1	
7	3400-32023-0	コントロールケーブル	CONTROL CABLE	1	INC. 8
8	2120-06050-0	ナット	NUT	2	
9	3404-20015-0	ロッドエンド	ROD END	1	
10	2100-06025-1	ボルト	BOLT	1	
11	2170-06016-0	ワッシャ	WASHER	1	
12	2580-06006-1	ブッシュ	BUSH	1	
13	3120-00070-0	ナット	NUT	1	
14	2100-08020-1	ボルト	BOLT	4	
15	2170-08020-1	ワッシャ	WASHER	4	
16	1406-12016-0	カバー	COVER	1	
17	2100-10020-1	ボルト	BOLT	3	
18	2170-10020-0	ワッシャ	WASHER	3	
19	4416-57000-0	グリップ	GRIP	1	
20	3180-20023-0	コネジ	SCREW	2	
21	1402-19001-0	ネームプレート	NAME PLATE	1	
22	2156-06030-0	ピン	PIN	1	
23	2170-06016-0	ワッシャ	WASHER	1	
24	2157-20015-0	ワリピン	SPLIT PIN	1	
25	3403-01017-0	クレビス	CLEVIS	1	
26	3171-93007-0	ワッシャ	WASHER	2	
27	2580-20025-1	ブッシュ	BUSH	2	
28	1406-12014-0	ブラケット	BRACKET	1	
29	2100-16030-1	ボルト	BOLT	1	
30	2120-16130-0	ナット	NUT	1	
31	3910-21001-0	スプリング	SPRING	1	
32	2170-06016-0	ワッシャ	WASHER	1	
33	2598-18000-0	スチールボール	STEEL BALL	1	
34	2170-20030-0	ワッシャ	WASHER	1	
35	2120-20160-0	ナット	NUT	2	
36	2196-06025-1	キー	SUNK KEY	1	
37	1406-12015-0	レバー	LEVER	1	
38	3823-20004-0	マイクロスイッチ	MICRO SWITCH	2	

—MEMO—

油 圧 装 置 (フロントドライブ) HYDRAULIC SYSTEM (FRONT DRIVE)

記 号 Key No.	部品番号 Parts No.	部 品 名 称	Parts Name	数量 Q'ty	備 考 Remarks
1	4209-19000-0	モータ	MOTOR	1	
2	2265-22004-0	アダプタ	ADAPTER	1	INC. 3
3	2632-00010-0	Oリング	O-RING	1	
4	2265-22004-0	アダプタ	ADAPTER	1	INC. 5
5	2632-00010-0	Oリング	O-RING	1	
6	2265-19003-1	アダプタ	ADAPTER	1	INC. 7
7	2632-00008-0	Oリング	O-RING	1	
8	2301-12208-7	ホース	HOSE	1	1/2, L=2080, 27.5MPa
9	4216-86000-0	ホース	HOSE	1	1/2, L=2120, 27.5MPa
10	4216-87000-0	ホース	HOSE	1	3/8, L=2030, 7.0MPa
11	2265-04004-2	アダプタ	ADAPTER	1	INC. 12
12	2630-02018-0	Oリング	O-RING	1	
13	2100-10050-1	ボルト	BOLT	2	
14	2170-10020-0	ワッシャ	WASHER	2	
15	1406-36019-0	クランプ	CLAMP	3	
16	3934-12065-0	クランプ	CLAMP	3	
17	2100-10020-1	ボルト	BOLT	4	
18	2170-10020-0	ワッシャ	WASHER	4	
19	2100-10060-1	ボルト	BOLT	4	
20	2170-10020-0	ワッシャ	WASHER	4	
21	3120-01073-0	ナット	NUT	4	
22	1406-36016-0	ブラケット	BRACKET	2	

油 圧 装 置 (振 動)

HYDRAULIC SYSTEM (VIBRATING)

記 号 Key No.	部品番号 Parts No.	部 品 名 称	Parts Name	数量 Q'ty	備 考 Remarks
1	2265-04004-2	アダプタ	ADAPTER	2	INC. 2
2	2630-02018-0	Oリング	O-RING	2	
3	3260-26025-0	アダプタ	ADAPTER	1	INC. 4
4	2630-02018-0	Oリング	O-RING	1	
5	4212-09000-0	モータ	MOTOR	1	
6	2100-10050-1	ボルト	BOLT	2	
7	2170-10020-0	ワッシャ	WASHER	2	
8	1406-36016-0	ブラケット	BRACKET	2	
9	1406-36019-0	クランプ	CLAMP	3	
10	3934-12065-0	クランプ	CLAMP	3	
11	4216-85000-0	ホース	HOSE	1	1/2, L=2240, 17.0MPa
12	4216-89000-0	ホース	HOSE	1	1/2, L=2180, 17.0MPa
13	4216-88000-0	ホース	HOSE	1	3/8, L=2070, 7.0MPa
14	2701-31066-2	ホース	HOSE	1	3/8, L=660, 7.0MPa
15	2701-32080-5	ホース	HOSE	1	1/2, L=800, 17.0MPa
16	2701-12067-5	ホース	HOSE	1	1/2, L=670, 17.0MPa
17	3291-12013-0	クランプ	CLAMP	2	
18	2300-16197-1	ホース	HOSE	1	1 1/4, L=1970, 3.5MPa
19	2265-06006-2	アダプタ	ADAPTER	1	INC. 20
20	2630-02024-0	Oリング	O-RING	1	
21	2301-14074-1	ホース	HOSE	1	3/4, L=740, 3.5MPa
22	3260-32065-0	アダプタ	ADAPTER	2	INC. 23
23	2630-02029-0	Oリング	O-RING	2	
24	3260-32130-0	アダプタ	ADAPTER	1	INC. 25
25	2630-02029-0	Oリング	O-RING	1	
26	2701-12151-5	ホース	HOSE	1	1/2, L=1510, 17.0MPa
27	2265-04004-6	アダプタ	ADAPTER	1	INC. 28
28	2630-02018-0	Oリング	O-RING	1	
29	3260-22006-0	アダプタ	ADAPTER	1	INC. 30
30	2630-02024-0	Oリング	O-RING	1	
31	2100-10070-1	ボルト	BOLT	2	
32	2170-10020-0	ワッシャ	WASHER	2	
33	3260-32110-0	アダプタ	ADAPTER	1	INC. 34
34	2630-02024-0	Oリング	O-RING	1	
35	4211-48000-1	バルブ	VALVE	1	
36	2701-14060-1	ホース	HOSE	1	3/4, L=600, 3.5MPa
37	2215-06001-2	プラグ	PLUG	1	INC. 38
38	2630-02024-0	Oリング	O-RING	1	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

—MEMO—

振 動 口 ー ル VIBRATING ROLL

記 号 Key No.	部品番号 Parts No.	部 品 名 称	Parts Name	数量 Q'ty	備 考 Remarks
1	1406-43701-0	ロール	ROLL	1	
2	2100-12030-3	ボルト	BOLT	16	
3	2171-12036-1	スプリングワッシャ	SPRING WASHER	16	
4	2100-12070-3	ボルト	BOLT	16	
5	2170-12032-2	ワッシャ	WASHER	16	
6	2171-12036-1	スプリングワッシャ	SPRING WASHER	16	
7	2120-12100-2	ナット	NUT	16	
8	1533-43018-0	ダンパ	DAMPER	4	
9	2100-16045-3	ボルト	BOLT	12	
10	2170-16045-2	ワッシャ	WASHER	12	
11	1406-43005-0	ディスク	DISC	1	
12	2100-16050-3	ボルト	BOLT	16	
13	2170-16045-2	ワッシャ	WASHER	16	
14	2630-01270-1	Oリング	O-RING	1	
15	2100-16050-3	ボルト	BOLT	12	
16	2170-16045-2	ワッシャ	WASHER	12	
17	3630-18037-0	Oリング	O-RING	1	
18	1406-43002-0	ホルダ	HOLDER	1	
19	3511-42027-0	ローラベアリング	ROLLER BEARING	1	
20	1406-43018-0	シャフト	SHAFT	1	
21	3511-42027-0	ローラベアリング	ROLLER BEARING	1	
22	1406-43003-0	アクスルシャフト	AXLE SHAFT	1	
23	3630-18037-0	Oリング	O-RING	1	
24	2100-16050-3	ボルト	BOLT	12	
25	2170-16045-2	ワッシャ	WASHER	12	
26	2215-06001-2	プラグ	PLUG	2	INC. 27
27	2630-02024-0	Oリング	O-RING	2	
28	2603-04581-0	オイル シール	OIL SEAL	1	
29	2513-32020-2	ローラベアリング	ROLLER BEARING	2	
30	2932-00120-0	シム	SHIM	1	
31	2630-02145-1	Oリング	O-RING	1	
32	1406-43004-0	アクスル	AXLE	1	
33	2100-12030-3	ボルト	BOLT	8	
34	2171-12036-1	スプリングワッシャ	SPRING WASHER	8	
35	2100-12070-3	ボルト	BOLT	8	
36	2170-12032-2	ワッシャ	WASHER	8	
37	2171-12036-1	スプリングワッシャ	SPRING WASHER	8	
38	2120-12100-2	ナット	NUT	8	

フロントフレーム FRONT FRAME

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	2100-20100-3	ボルト	BOLT	6	
2	2170-20060-2	ワッシャ	WASHER	12	
3	2120-20160-2	ナット	NUT	6	
4	1406-61094-0	クロスメンバ	CROSS MEMBER	1	
5	1406-61005-0	フレーム	FRAME	1	
6	2100-08020-1	ボルト	BOLT	1	
7	2170-08016-0	ワッシャ	WASHER	2	
8	3956-00006-0	Rピン	R-PIN	1	
9	1536-61051-1	ピン	PIN	1	

フレーム (センターピン) FRAME (CENTER PIN)

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	2100-20070-3	ボルト	BOLT	4	
2	2170-20060-2	ワッシャ	WASHER	4	
3	1406-61031-0	ブラケット	BRACKET	1	
4	2472-01002-0	グリースニップル	GREASE NIPPLE	1	
5	2100-16060-3	ボルト	BOLT	12	
6	2170-16045-2	ワッシャ	WASHER	12	
7	1406-61032-0	ブラケット	BRACKET	1	
8	2215-01002-3	アナツキ プラグ	PLUG	1	
9	2100-20070-3	ボルト	BOLT	4	
10	2170-20060-2	ワッシャ	WASHER	4	
11	1406-61001-0	ヨーク	YOKE	1	
12	4417-63000-0	ベアリング	BEARING	1	
13	2100-16060-3	ボルト	BOLT	11	
14	2170-16045-2	ワッシャ	WASHER	11	
15	4419-07000-0	カバー	COVER	1	
16	2501-06214-4	ボール ベアリング	BALL BEARING	2	
17	2215-01002-3	アナツキ プラグ	PLUG	1	
18	4216-00000-0	プラグ	PLUG	1	
19	4419-07000-0	カバー	COVER	1	
20	2501-06214-4	ボール ベアリング	BALL BEARING	2	
21	2215-01002-3	アナツキ プラグ	PLUG	1	

レベリングブレード LEVERING BLADE

記号 Key No.	部品番号 Parts No.	部品名称	Parts Name	数量 Q'ty	備考 Remarks
1	3931-12115-0	カラー	COLLAR	2	
2	2472-01001-0	グリースニップル	GREASE NIPPLE	1	
3	1406-47003-0	ピン	PIN	1	
4	2100-10020-1	ボルト	BOLT	2	
5	2171-10025-0	スプリングワッシャ	SPRING WASHER	2	
6	3934-02678-0	プレート	PLATE	1	
7	3934-02674-0	プレート	PLATE	1	
8	2100-10020-1	ボルト	BOLT	2	
9	2171-10025-0	スプリングワッシャ	SPRING WASHER	2	
10	1406-47504-0	ピン	PIN	1	
11	2472-01001-0	グリースニップル	GREASE NIPPLE	1	
12	3931-12115-0	カラー	COLLAR	2	
13	2100-12020-1	ボルト	BOLT	2	
14	2171-12030-0	スプリングワッシャ	SPRING WASHER	2	
15	2472-01001-0	グリースニップル	GREASE NIPPLE	2	
16	1406-47502-0	ピン	PIN	2	
17	2194-05520-4	C-スナップリング	C-RETAINING RING	2	
18	2541-00035-2	スフェリカルベアリング	SPHERICAL BEARING	2	
19	1406-47001-0	ブレード	BLADE	1	
20	2100-16050-3	ボルト	BOLT	4	
21	2171-16048-1	スプリングワッシャ	SPRING WASHER	4	
22	2120-16130-2	ナット	NUT	4	
23	3934-02395-0	ワッシャ	WASHER	2	
24	1538-74202-0	シュー	SHOE	2	
25	4703-14000-0	キャップ	CAP	4	

索引 INDEX

部品番号 PARTS NO.	頁 PAGE.	部品番号 PARTS NO.	頁 PAGE.	部品番号 PARTS NO.	頁 PAGE.
0788-36003-0	15-1	1406-05018-0	5-1	1406-36501-0	14-1
1402-09002-0	35-1	1406-09001-0	36-1	1406-36501-0	18-2
1402-09014-0	35-1	1406-09002-0	36-1	1406-36502-0	14-1
1402-09033-0	35-1	1406-09020-0	35-1	1406-36503-0	14-1
1402-12021-0	6-1	1406-09028-0	35-1	1406-43001-0	20-1
1402-19001-0	7-1	1406-09029-0	36-2	1406-43002-0	20-1
1402-31003-1	30-1	1406-12006-0	6-1	1406-43002-0	21-1
1402-32002-0	11-1	1406-12007-0	6-1	1406-43002-0	22-1
1402-32005-0	11-1	1406-12008-0	6-1	1406-43003-0	20-1
1402-32014-0	9-1	1406-12009-0	6-1	1406-43003-0	21-1
1402-32014-0	10-1	1406-12013-0	6-1	1406-43003-0	22-1
1402-51012-1	8-2	1406-12014-0	7-1	1406-43004-0	20-1
1402-51013-0	8-2	1406-12015-0	7-1	1406-43004-0	21-1
1402-51015-1	8-2	1406-12016-0	7-1	1406-43004-0	22-1
1402-51019-0	8-1	1406-12017-0	7-1	1406-43005-0	20-1
1402-51021-0	8-1	1406-27002-0	23-1	1406-43005-0	21-1
1402-61164-0	27-1	1406-27003-0	23-1	1406-43005-0	22-1
1402-61164-0	28-1	1406-31001-0	30-1	1406-43009-0	20-2
1402-61170-0	27-1	1406-32001-0	9-1	1406-43009-0	21-2
1402-61170-0	28-1	1406-32001-0	10-1	1406-43009-0	22-2
1402-61176-0	15-3	1406-32001-0	19-1	1406-43017-0	20-2
1402-61194-0	27-2	1406-32002-0	9-1	1406-43017-0	21-2
1402-61194-0	28-2	1406-32002-0	10-2	1406-43017-0	22-2
1406-01001-0	1-1	1406-32003-0	9-1	1406-43018-0	20-1
1406-01002-0	1-1	1406-32003-0	10-2	1406-43018-0	21-1
1406-01003-0	1-1	1406-36001-0	15-3	1406-43018-0	22-1
1406-02001-0	2-1	1406-36002-0	15-3	1406-43301-0	21-1
1406-02004-0	2-1	1406-36003-0	15-3	1406-43701-0	22-1
1406-02005-0	2-1	1406-36004-0	15-3	1406-43702-0	22-2
1406-02006-0	2-1	1406-36007-0	15-2	1406-47001-0	34-1
1406-03001-0	3-1	1406-36011-0	15-1	1406-47003-0	34-1
1406-03004-0	3-1	1406-36012-0	15-1	1406-47502-0	34-1
1406-03005-0	3-1	1406-36013-0	15-1	1406-47504-0	34-1
1406-03006-0	3-1	1406-36014-0	12-1	1406-49004-0	19-1
1406-03013-0	3-1	1406-36015-0	15-3	1406-49008-0	19-1
1406-03014-0	3-1	1406-36016-0	13-1	1406-49506-0	18-2
1406-03015-0	3-1	1406-36016-0	17-1	1406-49507-0	19-1
1406-03016-0	3-1	1406-36019-0	13-1	1406-49508-0	18-1
1406-04007-0	4-1	1406-36019-0	14-1	1406-51002-0	8-1
1406-04008-0	4-1	1406-36019-0	17-1	1406-51003-0	8-2
1406-05013-0	5-1	1406-36019-0	18-1	1406-51004-0	8-1
1406-05014-0	5-1	1406-36020-0	15-3	1406-51005-0	8-2
1406-05015-0	5-1	1406-36021-0	15-3	1406-61001-0	29-1
1406-05016-0	5-1	1406-36023-1	15-1	1406-61005-0	24-1
1406-05017-0	5-1	1406-36024-0	15-1	1406-61005-0	25-1

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL