

# 产品图册

PARTS BOOK



## QY25CS2汽车起重机主体 QY25CS2.0

---

QY25CS2 vehicle crane body  
(Europe III)

设备编号 Equipment No.

10TC10251201

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

10053546 起重臂 .....	5-4
10138488 基本臂总成 .....	5-8
10138478 压绳滚轮 .....	5-12
10138468 滚筒总成 .....	5-14
10669845 托绳滚轮2 .....	5-16
10136452 二节臂总成 .....	5-18
10138075 三节臂总成 .....	5-22
10137468 滑轮总成 .....	5-26
10138162 四节臂总成 .....	5-28
10138100 滑轮总成 .....	5-32
10138120 导向轮总成 .....	5-34
10669838 托绳滚轮1 .....	5-36
10053533 伸缩机构 .....	5-38
10053527 导向轮总成 .....	5-44
10138404 轮子 .....	5-46
10131948 副起重臂 .....	5-48
10137574 滑轮总成 .....	5-52
10138055 臂端滑轮组件 .....	5-54
11223626 滑轮组件 .....	5-56
10140758 伸缩臂油缸总成 .....	5-58
<b>第6章 上车操纵室 .....</b>	<b>6-1</b>
<b>10240959 上车操纵室 .....</b>	<b>6-2</b>
A810402010050 上车操纵室 .....	6-4
10052944 上车操纵装置 .....	6-6
11141079 保护装置 .....	6-8
10136970 操纵室空调装置 .....	6-10
<b>第7章 上车液压系统 .....</b>	<b>7-1</b>

序号	代码	名称	数量	备注
1	10100454	驾驶室总成及空调系统	1	
2	11031377	铭牌及标牌安装图	1	
3	10101103	动力系装置	1	
4	11012598	传动系装置	1	
5	00001681	下车操纵装置	1	
6	10138864	车架结构系装置	1	
7	10178437	车桥悬架装置	1	
8	10230381	下车液压系统	1	
9	10010561	25吨欧III底盘电气系统	1	
10	10938802	制动系统装置	1	
11	10621060	转向系统装置	1	

序号	代码	名称	数量	备注
1	A210405000007	垫圈8GB97.1	16	
2	60005656	压缩机	1	
3	60005669	冷凝器	1	
4	60005673	蒸发器	1	
5	60025906	空调附件	1	
6	10003454	冷凝器固定板 I	1	
7	10003456	冷凝器固定板II	1	
8	A210319000004	螺母M8GB889.1	8	
9	A210111000091	螺栓M8×30GB5783	8	

序号	代码	名称	数量	备注
1	10050173	发动机悬置前支架	2	
2	10050353	发动机后支座总成	2	
3	A210405000011	垫圈10GB97.1	4	
4	A210401000002	垫圈12GB93	8	
5	A210405000001	垫圈12GB97.1	8	
6	A210401000003	垫圈14GB93	6	
7	A210405000002	垫圈14GB97.1	22	
8	A229900002985	右支承托架	1	
9	A229900002986	左支承托架	1	
10	A210319000001	螺母M10GB889.1	4	
11	A210111000026	螺栓M10×35GB5783 10.9级	4	
12	A210114000036	螺栓M12×1.5×35GB5786	8	
13	A210319000018	螺母M14GB889.1	16	
14	A210114000061	螺栓M14×1.5×35GB5786 10.9级	2	
15	A210113000259	螺栓M14×1.5×45GB5786 10.9级	4	
16	A210111000208	螺栓M14×40GB5783 10.9级	16	
17	A220200000026	发动机	1	

序号	代码	名称	数量	备注
23	A210307000012	螺母M8GB6170	14	
24	A210111000090	螺栓M8×25GB5783	2	
25	A210111000092	螺栓M8×35GB5783	2	

序号	代码	名称	数量	备注
23	11018034	离合器油壶耐腐蚀胶管	1	
24	11082429	离合器助力缸油管	1	

序号	代码	名称	数量	备注
23	60122632	方头锥形螺塞Q614B12	1	
24	60075122	底取力窗口衬垫16929	1	
25	60075123	底取力窗口盖16596	1	
26	60125240	六角头螺栓Q4031225	8	
27	60105587	弹簧垫圈Q40312 东风	8	
28	60105621	垫圈Q40112 东风	8	
29	60122628	方头锥形螺塞Q61304	1	
30	60125246	自动调心离合器分离轴承单元85CT5740F3	1	
31	A229900005424	离合器分离拨叉	1	
32	60125233	卡板C04016-1	1	
33	60107020	螺钉Q2140510	3	
34	60125275	组合件用弹簧垫圈Q40605	3	
35	60125264	分离支柱C04015-1	1	
36	60106926	标准型弹簧垫圈Q40320	1	
37	60125235	六角头螺母Q340B20	1	
38	60125261	弹性圆柱销Q5280324	2	
39	60125256	离合器手孔盖JS180-1601016-2	1	

序号	代码	名称	数量	备注
85	60104396	三四档拨叉16136	1	
86	60104397	一二档拨叉16135	1	
87	60125267	三四档拨叉轴16134	1	
88	60075076	三四档导块14659	1	
89	60075236	换档拨叉锁止螺钉3220	5	
90	60122631	方头锥形螺塞Q614B10	1	
91	60075243	随动杆17177	1	
92	60075172	上盖F99980-1	1	
93	60075249	拨叉轴联锁销1634	1	
94	60075157	开关启动销15899	1	
95	60075251	倒档开关衬垫15900	2	
96	60075221	压力开关791.00.71.0068	1	
97	60125245	钢球19.05G100bGB308	2	
98	60122620	钢球12.7G100bGB308	3	
99	60075182	压缩弹簧15918	3	
100	60075250	操纵窗口衬垫19870	1	
101	60122646	密封垫圈Q72318T3	1	
102	60125277	压力开关990.12.71.0041-1	1	
103	60125266	气缸总成JS150T-1703000-1	1	
104	60125231	低倒档拨叉总成T115-1702020	1	
105	60125244	一二档导块14658	1	
106	60104340	低倒档拨叉轴16132	1	

序号	代码	名称	数量	备注
141	60064780	付箱主轴F99882	1	
142	60075073	高低档同步器总成A-C09005	1	
143	60075234	副箱主轴垫圈14332	1	
144	60075146	副箱主轴齿轮垫片14331	1	
145	60075090	副箱主轴减速齿轮19726	1	
146	60075209	止动环14327	1	
147	60075232	副箱减速齿轮垫片19466	1	
148	60075179	凸缘螺母F96006	1	

序号	代码	名称	数量	备注
1	A229900003320	传动轴	1	
2	A229900003321	中传动轴总成	1	
3	A229900003322	后传动轴总成	1	
4	A210405000011	垫圈10GB97.1	2	
5	A210405000002	垫圈14GB97.1	2	
6	A210405000003	垫圈16GB97.1	40	
7	A229900003001	传动轴螺栓	40	
8	10683770	传动轴防护板	1	
9	A210307000017	螺母M10GB6170	2	
10	A210111000023	螺栓M10×30GB5783	2	
11	A210319000019	螺母M14GB889.1 10级	2	
12	A210111000208	螺栓M14×40GB5783 10.9级	2	
13	A210319000012	螺母M16GB889.1	40	

序号	代码	名称	数量	备注
1	10205004	软轴支架	1	
2	A810103990168	控制器支架	1	
3	10047858	变速操纵杆	1	
4	A210401000017	垫圈8GB93	4	
5	A210401000001	垫圈10GB93	4	
6	A229900009084	进挡软轴	1	
7	A229900009088	选挡软轴	1	
8	A229900003059	控制器	1	
9	A229900003063	选挡摇臂	1	
10	A210314000009	螺母M10GB6184	2	
11	A210111000018	螺栓M10×25GB5783	4	
12	A210307000001	螺母M12GB6170	1	
13	A210210000015	螺钉M4×10GB818	4	
14	A210314000008	螺母M8GB6184	1	
15	A210111000091	螺栓M8×30GB5783	4	
16	A210111000093	螺栓M8×40GB5783	1	
17	A229900003374	操纵杆防尘罩(大号)	1	
18	A229900003375	防尘罩压圈(大号)	1	

序号	代码	名称	数量	备注
1	10060804	车架结构	1	
2	10878596	第五支腿油缸	1	含替代方案, 发货之前测量行程进
3	A210401000004	垫圈16GB93	4	
4	A210111000230	螺栓M16×50GB5783	4	
5	A810312000264	第五支脚盘	1	
6	10002494	吊臂支架总成	1	
7	10937311	走台板及支架	1	
8	10138860	上下护栏	1	
9	10116082	发动机罩	1	
10	00000196	备胎架总成	1	
11	10039139	垂直支脚油缸	4	发货时测量油缸行程进行反馈
12	00000604	支脚盘	4	
13	10138838	工具箱及挡泥板	1	
14	00000605	活动支腿总成	1	
15	10183890	水平支腿油缸	1	
16	10137433	起重钩固定装置	1	
17	00000844	销轴	4	
18	A210501000008	销5×32GB91	4	
19	10017201	调节滑块	8	
20	10018446	螺栓	8	
21	A210309000014	螺母M16GB6172.1	8	
22	10017205	压板	8	

序号	代码	名称	数量	备注
1	A229900004376	左前轮后挡泥板	1	
2	10483859	前挡泥板支架	4	
3	A210111000090	螺栓M8×25GB5783	74	
4	A210307000012	螺母M8GB6170	78	
5	A210401000017	垫圈8GB93	80	
6	A210405000001	垫圈12GB97.1	4	
7	A290000002357	铝制拉手	2	
8	10039097	罩后盖板	1	
9	A210405000007	垫圈8GB97.1	80	
10	A210111000092	螺栓M8×35GB5783	4	
11	A229900004377	右前轮后挡泥板	1	
12	A210401000001	垫圈10GB93	4	
13	A210405000011	垫圈10GB97.1	4	
14	A210111000018	螺栓M10×25GB5783	4	
15	10937301	右前走台板	1	
16	10937303	右前支腿盖板	1	
17	10937304	液压油箱盖板	1	
18	10937305	右中走台板	1	
19	10937306	右后走台板	1	
20	10937307	左后走台板	1	
21	10937308	左中走台板	1	
22	10937309	柴油箱盖板	1	

序号	代码	名称	数量	备注
1	10116078	发动机罩总成	1	
2	A820101990492	烫手警示牌	1	
3	A210111000089	螺栓M8×20GB5783	10	
4	A210307000012	螺母M8GB6170	10	
5	A210401000017	垫圈8GB93	10	
6	A210405000007	垫圈8GB97.1	10	
7	A230199000010	门把手	2	
8	A210210000020	螺钉GB818	4	
9	A210307000015	螺母	4	
10	A210401000015	垫圈5GB93	4	
11	A210405000005	垫圈5GB97.1	4	
12	11083216	密封条	2	
13	A229900003056	气弹簧	4	
14	11083215	密封条	2	
15	11127687	密封条	2	
16	A210491000009	销2×16GB91	8	

序号	代码	名称	数量	备注
1	10417561	左工具箱门总成	1	
2	10417562	右工具箱门总成	1	
3	10139428	左后挡泥板总成	1	
4	10139432	右后挡泥板总成	1	
5	10139434	左中挡泥板总成	1	
6	10139436	右中挡泥板总成	1	
7	A210111000090	螺栓M8×25GB5783	54	
8	A210307000012	螺母M8GB6170	54	
9	A210401000017	垫圈8GB93	108	
10	A210405000007	垫圈8GB97.1	54	
11	10253707	连接板	2	
12	11115509	密封胶条	4	

序号	代码	名称	数量	备注
1	60126073	转向节总成80622003	1	
2	60126060	垫79601073	2	
3	60126131	气室支架80428002	1	
4	60126149	转向横拉杆80380003	1	
5	60126064	桥壳总成81380000	1	
6	A210491000017	销4×40GB91	4	
7	60126074	转向节总成80622004	1	
8	60126148	主销轴79601039	2	
9	60126072	转向节臂80380001	1	
10	60126130	气室支架80428001	1	
11	A229900007319	制动气室	2	
12	60126108	调整螺栓79601013	2	
13	A210138000007	螺栓M14×65GB5789	4	
14	60126078	制动器总成79601004 φ420×160P	2	
15	60126141	制动鼓79601003	2	
16	60126117	轮毂总成79601002	2	
17	A229900005969	轮胎螺栓50016001	20	
18	60057044	轮辋螺母M22X1.5	20	
19	60126063	前制动调节臂79605015	1	
20	60126143	制动凸轮轴79601005	1	
21	A210338000003	螺母M16×1.5GB3763	4	
22	60126138	油杯56300002	6	

序号	代码	名称	数量	备注
23	A210319000005	螺母M20GB889.1	18	
24	A210355000010	螺母M20×1.5GB9457	4	
25	A210321000010	螺母M20×1.5GB56 10级	8	
26	A210111000062	螺栓	18	
27	A210355000008	螺母M24×2GB9457 10级	2	
28	A229900003003	减振器	2	
29	A229900003002	前钢板弹簧总成	2	
30	10125894	缓冲块	2	
31	10490661	缓冲块压板	2	

序号	代码	名称	数量	备注
1	60126231	双金属衬套2913660-022	1	
2	60057009	后簧一片SY280QD-2912000-1	1	
3	60056990	后簧二片SY280QD-2912000-2	1	
4	60056998	后簧三片SY280QD-2912000-3	1	
5	60057005	后簧四片SY280QD-2912000-4	1	
6	60057007	后簧五片SY280QD-2912000-5	1	
7	60090805	卡箍套管2912650-107	2	
8	60126220	六片夹箍2913660-032	2	
9	60056994	后簧六片SY280QD-2912000-6	1	
10	60056996	后簧七片SY280QD-2912000-7	1	
11	60056988	后簧八片SY280QD-2912000-8	1	
12	60056992	后簧九片SY280QD-2912000-9	1	
13	60057001	后簧十片SY280QD-2912000-10	1	
14	60126234	中心螺栓660-29044-000-106	1	

序号	代码	名称	数量	备注
23	A229900002747	管接头	1	
24	10138970	钢管总成	1	
25	10138971	钢管总成	1	
26	10138972	钢管总成	1	
27	10138973	钢管总成	1	
28	10138974	钢管总成	1	
29	10138975	钢管总成	1	
30	A229900005515	管接头	5	
31	B230103003223	胶管	1	
32	A229900002509	对开法兰	2	
33	A210111000039	螺栓M12×35GB5783	4	
34	B230103004276	胶管	1	
35	A229900002857	国产法兰夹	2	
36	A210111000041	螺栓M12×45GB5783	4	
37	B230103008039	胶管	1	
38	10138601	回油管总成	1	
39	B230103008038	胶管	1	
40	A229900002510	管接头	1	
41	B230103002120	胶管	1	
42	A810201029364	吸油硬管总成	1	
43	10138977	钢管总成	1	
44	10138978	钢管总成	1	

序号	代码	名称	数量	备注
23	60107570	未连阀体DL8-07	1	
24	60107651	双头螺栓DL8-16	4	
25	60107636	螺母M8/12HYGB55	8	
26	60107569	换向阀体DL-8-10-05	5	
27	A210609000103	O形圈	7	
28	60107637	螺塞(M16×1.5)DL8-19.2	7	
29	60107565	阀套DL8-20	1	
30	A210609000270	O形圈	3	
31	60107564	单向阀阀芯DL8-21	1	
32	60107582	单向阀弹簧DL8-22	1	
33	60107655	外六角螺塞DL8-23	1	
34	60107549	矩形圈2.45×2.65×212 CY168	1	
35	60107548	矩形圈1.6×1.8×12.5 CY168	22	
36	60107650	手柄架DL8-18	6	
37	60024939	多路阀DL-8-10	1	
38	29010022	O形圈10×1.9	1	

序号	代码	名称	数量	备注
1	60033556	变幅平衡阀	1	
2	A229900002570	管接头	1	
3	A229900002541	管接头	1	
4	21002923	直角法兰接头	1	
5	A229900002856	对开法兰	2	
6	A210111000025	螺栓M10×35GB5783	4	

序号	代码	名称	数量	备注
1	A210204000147	螺钉M8×20GB70.1	4	
2	A820299001703	端盖	1	
3	10227870	中央回转壳体	1	
4	B230101001052	OQ油封150×135.5×6.3	9	
5	10227672	体芯	1	
6	B230101001054	导向环	2	
7	60018184	星形密封圈	1	
8	10044529	铜环	1	
9	A820299001805	端盖	1	
10	A210204000275	螺钉M14×100GB70.1	7	
11	A210401000003	垫圈14GB93	7	
12	A210608000120	O形圈	1	
13	A210609000287	O形圈	2	
14	A210609000268	O形圈18×2.65GB3452.1	2	
15	A210609000032	O形圈23.6×2.65 GB3452.1	1	
16	A210609000220	O形圈45×2.65	1	
17	A229900002547	堵头	6	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

序号	代码	名称	数量	备注
1	A240600000162	水位传感器	1	
2	A241100000349	侧标志灯总成	8	
3	B240600000007	压力传感器360081030015C	1	
4	60006478	收音机	1	
5	A249900000841	水位水温报警器	1	
6	A240500000075	电喇叭	1	
8	A210111000089	螺栓M8×20GB5783	19	
10	A210405000007	垫圈8GB97.1	43	
15	10212064	控制盒安装支架	1	
18	10020363	电源线	1	
20	A810201058462	电源线	1	
24	10174852	右尾灯线束总成	1	
25	A240600000139	液位传感器	1	
28	A210404000010	垫圈5GB96.1	5	
30	10174850	左尾灯线束总成	1	
32	A810201058463	编织铜线	1	
38	60013322	A型蓄电池正极接头总成A17.5	2	
40	A241200000524	刹车灯开关	1	
43	A250202000028	机油压力表	1	
44	A250204000024	水温表	1	
45	A250208000008	电子里程表	1	
46	A820606010865	过线圈55	7	

序号	代码	名称	数量	备注
27	A229900003044	可调向直角接头BOLM08-M10×1	3	
28	A210770000394	管接头BOLM12-M16×1.5	16	
29	A229900003034	隔壁三通接头	2	
30	A210334000015	螺母M14×1.5GB3763	2	
31	A229900003251	三通接头	2	
32	A229900003354	三通接头	3	
33	A210770000393	管接头	8	
34	A220401000199	差动阀	1	
35	A229900005108	制动软管Q-22-500W	3	
36	A229900003042	端直通接头BMC12-M16×1.5	2	
37	A229900002971	密封垫圈16QC638	4	
38	A229900003017	储气筒	1	
39	A210332000003	螺塞M22×1.5JB1000	1	
40	A220401000201	继动阀	1	
41	A210314000008	螺母M8GB6184	4	

序号	代码	名称	数量	备注
1	60013492	转向中间传动轴	1	
2	10937505	转向直拉杆总成	1	
3	A210405000007	垫圈8GB97.1	4	
4	A210401000006	垫圈20GB93	5	
5	A210501000010	销5×50GB91	2	
6	A229900005682	转向垂臂	1	
7	A229900005684	转向器总成	1	
8	21029600	螺栓	5	
9	A210319000004	螺母M8GB889.1	4	
10	A210111000092	螺栓M8×35GB5783	4	
11	A229900003007	角转向器	1	

序号	代码	名称	数量	备注
1	10101738	主臂电气图	1	
2	10131949	转台电气图	1	
3	10014097	附臂电气图	1	

序号	代码	名称	数量	备注
1	10526311	重锤钢丝绳1	1	
2	10526313	重锤钢丝绳2	1	
3	10022373	环形锤	1	

序号	代码	名称	数量	备注
1	A249900000513	侧边单框架	10	
2	A249900000514	中间单框架	10	
3	A249900000517	指示灯板	3	
4	A241100000320	指示灯	9	
5	A249900000520	指示灯座	15	
6	A249900000539	主电源标志板	1	
7	A249900000545	吊钩过卷标志板	1	
8	A249900000543	主卷扬过放标志板	1	
9	60027598	标志板 绿	1	
10	A229900003539	油压报警标志板	1	
11	A229900003540	水温报警标志板	1	
12	10061132	超载解除警告标牌	1	
13	B241200000145	钥匙开关	1	
14	A241200000540	翘板开关	1	
15	A241200000539	翘板开关	1	
16	A241200000536	翘板开关	1	
17	60027599	标志板 红	1	
18	21005650	翘板开关	1	
19	A241200000751	翘板开关	1	
20	A241200000552	翘板开关	1	
21	60027597	标志板 红	1	
22	B241200000030	点火开关	1	

序号	代码	名称	数量	备注
1	A249900001070	中心导电环	1	
2	B241000000005	三线插座护套总成	1	
3	B241000000004	三线插头护套总成	1	
4	B241000000001	片式插座	5	
5	B241200000461	水塞	10	
6	B241000000002	片式插头	5	
7	A210111000091	螺栓M8×30GB5783	3	
8	A210307000012	螺母M8GB6170	3	
9	A210401000017	垫圈8GB93	3	
10	A210405000007	垫圈8GB97.1	6	
11	B241000000018	二线插座护套总成	1	
12	B241000000003	二线插头护套总成	1	

序号	代码	名称	数量	备注
1	10139051	护板	1	
2	10138488	基本臂总成	1	
3	10669845	托绳滚轮2	1	
4	10136452	二节臂总成	1	
5	10138075	三节臂总成	1	
6	10138162	四节臂总成	1	
7	10139041	支架	1	
8	10669838	托绳滚轮1	2	
9	A210501000039	销6.3×45GB91	4	
10	A210401000016	垫圈6GB93	4	
11	A210401000017	垫圈8GB93	24	
12	A210405000007	垫圈8GB97.1	24	
13	A210401000001	垫圈10GB93	8	
14	A210405000011	垫圈10GB97.1	4	
15	A210401000002	垫圈12GB93	6	
16	A210405000001	垫圈12GB97.1	6	
17	A210307000017	螺母M10GB6170	4	
18	A210111000025	螺栓M10×35GB5783	4	
19	A210204000008	螺钉M10×40GB70.1	6	
20	A210111000039	螺栓M12×35GB5783	6	
21	A210307000005	螺母M20GB6170	3	
22	A210111000117	螺栓M20×80GB5783	3	

序号	代码	名称	数量	备注
1	A210601006241	滚动轴承	2	
2	10138464	滚筒	1	
3	10138467	销轴	1	

序号	代码	名称	数量	备注
23	10138433	支承块	2	
24	10136782	滑块	2	
25	10136812	销轴(-)	2	
26	10137474	垫片	4	
27	10137483	调整垫	4	
28	10137484	调整垫	4	
29	10137485	滑块(1)	2	
30	10431404	滑块(2)	2	
31	10137487	垫片(2)	4	
32	10138074	调整垫圈	2	
33	10137475	销轴(1)	2	
34	10137476	隔套	2	
35	10137477	销轴(2)	2	
36	10137478	止推块	2	
37	10137479	隔套(2)	2	
38	10137480	挡板	2	
39	10137481	挡轴板	2	
40	10137482	滑块	1	
41	10431339	滑块V	2	
42	10009313	垫片	4	
43	10009314	垫片	4	
44	10133916	滑轮	2	

序号	代码	名称	数量	备注
1	10138116	滑轮	1	
2	A210416000006	挡圈140GB893.1	1	
3	A210601006272	滚动轴承	2	
4	A210804000002	油杯	1	

序号	代码	名称	数量	备注
1	10053521	导向轮结构	1	
2	10138350	滑轮	1	
3	10138349	销轴	1	
4	10461015	挡板	1	
5	10138351	滚轮	2	
6	10138369	轴	1	
7	10138371	隔套	1	
8	10138373	绳挡	1	
9	B221500000214	轴承 Schaeffler	2	
10	A210111000018	螺栓M10×25GB5783	2	
11	A210401000001	垫圈10GB93	2	
12	A210491000023	销6.3×63GB91	1	
13	A210491000016	销4×32GB91	1	
14	10138375	挡绳卡	1	
15	A210307000012	螺母M8GB6170	2	
16	A210405000007	垫圈8GB97.1	2	
17	A210401000017	垫圈8GB93	2	

序号	代码	名称	数量	备注
1	10138054	滑轮架组件	1	
2	11223626	滑轮组件	1	
3	A210401000016	垫圈6GB93	6	
4	A210491000018	销4×50GB91	2	
5	A290000001564	黄油嘴保护帽	1	
6	A829900002661	弹性销	2	
7	A210804000002	油杯	1	
8	A210111000079	螺栓	6	
9	10137999	轴	2	
10	10138003	轴	1	
11	10138004	挡板	2	
12	10138007	垫圈	2	
13	10138012	销轴	2	

序号	代码	名称	数量	备注
1	A810402000280	操纵室	1	
2	10052944	上车操纵装置	1	
3	10173489	二力杆总成	5	
4	10240981	套	6	
5	11141079	保护装置	1	
6	A210508000032	销轴B8×40GB882	5	
7	A210491000014	销3.2×20GB91	5	
8	21006468	销轴	5	
9	A210501000025	销4×25GB91	5	
10	10136970	操纵室空调装置	1	

# 第7章

## 上车液压系统

序号	代码	名称	数量	备注
58	A229900002537	管接头	3	
59	B230103000589	胶管	1	
60	A831313055000	胶管	1	
61	10003371	钢管总成	1	
62	10003377	钢管总成	1	
63	10003367	钢管总成	1	
64	10003375	钢管总成	1	
65	B230103004437	胶管Q/SY1102	1	
66	21022017	胶管2	1	
68	21002960	管接头	1	
69	B230103008264	胶管	1	
70	B230103004857	胶管	1	
73	A229900002559	管接头	5	
75	11016129	钢管总成	1	
76	11126050	单向阀总成	2	
77	21023771	管接头	2	
78	B230103001071	胶管	1	
79	B230103001615	胶管	3	
80	A229900004247	管接头	1	
81	11219426	空调液压管路	1	

序号	代码	名称	数量	备注
1	A229900002977	管接头	1	
2	A229900002585	管接头	1	
3	10017248	单向节流阀块	1	
4	10026311	单向阀	1	

序号	代码	名称	数量	备注
1	A820101340033	过渡块Transitional block	1	
2	A229900002495	管接头	1	
3	A229900002581	管接头	1	

序号	代码	名称	数量	备注
1	A220401000373	单向阀	1	
2	A229900002581	管接头	1	
3	A229900002750	管接头	1	

序号	代码	名称	数量	备注
1	A831313055000	胶管	1	
2	A229900002938	管接头	2	
3	B230103002373	胶管1SN8-DKOL-DKOL90-1800Q/SY1102	1	
4	B230103001392	胶管	2	
5	A229900002814	管接头	1	
6	B210780000439	管接头	1	
7	A229900002561	管接头	1	
8	10176373	空调控制阀总成	1	
9	A210204000147	螺钉M8×20GB70.1	4	
10	A210401000017	垫圈8GB93	4	
11	A229900004359	管接头	1	
12	B230103000956	胶管	1	
13	60000458	液压马达	1	

序号	代码	名称	数量	备注
1	A229900002581	管接头	1	
2	A820101328659	电磁溢流阀座	1	
3	A229900002589	管接头	1	
4	A220401000189	电磁溢流阀	1	
5	A210204000304	螺钉M16 × 45GB70.1	4	
6	A210401000004	垫圈16GB93	4	

序号	代码	名称	数量	备注
1	10244657	转台焊接体	1	
2	10138927	转台锁定插销	1	
3	A210401000016	垫圈6GB93	12	
4	A210401000004	垫圈16GB93	9	
5	A210804000002	油杯	2	
6	A210111000100	螺栓	1	
7	A210111000242	螺栓M16×40GB5783 12.9级	8	
8	A210111000078	螺栓	12	
9	10140766	大臂铰接轴	1	
10	10140762	变幅油缸轴端压板	1	
11	10805969	大臂轴端压板	4	
12	00001868	变幅油缸下铰接轴	1	
13	10003433	盖板	4	
14	10003434	橡胶垫	4	
15	A290000001564	黄油嘴保护帽	2	

序号	代码	名称	数量	备注
1	10177414	右侧后封板	1	
2	10184345	上支架	1	
3	10184384	左支架	1	
4	10184385	斜支架	1	
5	10184386	下支架	1	
6	10184387	右支架	1	
7	10184350	中支架	1	
8	10196451	安装支座	4	
9	10184351	垫板	6	
10	A210108000074	螺栓M6×30GB5782	12	
11	A210405000006	垫圈6GB97.1	8	
12	A210401000016	垫圈6GB93	8	

序号	代码	名称	数量	备注
1	A210208000001	螺钉M8×16GB79	4	
2	10074140	衬套	1	
3	10041691	螺塞	2	
4	A210434000007	垫圈	2	
5	A210434000015	垫圈	1	
6	A210332000002	螺塞	1	
7	B210399000003	螺塞	1	
8	A210342000002	螺塞	1	
9	A210609000274	O形圈218×7 GB3452.1	2	
10	10074135	挡圈	2	
11	10074136	导向套	1	
12	A880803040004	导向环	3	
13	A880806030018	GS密封圈180×195.1×6.3	1	
14	B230101000512	B3型密封圈180×200×15	1	
15	B230101001111	防尘圈AY180AP5008	1	
16	A210208000008	螺钉M10×16GB79	2	
17	10513572	螺母	1	
18	B230101001639	导向环	2	
19	A210208000007	螺钉M10×20GB79	4	
20	10074139	活塞	1	
21	B230101001567	MD密封圈230×205×25.4	1	
22	A31C210900530	O形圈109×5.3GB3452.1	2	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL