

**TM-ZE500 41050505045A BOOM/5 SECT.,HOOK-IN**

PB0000229-01 SYSTEM (ZE500,EXPORT)

PB0000272-01 SYSTEM (ZE550,EXPORT)

ASSEMBLY

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.


CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

# TM-ZE500 410505045A BOOM/5 SECT.,HOOK-IN

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Rem
54	31205510040	PLATE,SLIDE	2			DG3580		
55	37000312380	SPACER	6		L=13			
56	37000315390	SPACER	4					
57	90303070601	WASHER,PLAIN	4		6			
77	82400000459	CAP	1					
92	31360202500	SUPPORT	2					
98	31205511200	SUPPORT	1					
99	31201571100	SUPPORT	1					
116	31205492060	PLATE	1					
126	31205493200	SUPPORT	1				DF1055	
	31205493201	SUPPORT	1			DF1056		
131	31205514200	SUPPORT	1					
142	80530000222	BEARING,BALL (NACHI)	2					
	31205310110	BEARING,BALL (IP)	2					
	80530000224	BEARING,BALL (KOYO SEIKO)	2					
151	31202630400	SUPPORT	1				DH5493	
	31202960400	SUPPORT	1			DH5494		
152	37001101900	ROLLER	1					
153	80601110120	RING,RITAINING	2		S12			
154	37000173800	PIN	1					
181	37001107720	ROLLER ASSY	1					
182	37000538730	PLATE	2					
183	31202510560	SUPPORT	1					
184	37000160580	PIN	1					
185	90101208012	BOLT	1		M8X12			
186	90302040801	WASHER,SPRING	1		8			
187	90303070801	WASHER,PLAIN	1		8			
192	80516006902	BEARING,BALL	2					
	31205310210	BEARING,BALL (IP)	2					

TM-ZE500 410505045A BOOM/5 SECT.,HOOK-IN  
PC6470013-00 CYLINDER ASSY,TELESCOPING

NO.3 CYLINDER



Δ:PACKING SET KEY NO.150 (KEY NO.4,5,9,10,14,15,16,17)

# TM-ZE500 41050505045A BOOM/5 SECT.,HOOK-IN

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Rem
1	(*****)	BOOM ASSY	1					
2	31212430000	TELESCOPE ASSY	1					
3	(*****)	INDICATOR ASSY,OVERWIND	1					
4	(*****)	PIPING,TELESCOPING (JOINT)	1					

# TM-ZE500 410505045A BOOM/5 SECT.,HOOK-IN

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1	37001008230	SHEAVE	3				DE7999		
	37001008670	SHEAVE ASSY	3			DE8000			
2	37000303960	SPACER	3		L=13.5				
3	31203395100	PIN	1						
4	31203395500	LINK ASSY	1						
5	31200584000	COVER	1						
6	90191210020	BOLT	2		M10X20				
7	90302041001	WASHER,SPRING	2		10				
8	37000308850	SPACER	1		L=8.5				
22	80516006207	BEARING,BALL	3				DE7999		
	36093861100	BEARING,BALL	3			DE8000			
31	31203395600	SPACER	1						
32	31201565200	PIN	1						
33	31203395700	LINK	1						

# TM-ZE500 41050505045A BOOM/5 SECT.,HOOK-IN

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Page
1	36161625010	PLATE (BASE)	1						
2	36161625020	CASE	1						
3	36161625060	SPRING ASSY	1						
8	36161615040	CONTACTOR ASSY	1				DF3001		
	36132395100	CONTACTOR ASSY	1			DF3002			
9	36161615050	CONTACTOR ASSY	1						
15	36161615060	WASHER	1						
17	36161495050	LOCK	1						
20	36132385060	CORD (MAIN)	17	M					
21	36132385070	CORD (SUB)	2	M					
100	36161620001	REEL ASSY,CORD	1						

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL