

TM-ZF500 31093010390A FRAME/ROUND TYPE

PK2000781-00 FRAME UNIT

PO1000122-01 INDICATION PLATES

PY1000373-00 OPTIONS

ASSEMBLY

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

TM-ZF500 31093010390A FRAME/ROUND TYPE

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1	31630971000	PLATE	1						
2	90171110025	BOLT	2		M10X25				
3	90302041001	WASHER,SPRING	2		10				

**TM-ZF500 31093010390A FRAME/ROUND TYPE
PB1410840-01 PIPING, HYDRAULIC LOWER**



TM-ZF500 31093010390A FRAME/ROUND TYPE

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Rema
1	37002303420	BEARING,SWING (NSK)	1					
2	37001505390	BOLT	25		M20X80			
3	37001500560	BOLT	10		M18X55			
4	90171116040	BOLT	4		M16X40			
5	90302041601	WASHER,SPRING	4		16			
6	36081300000	REDUCER,SWING SPEED	1					
7	91001208500	O-RING	1		1A G85			
8	90174112035	BOLT	2		M12X35			
9	90302041201	WASHER,SPRING	2		12			
10	36662590000	MOTOR,HYDRAULIC (SWING)	1					

TM-ZF500 31093010390A FRAME/ROUND TYPE

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks
1	36072255010	CASING	1					
2	36072255020	COVER	1					
3	36072255030	GEAR (1)	1					
6	36072255060	DISK	1				EW0427	
	36073425030	DISK	1			EW0428		
7	36073425020	WHEEL,RATCHET	1					
8	36072255080	BUSH	1				EW0427	
	36073425040	BUSH	1			EW0428		
9	36072255091	RING,SLIP	1					
10	36072255101	RATCHET	1					
11	36072255110	PIN	1					
12	36072255120	SPRING	1					
13	36072255130	PIN	1					
14	36072255140	PLATE (LOCK)	1					
15	80172304010	SCREW,MACHINE	1		M4X10			
17	36072255160	BOLT (WITH WASHER)	6		M8X25			
19	36072255180	GAUGE,OIL	1					
20	36072255240	PLUG	1					
21	80500006004	BEARING,BALL	1					
22	80500006212	BEARING,BALL	1					
23	80500006305	BEARING,BALL	1					
24	80500006007	BEARING,BALL	1					
25	36072255190	KEY	2		7X7X20			
26	36072255250	O-RING	1					
27	91001101500	O-RING	1		1A P15			
28	36072255210	SEAL,OIL	1					
29	36072255220	NUT,CASTLE	1		M24			
30	80136350035	PIN,SPLIT	1		5X35			
31	80602110620	RING,RITAINING	1		R62			
41	36073435010	GEAR SET	1				EW0427	
	36073435011	GEAR SET	1			EW0428		
50	36073430000	WINCH (OOKUBO)	1					
101	36072251000	FACING KIT(JAPANESE)	1					
102	36072252000	FACING KIT (ENGLISH)	1					

TM-ZF500 31093010390A FRAME/ROUND TYPE

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Rema
4	91001004800	O-RING	1		S48			
5	36661915020	HOLDER (OIL SEAL)	1					
6	91252102500	SEAL,OIL	1					
7	36661915030	PLATE (HOLDER)	1					
8	80602110520	RING,RITAINING	1		R52			
18	91001008500	O-RING	1		S-85			
24	36661115120	KEY	1		6X6X41			
50	36661910000	MOTOR,HYDRAULIC (WINCH)	1					

TM-ZF500 31093010390A FRAME/ROUND TYPE

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1	31230811000	POST	1						
2	37000203590	PIN	1						
3	80136363080	PIN,SPLIT	1		6.3X80				
4	31230770200	COVER	1						
5	90101208012	BOLT	4		M8X12				
6	90302040801	WASHER,SPRING	4		8				
7	37000203570	PIN	1						
8	90303135601	WASHER,PLAIN	1		56				
9	90236255601	NUT,CASTLE	1						
10	80136380090	PIN,SPLIT	1		8X90				
11	31630482000	PLATE	1						
12	90171110014	BOLT	2		M10X14				
13	90302041001	WASHER,SPRING	2		10				
14	82458202000	NIPPLE,GREASE	1		B-TYPE PT1/8				
15	82400000459	CAP	2						
16	31230770100	COVER	1						
17	82459203000	NIPPLE,GREASE	1		C-PT1/8				
18	82401800180	PLUG	2		FOR M18				

TM-ZF500 31093010390A FRAME/ROUND TYPE

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1	31653110100	SUPPORT	1						
2	90101210014	BOLT	2		M10X14				
3	90302041001	WASHER,SPRING	2		10				
4	90101206060	BOLT	4		M6X60				
5	90302040601	WASHER,SPRING	4		6				
6	90303070601	WASHER,PLAIN	8		6				
7	90201200600	NUT	4		M6				
8	91850310305	CLAMP	4						
9	91810130240	FASTENER	8						
10	82401600510	CLAMP	1		10				

TM-ZF500 31093010390A FRAME/ROUND TYPE

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Page
1	36803215010	PLATE ASSY,NAME	1						

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

TM-ZF500 31093010390A FRAME/ROUND TYPE

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1	31396630100	PLATE,NAME	2						

TM-ZF500 31093010390A FRAME/ROUND TYPE

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (E
1	(*****)	REMOTE CONTROL (PARTS)	1				
2	(*****)	ELEC.ASSY (REMOTE CONTROL)	1				
3	(*****)	VALVE,REMOTE CONTROL	1				
4	(*****)	OPE.ASSY,CONT.VALVE (REMOTE)	1				
6	36800581000	CONTROL BOX (REMOTE CONTROL.M2)	1				

TM-ZF500 31093010390A FRAME/ROUND TYPE


Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No
228	36642415260	BALL,STEEL	8		S18		
230	91001001800	O-RING	8				
241	36645065070	BOX	1				
242	36642415360	COVER (BOX)	1				
243	36645155190	CABLE (METAL CONNECTOR)	1				
244	36647365100	BOX ASSY (FUSE & RELAY)	1				
245	36647365110	COIL ASSY (SV)	1				
246	36647365120	COIL ASSY (LVDT)	1				
247	36645155230	COIL ASSY (LVDT/EHS)	1				
248	36645155240	COIL ASSY (FHS)	1				
300	36647360000	VALVE,REMOTE CONTROL	1				

TM-ZF500 31093010390A FRAME/ROUND TYPE

Pos No.	Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Ren
7	36802865030	PLATE,NAME	1					
8	36802865050	PLATE,NAME	1					
21	36802865040	CASE (BATTERY)	1					
22	36802865060	BATTERY (4 PIECES)	1					
31	36802865070	STRAP	1					
41	36802865080	RUBBER (FOR SWITCH)	1					
50	36802863000	SWITCH BOX(RADIO CONTROL)	1					


TM-ZF500 31093010390A FRAME/ROUND TYPE
PV1040018-02 CONTROL BOX (RADIO CONTROL.M2.A)

50



TM-ZF500 31093010390A FRAME/ROUND TYPE
PV1040093-03 CONTROL UNIT


900




TM-ZF500 31093010390A FRAME/ROUND TYPE
PV1070117-00 RADIO CONTROL

2.	ハイセンASSY ELEC. ASSY
3.	バルブ , リモート コントロール VALVE , REMOTE CONTROL
4.	オペ . ASSY , ソウサバルブ OPE . ASSY , CONT . VALVE
5.	ストーイング ボックス STOWING BOX
6.	マウント , アンテナ MOUNT , ANTENNA
8.	プレートASSY , ネーム PLATE ASSY , NAME
21	コントロール ボックス CONTROL BOX
22	スイッチ ボックス SWITCH BOX

TM-ZF500 31093010390A FRAME/ROUND TYPE
PV1250006-00 STOWING BOX (BAG,RADIO CONTROL)



TM-ZF500 31093010390A FRAME/ROUND TYPE
PV1400030-01 ANTENNA



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL