

Takeuchi

TB68S

LOADED ENGINE

DIESEL ENGINE

MODEL

SD334

PARTS CATALOG

TAKEUCHI MFG. CO., LTD.
205-3, UADAIRA, SAKAKI-MACHI,
HANISHINA-GUN, NAGANO 389-07,
JAPAN

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Key-No.	Description 部品名称	C O D E	Part Number 部品番号	Quantity Per Section 個数及び適用												I N T	Execution (E/#)
1	PAN ASSY-OIL		11110-90806	1
2	PLUG-DRAIN		11128-69200	1
3	WASHER	K	11026-61000	1
9	GASKET	K	11121-C7800	1
10	BOLT,W/WASHER		08120-61228	34
15	GUIDE ASSY		15150-90002	1
16	RING-RUBBER	K	15147-37500	1
18	GAUGE-OIL LEVEL		15140-90064	1
19	PUMP ASSY-OIL (INNER PARTS E111P)		15010-90063	1
20	GASKET-OIL PUMP	K	15066-90007	1
21	BOLT,W/WASHER		08120-82028	2

FILTER-OIL (INNER PARTS)

FIG.E152P

Key-No.	Description 部品名称	C O D E	Part Number 部品番号	Quantity Per Section 個数及び適用												I N T	Execution (E/#)
1- 19	FILTER ASS'Y-OIL		15200-C6800	1
1	BRACKET ASS'Y		15237-C6800	1
2- 4	ELEMENT KIT		15208-61525	1
6	CASE		15201-61502	1
7	BOLT-CENTER		15213-61502	1
8	SPRING SET		15224-61501	1
9	RETAINER-SPRING		15291-90003	1
11	VALVE		15280-90001	1
12	SPRING		15341-61500	1
13	GASKET-PLUG		15304-61501	1
14	PLUG		15303-61503	1
16	VALVE-SHORT		15300-76200	2
17	SPRING-SHORT VALVE		15301-76201	2
18	GASKET		15304-61501	2
19	PLUG		15303-61503	2



NOZZLE (INNER PARTS)

FIG.E166P

Key-No.	Description 部品名称	C O D E	Part Number 部品番号	Quantity Per Section 個数及び適用												I N T	Execution (E/#)	
1- 9	NOZZLE ASSY		16600-90019	6
1- 8	HOLDER ASSY		16610-90016	6
2	ROD-PUSH		16612-37500	6
3	SPRING		16615-37500	6
4	SHIM T=0.50	S	16613-V0700	N
4	SHIM T=0.52	S	16613-V0701	N
4	SHIM T=0.54	S	16613-V0702	N
4	SHIM T=0.56	S	16613-V0703	N
4	SHIM T=0.58	S	16613-V0704	N
4	SHIM T=0.60	S	16613-V0705	N
4	SHIM T=0.62	S	16613-V0706	N
4	SHIM T=0.64	S	16613-V0707	N
4	SHIM T=0.66	S	16613-V0708	N
4	SHIM T=0.68	S	16613-V0709	N
4	SHIM T=0.70	S	16613-V0710	N
4	SHIM T=0.72	S	16613-V0711	N
4	SHIM T=0.74	S	16613-V0712	N
4	SHIM T=0.76	S	16613-V0713	N
4	SHIM T=0.78	S	16613-V0714	N
4	SHIM T=0.80	S	16613-V0715	N
4	SHIM T=0.82	S	16613-V0716	N
4	SHIM T=0.84	S	16613-V0717	N
4	SHIM T=0.86	S	16613-V0718	N
4	SHIM T=0.88	S	16613-V0719	N
4	SHIM T=0.90	S	16613-V0720	N
4	SHIM T=0.92	S	16613-V0721	N
4	SHIM T=0.94	S	16613-V0722	N
4	SHIM T=0.96	S	16613-V0723	N
4	SHIM T=0.98	S	16613-V0724	N
4	SHIM T=1.00	S	16613-V0760	N
4	SHIM T=1.02	S	16613-V0761	N
4	SHIM T=1.04	S	16613-V0762	N



GOVERNOR (INNER PARTS)

FIG.E167S

Key-No.	Description 部品名称	C O D E	Part Number 部品番号	Quantity Per Section 個数及び適用												I N T	Execution (E/#)	
1- 72	GOVERNOR ASS'Y		19109-90064	1
1	HOUSING		19356-99114	1
6	O RING		19279-99003	1
7	PLUG		19289-99004	1
8	ADAPTER		19258-37500	1
9	BOLT		19382-Z9000	1
10	PLATE		19380-90004	1
11	BOLT		16754-37501	6
12	SCREW		19310-90004	1
13	NUT		19268-90000	2
14. 15	COVER ASS'Y		19373-99013	1
15	BUSH		19123-90002	1
16	SCREW		19336-99009	1
17	NUT		19370-90003	1
18	PLUG		19382-90001	1
19	BOLT		19285-99000	2
20	SCREW		19310-90003	1
21	BOLT		19797-99001	4
22	CAP		19261-99005	1
23	COVER		19286-99019	1
25	BOLT		19797-99003	2
26	BOLT		19382-99017	2
27	FLYWEIGHT ASS'Y		19312-90004	1
28	KEY-WOODRUFF		16742-37500	1
29	WASHER-SPRING		16874-90001	1
30	NUT		19325-90002	1
31. 32	SLEEVE ASS'Y		19363-99007	1
32	BEARING		19339-99000	1
33	SHIM T=0.2	S	19342-90001	N
33	SHIM T=0.3	S	19342-90002	N
33	SHIM T=0.4	S	19342-90003	N
33	SHIM T=1.0	S	19342-90004	N

PUMP-WATER (FITTING PARTS)

FIG.E210A

Key-No.	Description 部品名称	C O D E	Part Number 部品番号	Quantity Per Section 個数及び適用												I N T	Execution (E/#)		
1	PUMP ASSY-WATER (INNER PARTS E210P)		21010-61505	1
2	PLUG-SCREW		08931-30610	1	
3	GASKET-PUMP	K	21074-37502	1	
4	BOLT,W/WASHER		08110-85562	1	
5	BOLT,W/WASHER		08110-84562	1	
6	BOLT,W/WASHER		08114-05562	1	
7	HOSE-WATER		21069-61500	1	
8	CLAMP-HOSE		08723-13600	2	
9	HOSE-WATER	*	21504-90165	1	
10	PIPE-WATER	*	21505-90068	1	
11	CLAMP-HOSE		21383-90012	1	
12	CLAMP-HOSE		21383-90013	1	
13	BOLT,W/WASHER		08114-02062	1	

GENERATOR (INNER PARTS)

FIG.E231P

Key-No.	Description 部品名称	C O D E	Part Number 部品番号	Quantity Per Section 個数及び適用												I N T	Execution (E/#)	
1- 29	GENERATOR ASS'Y (FOR 12V-35A)		23100-90066	1
1- 3	ROTOR ASS'Y		23108-L1801	1
3	BEARING-BALL		23120-14801	1
5	BEARING-BALL		23120-89801	1
8	STARTER ASS'Y		23102-L1800	1
9. 10	COVER ASS'Y-REAR (INC.KEY NO.16)		23127-L6001	1
9	COVER-REAR		23183-L6001	1
10	DIODE		23137-27000	1
16	BRUSH ASS'Y		23134-27000	1
25	COVER ASS'Y-FRONT (INC.KEY NO.4,5)		23118-L1800	1
26	PULLEY ASS'Y		23151-L1801	1
27	BOLT-THROUGH		23131-L6000	2
28	NUT ASS'Y-PULLEY		23161-27000	1
29	BOLT-THROUGH		23131-L6000	1

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL