

TCM[®]

PARTS MANUAL

WHEEL LOADER

LIB-2

TCM CORPORATION

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
1	201N1-12011		CABLE	1	
2	26602-42031		CLIP	3	
3	01183-10020		BOLT & WASHER	3	
4	26191-12011		BRACKET	1	
5	01400-00010		NUT	2	
6	02010-00010		WASHER	2	
A	26401-12051		ACCELERATOR PEDAL ASSY	1	INC.7-10
7	NO PART NO.	#	PEDAL	1	
8	26091-13071		BRACKET	1	
9	26091-13081		PIN	1	
10	02200-32020		PIN,COTTER	2	
11	26405-42211		COVER,PEDAL	1	
12	26093-62171		LINK,BALL	2	
13	01400-00006		NUT	4	
14	02010-00006		WASHER	2	
15	26061-12071		ROD	1	
16	26061-12001		BELLCRANK	1	
17	26601-12081		SPRING	1	
18	01183-08020		BOLT & WASHER	4	
19	01111-10050		BOLT	1	
20	01401-00010		NUT	1	
21	01400-00008		NUT	2	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
1	26192-42132		HARNES,REAR FRAME	1	SEE FIG.11
2	26192-42112		HARNES,ENGINE 1	1	SEE FIG.12
3	26192-42122		HARNES,ENGINE 2	1	SEE FIG.12
4	26192-42101		HARNES,T/M HST	1	SEE FIG.12
5	26192-42082		HARNES,COCKPIT	1	SEE FIG.10
6	26192-42261		HARNES,KEY SWITCH	1	SEE FIG.10
7	26192-42212		HARNES,WORKING LAMP	1	SEE FIG.10
8	26192-42072		HARNES,FRONT FRAME	1	SEE FIG.9

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
1	26192-42152		CABLE,BATTERY	1	
2	26192-42162		CABLE,BATTERY	1	
3	26192-42172		CABLE,BATTERY	1	
4	26192-42182		CABLE,BATTERY	1	
5	01116-10020		BOLT	1	
6	02011-00010		WASHER	1	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
1	26401-07031		RELAY,BATTERY	1	
2	01185-08025		BOLT & WASHER	2	
3	26552-42131		RELAY,GLOW	1	
4	01100-06012		BOLT	2	
5	02010-00006		WASHER	2	
6	26192-42241		BRACKET	1	
7	01185-10020		BOLT & WASHER	2	
8	26192-42251		COVER	1	
9	01185-08016		BOLT & WASHER	2	
10	26192-42012		BRACKET	1	
11	01183-08020		BOLT & WASHER	2	
12	26192-42031		RELAY	11	
13	26602-40261		UNIT,FLASHER	1	
14	01033-05016		SCREW & WASHER	1	
15	01400-00005		NUT	1	
16	26192-42341		CONTROLER,T/M	1	
17	01185-08016		BOLT & WASHER	4	
18	26192-42301		UNIT,CONTROL	1	
19	01185-06012		BOLT & WASHER	2	
20	26192-42092		BOX,FUSE	1	
21	26192-42411		FUSE	7	5A
22	26192-42421		FUSE	7	10A
23	26192-42431		FUSE	5	15A
24	26192-42441		FUSE	1	20A
25	26192-42451		PULLER	1	
26	01185-06025		BOLT & WASHER	4	
27	01032-06020		SCREW & WASHER	2	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
1	02212-10025		PIN	3	
2	16193-42032		COVER	1	
3	03310-01150		O-RING	1	
4	01116-10030		BOLT	4	
5	02010-00010		WASHER	4	
6	03300-00100		O-RING	3	
7	14813-82411		PLUG	1	
8	24047-92101		PLUG	2	
9	16193-42501		SHROUD, A	1	
10	16193-42561		SHROUD, B	1	
11	01106-08012		BOLT	3	
12	02000-00008		WASHER	3	
13	01116-10016		BOLT	2	
14	02010-00010		WASHER	2	
15	16682-52131		PLUG	1	
16	03300-00224		O-RING	1	
17	16193-42231		SPRING	1	
18	16193-42241		SPRING	1	
19	16193-42251		VALVE,PISTON	1	
20	16193-42411		COVER	1	
21	01116-10016		BOLT	2	
22	02010-00010		WASHER	2	
23	09300-00902		PLATE,NAME	1	
24	14092-52141		SCREW	2	
25	16193-40262		CLUTCH, HI-LO	1	SEE FIG.25
26	16193-42051		SHAFT	1	
27	02100-00045		RING,SNAP	1	
28	03007-06309		BEARING	1	
29	16193-42061		SPACER	1	
30	16193-43541		GEAR	1	Z=89
31	16193-43551		GEAR	1	Z=63
32	16193-42091		SEAL,OIL	1	
33	03001-06212		BEARING	1	
34	16193-43521		GEAR	1	
35	03190-00006		BALL	1	
36	16193-43301		SEAL,OIL	1	
37	16193-42151		CASE,BRAKE	1	
38	16193-43151		O-RING	1	
39	01116-10030		BOLT	5	
40	02010-00010		WASHER	5	
A	16393-40211		BRAKE COVER ASSY	1	INC.41-45
41	16393-42201		FLANGE	1	
42	16193-42491		COVER,BRAKE	1	
43	16193-43681		PLATE	1	
44	01119-12025		BOLT	6	
45	02011-00012		WASHER	6	
46	10050-12511		PLUG	1	
47	02110-00052		RING,SNAP	1	
48	16193-42141		BRAKE,PARKING	1	
49	01107-14035		BOLT	4	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
A	16193-40201		CONTROL VALVE ASSY	1	INC.1-13
1	16193-42671		BODY	1	
2	16193-42681		SPOOL	1	
3	16193-43211		SPRING	1	
4	16193-42691		GASKET	1	
5	16193-42701		COVER	1	
6	01170-06020		BOLT	6	
7	16193-42711		CHOKE	1	
8	16193-42721		PISTON	1	
9	16193-42731		SPRING	1	
10	16193-43331		SPRING	1	
11	16193-42741		STOPPER	1	
12	16193-42751		GASKET	1	
13	16193-42661		VALVE,SOLENOID	1	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
A	26192-57391		VALVE ASSY	1	INC.1-12
1	26192-58171		HOUSING	1	
2	26192-57801		PLUG	6	
3	26192-58181		O-RING	2	
4	26192-58191		VALVE,RELIEF	2	
5	26192-58201		SPRING	1	
6	26192-58211		SEAT,SPRING	1	
7	26192-58221		PLUG	1	
8	26192-58231		SPOOL	1	
9	26192-58241		PLUG	3	
10	26192-58251		STOPPER	1	
11	26192-58261		ORIFICE	2	
12	26192-58271		PLUG	1	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
A	16193-00011		AXLE ASSY	1	INC.1-15,FIG.36,FIG.37
1	16403-02042		TUBE,AXLE,RH	1	
2	16403-02052		TUBE,AXLE,LH	1	
3	16403-02061		SHAFT,AXLE	2	
4	16403-02071		SEAL,OIL	2	
5	16403-02081		BEARING	2	
6	16403-02091		BEARING	2	
7	16413-02251		BOLT	2	
8	16413-02271		SHIM	AR	t=1.0mm
-	16413-02281		SHIM	AR	t=0.5mm
-	16413-02291		SHIM	AR	t=0.25mm
-	16413-02301		SHIM	AR	t=0.2mm
-	16413-02311		SHIM	AR	t=0.1mm
9	16193-02021		GEAR,RING	2	Z=58
10	16403-02351		PIN	8	
11	01106-16110		BOLT	28	
12	190A3-02051		WASHER	28	
13	02212-10032		PIN	4	
14	16403-02331		GAUGE,LEVEL	1	
15	NO PART NO.		PLANET CARRIER	2	SEE FIG.38
16	01106-24050		BOLT	24	
17	26604-42011		WASHER	24	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
A1	26193-32021		PROPELLER SHAFT ASSY	1	INC.1-8
1	26403-37001		BEARING,CROSS	1	
2	26403-37011		BEARING,CROSS	2	
A2	26393-37041		CENTER SHAFT ASSY	1	INC.3,4
3	26393-37031		SHAFT,CENTER	1	
4	26403-37031		BLOCK	1	
5	26393-37051		SHAFT,SLEEVE	1	
6	26403-37081		BOLT	12	
7	26403-37091		WASHER	2	
8	26403-37101		FITTING,GREASE	1	
9	01116-16065		BOLT	2	
10	190A3-02051		WASHER	2	
11	02011-00016		WASHER	2	
12	01401-10016		NUT	2	
A3	26193-32011		PROPELLER SHAFT ASSY	1	INC.13-15
13	26403-37001		BEARING,CROSS	2	
14	26193-37031		COUPLING,YOKE	1	
15	26403-37081		BOLT	8	

FIG.45

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
1	26315-43541		TANK,OIL	1	INC.2-5
2	26315-47431		CAP	1	
3	26315-47441		CAP,INNER	1	
4	26315-47451		STRAINER	1	
5	NO PART NO.	#	SWITCH,LEAD	1	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
1	NO PART NO.	#	FRAME,REAR	1	
2	26386-12291		BUSHING	2	
3	26406-12371		PIN	1	
4	01116-12025		BOLT	1	
5	02011-00012		WASHER	1	
6	26096-42351		WASHER	1	
7	26406-12851		COLLAR	1	
8	26406-12381		PIN	1	
9	26406-12831		FLANGE	1	
10	01106-24185		BOLT	1	
11	26316-13761		U-NUT	1	
12	26406-12941		RUBBER,CUSHION	2	
13	01183-12025		BOLT & WASHER	2	
14	02000-00012		WASHER	2	
15	16193-00011		REAR DRIVE AXLE	1	SEE FIG.35
16	01106-20100		BOLT	8	
17	01400-10020		NUT	8	
18	26323-02001		WASHER	16	
19	26403-02001		SUPPORT,FRONT AXLE	1	
20	26403-02061		SUPPORT,REAR AXLE	1	
21	26403-02031		BUSHING	2	
22	26403-02071		PACKING	3	
23	26403-02021		PLATE,THRUST	1	
24	26403-02041		WASHER,THRUST	2	
25	01106-12030		BOLT	6	
26	26403-02011		CAP,THRUST	1	
27	01106-12055		BOLT	6	
28	26063-02111		WASHER	6	
29	26389-12091		LINK,SAFETY	1	
30	26389-12101		PIN,SET	2	
31	26404-52011		PIN	2	
32	01116-12025		BOLT	2	
33	02011-00012		WASHER	2	
34	26096-42351		WASHER	2	
35	04901-00160		FITTING,GREASE	2	
36	26316-13141		SPACER	AR	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
1	26196-42002		SUPPORT,GRILLE	1	
2	01220-12035		BOLT & WASHER	4	
3	26196-42042		ANGLE	1	
4	01220-12025		BOLT & WASHER	2	
5	26196-42012		HOOD	1	
6	01220-12025		BOLT & WASHER	4	
7	26102-12141		RUBBER,CAP	2	
8	26196-42102		GRILLE	1	
9	01183-10020		BOLT & WASHER	4	
10	02000-00010		WASHER	4	
11	26196-42142		COVER,SIDE	1	
12	01183-10020		BOLT & WASHER	2	
13	26091-12081		WASHER	2	
14	26406-42191		PLATE	1	
15	01183-10020		BOLT & WASHER	2	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
A	56060-58031		ROOF ASSY	1	INC.1-6
1	56060-58041		ROOF	1	
2	56330-50781		STRIP,RUBBER	4	
3	56500-54261		WASHER	8	
4	26096-42351		WASHER	4	
5	02010-00012		WASHER	4	
6	01400-00012		NUT	4	
7	01110-12090		BOLT	4	
8	26312-12021		WASHER	8	
9	01401-00012		NUT	8	
10	26409-52002		STAY,LH	1	
11	26409-52012		STAY,RH	1	
12	01110-16040		BOLT	6	
13	02010-00016		WASHER	6	
14	01401-00016		NUT	6	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
1	26197-12001		GEAR PUMP	1	SEE FIG.67
2	26197-92301		O-RING	1	
3	01116-12040		BOLT	4	
4	26063-02111		WASHER	4	
5	26197-62032		PIPE,SUCTION	1	
6	03350-00500		O-RING	1	
7	01116-12035		BOLT	4	
8	26197-62012		PIPE,SUCTION	1	
9	03350-00350		O-RING	2	
10	01170-08030		BOLT	8	
11	26197-62021		PIPE,SUCTION	1	
12	26197-62101		HOSE	1	
13	26197-62111		HOSE	1	
14	26607-82381		HOSE	1	
15	26197-62191		CLAMP	2	
16	26197-62211		CLAMP	2	
17	26197-62201		CLAMP	2	
18	26197-62062		HOSE	1	
19	26197-62141		O-RING	1	
20	26607-62571		FLANGE,SPLIT	2	
21	26607-62631		O-RING	1	
22	01116-10030		BOLT	4	
23	26197-62041		ELBOW	2	INC.24
24	26197-62181		O-RING	2	
25	26197-62071		HOSE	1	
26	26197-62141		O-RING	1	
27	26197-62051		PLUG	1	INC.28
28	26097-62701		O-RING	1	
29	26437-62341		ELBOW	2	INC.30
30	03320-00290		O-RING	2	
31	26197-62081		HOSE	1	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
1	04150-20404		ELBOW	2	
2	26197-92202		HOSE	1	
3	26197-92371		FILTER,OIL	1	INC.4,5
4	26197-97001		ELEMENT	1	
5	03310-00650		O-RING	1	
6	01183-10100		BOLT & WASHER	2	
7	26197-92091		ELBOW	1	INC.8
8	03320-00180		O-RING	1	
9	26197-92071		ELBOW	1	INC.10
10	26097-62631		O-RING	1	
11	26397-92041		HOSE	1	
12	26197-92101		ELBOW	2	INC.13
13	26097-62701		O-RING	2	
14	26197-92221		HOSE	1	
15	26197-92051		ADAPTER	1	INC.16
16	26097-62701		O-RING	1	
17	26197-92081		ELBOW	1	INC.18
18	26097-62701		O-RING	1	
19	26197-92231		HOSE	1	
20	26197-92051		ADAPTER	1	INC.21
21	26097-62701		O-RING	1	
22	26197-92081		ELBOW	1	INC.23
23	26097-62701		O-RING	1	
24	26197-92242		HOSE	1	
25	26602-42931		CLIP	4	
26	01110-10020		BOLT	2	
27	02010-00010		WASHER	2	
28	26197-92051		ADAPTER	2	INC.29
29	26097-62701		O-RING	2	
30	26197-92081		ELBOW	2	INC.31
31	26097-62701		O-RING	2	
32	26197-92251		HOSE	1	
33	26197-92261		HOSE	1	
34	04913-10200		INSULOCK	1	
35	26602-42181		CLIP	1	
36	01110-10020		BOLT	1	
37	02010-00010		WASHER	1	
38	01401-00010		NUT	1	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
A	26408-42001		BOOM CYLINDER ASSY	2	INC.1-21
K1	26408-47161		CYLINDER TUBE KIT	2	INC.1,15
1	NO PART NO.	*#	BODY,CYLINDER	2	
2	26408-47011		ROD,PISTON	2	
3	26408-47021		HEAD,CYLINDER	2	
K2	26408-47131		OVERHAUL KIT	2	INC.4,6-9,11,12
K3	26408-47141		SEAL KIT	2	INC.4,6-9
4	26408-47031	*	U-RING	2	
5	26408-47041		BUSHING	2	
6	26408-47051	*	RING,WIPER	2	
7	28778-47511	*	O-RING	2	
8	28778-47521	*	RING,BACK-UP	2	
9	28778-47531	*	O-RING	2	
10	26408-47061		PISTON	2	
K4	26408-47151		SEAL KIT	2	INC.11,12
11	26328-57171	*	RING,SEAL	2	
12	28778-47561	*	RING,SLIDE	4	
13	28778-47331		SCREW,SET	2	
14	28778-47341		BALL,STEEL	2	
15	26388-57441	*	BUSHING	2	
16	26388-57491		RING,WIPER	4	
17	26408-47071		PIPE	2	
18	26408-47081		PIPE	2	
19	26408-47091		HOLDER,PIPE	4	
20	26408-47111		BOLT	4	
21	26408-47121		WASHER	4	

Item No.	Part No.	Mark	Description	Req'd	Remarks : serial No.
A	26199-20001		TOOLS ASSY	1	INC.1-8
1	26099-22021		BAG,TOOL	1	
A2	26609-22011		GREASE PUMP ASSY	1	INC.2-4
2	26609-27001		PIPE	1	
3	26609-27011		LEVER	1	
4	26609-27021		NOZZLE	1	
5	26609-20201		SET,SPANNER	1	
6	24539-20033		SPNNER,BOX	1	
7	26319-22082		ARM,BOX SPANNER	1	
8	26759-12171		TAG,WARNING	1	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL