



**WACKER
NEUSON**
all it takes!



Product Guide

ET18 ET20 ET24

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Canopy – versions



Single door cab



Single door cab with sliding window
(option)



Two door cab (option)

Cab / Canopy features

Removal:


- The cab/canopy can be removed from the chassis by unscrewing 4 bolts.
- The only electrical connection to be disconnected is for the windscreen wiper; the screen wash container stays in the cab.

Benefits:


- Very easy and rapid removal is possible
- Machine operations remain unaffected

New:

Identification and covers of the bulbs for the cab removal



Cab



Dimensions

- The new cabin design offers a
- Lower overall machine height
 - Significantly more room inside the cab
 - Convenient access to the cab

Cab entry height is significantly reduced:


Depending on the model and version
between 40 and 80 mm
reduction in entry height



Tilt console

Hose routing arrangement through the tilt console

- Offers the best protection against damage
- No limitation of the field of vision



Rear counterweight

Solid cast steel, covering the side and rear area

- Optimal rear protection
- increases stability



Seat console

Deep drawn sheet steel with built-in maintenance,

- Can be tilted forwards
- New shape

Benefits:

- Time and cost saving in maintenance and repairs
- Greater operator comfort thanks to more room

Maintenance cover



Exhaust system

- Exhaust muffler directly mounted on the diesel engine
- Component reduction



Diesel engine



Additional weights for options per model

	WN ET18 1580.0 [kg]	WN ET20 1860.0 [kg]	WN ET24 2055.0 [kg]
Basic machine¹ (see price list)			
consists of dipper short, pusher blade short, undercarriage standard, canopy			
Transport weight of basic machine	1582.0 [kg]	1862.0 [kg]	2057.0 [kg]
Transport weight of basic machine	1724.8 [kg]	2004.8 [kg]	2199.8 [kg]
Available options (are simply added to the basic machine)			
dipper long	12.0 [kg]	12.0 [kg]	14.0 [kg]
tele – undercarriage	124.8 [kg]	standard	not available
VDS (ET18: opt. tele – undercarriage to be added!!)	110.3 [kg]	78.6 [kg]	108.8 [kg]
Available options cab:			
Back windscreen for canopy	8.8 [kg]	8.8 [kg]	8.8 [kg]
Cab 2-door	115.3 [kg]	115.3 [kg]	115.3 [kg]
Cab 1-door (sliding windows)	108.8 [kg]	108.8 [kg]	108.8 [kg]
Cab	106.8 [kg]	106.8 [kg]	106.8 [kg]
FOPS / TOPS II protective grill	16.2 [kg]	16.2 [kg]	16.2 [kg]
Protective grill front windscreen	41.8 [kg]	41.8 [kg]	41.8 [kg]
Split protection	17.0 [kg]	17.0 [kg]	17.0 [kg]
Pusher blade long	9.8 [kg]	7.0 [kg]	not available
Available options hydraulics:			
3rd control circuit proportion controlled	7.5 [kg]	7.5 [kg]	7.5 [kg]
Flat sealing connection	0.3 [kg]	0.3 [kg]	0.3 [kg]
Control circuit grab	6.7 [kg]	6.7 [kg]	6.7 [kg]
Overload warning device DE	6.8 [kg]	6.8 [kg]	6.8 [kg]
Overload warning device FR	14.7 [kg]	14.7 [kg]	14.7 [kg]
Overload warning device FR +LH 15.7 [kg]	15.7 [kg]	15.7 [kg]	
Pre-arrangement HSWS	10.5 [kg]	10.5 [kg]	10.5 [kg]
Pre-arrangement Powertilt	6.8 [kg]	6.8 [kg]	6.8 [kg]
Add-on tools:			
EasyLock	18.8 [kg]	18.8 [kg]	18.8 [kg]
EasyLock + Powertilt+ Load hook.	56.0 [kg]	56.0 [kg]	56.0 [kg]
EasyLock + Powertilt	55.0 [kg]	55.0 [kg]	55.0 [kg]
Available tools:			
Excavator bucket 300mm	43.0 [kg]	43.0 [kg]	43.0 [kg]
Excavator bucket 400mm (standard excavator bucket)	50.0 [kg]	50.0 [kg]	50.0 [kg]
Excavator bucket 500mm	60.0 [kg]	60.0 [kg]	60.0 [kg]
Excavator bucket 600mm	67.0 [kg]	67.0 [kg]	67.0 [kg]
Ditch cleaning bucket 850mm	63.0 [kg]	63.0 [kg]	63.0 [kg]
Ditch cleaning bucket 1000mm	72.0 [kg]	72.0 [kg]	72.0 [kg]
Ditch cleaning bucket 1200mm	84.0 [kg]	84.0 [kg]	84.0 [kg]
Swivel bucket 850mm	103.0 [kg]	103.0 [kg]	103.0 [kg]
Swivel bucket 1000mm	110.0 [kg]	110.0 [kg]	110.0 [kg]
Swivel bucket 1200mm	121.0 [kg]	121.0 [kg]	121.0 [kg]
For info:			
Diesel tank capacity full 24 [l]	19.8 [kg]	19.8 [kg]	19.8 [kg]
Diesel tank capacity 10%	2.0 [kg]	2.0 [kg]	2.0 [kg]
Machine operator	75.0 [kg]	75.0 [kg]	75.0 [kg]

Definitions:

Transport weight: weight of basic machine + weight at 10% of fuel tank capacity

Operating weight: weight of basic machine + wake-up machine operator + weight of full fuel tank capacity + weight of standard dipper

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to **CLICKING** the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL