

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below





- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


M	Item No.	Page	Part No.	Description	Quant.	Unit	Remarks
	1	002	58290249	Door	1,000		
	2	002	05932113	Lock	1,000		
	3	002	07320825	Countersunk screw	2,000		
	4	002	07230605	Socket-head cap screw	1,000		
	5	002	08510612	Washer	1,000		
	6	002	05932121	Push button handle	1,000		
	7	002	32110086	Reversing lever	1,000		
	8	002	07140622	Hexagon bolt	1,000		
	9	002	08751064	Spring washer	2,000		
	10	002	08110620	Hexagon nut	1,000		
	11	002	58290266	Rod	1,000		
	12	002	08510409	Washer	1,000		
	13	002	08130408	Safety nut	1,000		
	14	002	32110073	Retaining strip	1,000		
	15	002	07130842	Hexagon bolt	2,000		
	16	002	08510817	Washer	4,000		
	17	002	08130813	Safety nut	2,000		
	18	002	05932106	Door catch	1,000		
	19	002	05932105	Base	1,000		
	20	002	07210625	Lens head screw	3,000		
	22	002	05581123	Gas spring	1,000		
	23	002	08752084	Spring washer	2,000		
	24	002	05570180	Arm rest	1,000		
	25	002	32110273	Claw	1,000		
	26	002	07320608	Countersunk screw	2,000		
	27	002	32110325	Trim	1,000		
	28	002	07813916	Parker screw	4,000		


Cannot print image C:\Users\ADMINI~1\AppData\Local\Temp\121846003379.tif!
Error during loading: (7)





M	Item No.	Page	Part No.	Description	Quant.	Unit	Remarks
	1	001	31710022	Diesel engine	1,000		
	2	001	58180290	Engine bracket	1,000		
	3	001	07131212	Hexagon bolt	4,000		
	4	001	08752130	Spring washer	4,000		
	5	001	06170031	Engine support	1,000		
	6	001	07131212	Hexagon bolt	2,000		
	7	001	08511324	Washer	4,000		
	8	001	08111218	Hexagon nut	2,000		
	9	001	07131270	Hexagon bolt	1,000		
	10	001	58180224	Engine bracket	1,000		
	11	001	08752130	Spring washer	2,000		
	12	001	40080411	Shim	1,000		
	13	001	08131218	Safety nut	1,000		
	14	001	58180289	Engine bracket	1,000		
	15	001	07131212	Hexagon bolt	4,000		
	16	001	08752130	Spring washer	4,000		
	17	001	07131212	Hexagon bolt	2,000		
	18	001	08511324	Washer	4,000		
	19	001	08111218	Hexagon nut	2,000		
	20	001	06170031	Engine support	1,000		
	21	001	58180224	Engine bracket	1,000		
	22	001	07131270	Hexagon bolt	1,000		
	23	001	08752130	Spring washer	2,000		
	24	001	40080411	Shim	1,000		
	25	001	08131218	Safety nut	1,000		
	26	001	58180152	Engine bracket	1,000		
	27	001	07131212	Hexagon bolt	3,000		






M	Item No.	Page	Part No.	Description	Quant.	Unit	Remarks
	1	001	05272011	Spherical plain bearing	1,000		
	2	001	05276112	Spherical plain bearing	2,000		
	3	001	05521801	Shim	2,000		
	4	001	05521803	Shim	1,000		
	5	001	05521805	Shim	1,000		
	6	001	05521830	Supporting disc	1,000		
	7	001	06235300	V-ring	1,000		
	8	001	07132021	Hexagon bolt	12,000		
	9	001	07141242	Hexagon bolt	4,000		
	10	001	07241012	Socket-head cap screw	4,000		
	11	001	08511324	Washer	4,000		
	12	001	08512136	Washer	12,000		
	13	001	09291001	Belleville spring	2,000		
	14	001	58040110	Friction bearing	1,000		
	15	001	58040111	Sealing ring	1,000		
	16	001	58040123	Support	1,000		
	17	001	58040125	Housing	1,000		
	18	001	58040128	Intermediate ring	1,000		
	19	001	58040129	Intermediate ring	1,000		
	20	001	58040130	Cover	1,000		
	21	001	58040145	Cover	1,000		

M	Item No.	Page	Part No.	Description	Quant.	Unit	Remarks
	1	002	07140824	Hexagon bolt	4,000		
	2	002	08752084	Spring washer	4,000		
	3	002	07140824	Hexagon bolt	4,000		
	4	002	07140834	Hexagon bolt	2,000		
	5	002	08110813	Hexagon nut	2,000		
	6	002	08752084	Spring washer	12,000		
	7	002	58050325	Angle	1,000		
	8	002	58050324	Angle	1,000		
	9	002	58050345	Insulating mat	1,000		
	10	002	58050370	Plate	1,000		
	11	002	07130826	Hexagon bolt	1,000		
	12	002	58050350	Insulating mat	3,000		
	13	002	08510817	Washer	1,000		
	14	002	58080112	Flat steel	1,000		
	15	002	69230105	Tube	1,000		
	16	002	58050323	Brush	2,000		
	18	002	58050398	Guide	6,000		
	19	002	58050321	Angle	2,000		
	20	002	08752106	Spring washer	2,000		
	21	002	07141027	Hexagon bolt	4,000		
	22	002	07141041	Hexagon bolt	2,000		
	23	002	58050395	Lock	1,000		
	24	002	58050335	Plate	1,000		
	25	002	58050320	Flat steel	1,000		
	27	002	00652108	Expanded rubber	5	m	
	29	002	07140814	Hexagon bolt	4,000		
	30	002	07140842	Hexagon bolt	12,000		

M	Item No.	Page	Part No.	Description	Quant.	Unit	Remarks
	1	001	07131662	Hexagon bolt	4,000		
	2	001	07141027	Hexagon bolt	2,000		
	3	001	08111625	Hexagon nut	8,000		
	4	001	08752106	Spring washer	2,000		
	5	001	58140180	Operator's platform	1,000		
	9	001	58140162	Washer	4,000		
	10	001	58140125	Washer	4,000		
	11	001	58140126	Handle bar	1,000		
	12	001	58140148	Plate	1,000		
	13	001	07140848	Hexagon bolt	4,000		
	15	001	08510817	Washer	4,000		
	16	001	05726095	Glower starter switch	1,000		
	17	001	05755124	Key,ignition BOMAG	1,000		
	19	001	05755515	Socket	2,000		
	20	001	58140152	Plate	2,000		
	21	001	06510145	Plug	1,000		
	22	001	06510232	Plug	1,000		
	23	001	07140626	Hexagon bolt	4,000		
	24	001	08751064	Spring washer	4,000		
	25	001	06510208	Plug	3,000		
	26	001	06510212	Plug	2,000		
	27	001	06510114	Protection plug	3,000		
	28	001	06510140	Plug	1,000		



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below




- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


M	Item No.	Page	Part No.	Description	Quant.	Unit	Remarks
	71	002	05570034	Seat,upper part	1,000		
	72	002	05570009	Socket-head cap screw	4,000		
	73	002	05570033	Cover	1,000		
	74	002	05570035	Rivet,blind	1,000		
	75	002	05570036	Bar	1,000		
	76	002	05570201	Plug	10,000		
	77	002	05570049	Shock absorber	1,000		
	78	002	05570048	Bolt	2,000		
	79	002	05727273	Safety washer	2,000		
	80	002	05570064	Adjusting spindle	1,000		
	81	002	05570056	Bearing, ball	1,000		
	82	002	05570058	Nut	1,000		
	83	002	05570061	Dowel pin	1,000		
	84	002	05570063	T-bar	1,000		
	85	002	05570062	Centergrooved dowel pin	1,000		
	86	002	05570069	Ring	1,000		
	87	002	05570071	Bellows	1,000		
	88	002	05570201	Plug	21,000		
	89	002	05570070	Bar	2,000		
	90	002	05570041	Swaying unit	1,000		
	91	002	05570038	Bolt	1,000		
	92	002	05570039	Bushing	4,000		
	93	002	05727277	Safety washer	1,000		
	94	002	05570042	Bolt	1,000		
	95	002	05570043	Roller	4,000		
	96	002	05570044	Bar	1,000		
	97	002	05570045	Tension spring	2,000		







M	Item No.	Page	Part No.	Description	Quant.	Unit	Remarks
	1	003	05766480	Module	1,000		
	2	003	58270146	Pillow block	1,000		
	3	003	07140848	Hexagon bolt	4,000		
	4	003	08752084	Spring washer	8,000		
	5	003	58003295	Plate	2,000		
	6	003	58270147	Flat steel	4,000		
	7	003	07210895	Lens head screw	4,000		
	8	003	17110203	Angle	1,000		
	9	003	07140820	Hexagon bolt	1,000		
	10	003	08752084	Spring washer	2,000		
	11	003	08110813	Hexagon nut	1,000		
	12	003	05551913	Tube clamp	1,000		
	13	003	07140629	Hexagon bolt	1,000		
	14	003	08751064	Spring washer	2,000		
	15	003	08110620	Hexagon nut	1,000		
	16	003	58003298	Angle	1,000		
	17	003	15020310	Washer	4,000		
	18	003	07320641	Countersunk screw	2,000		
	19	003	07140820	Hexagon bolt	1,000		
	20	003	08752084	Spring washer	1,000		
	21	003	58003270	Box	1,000		
	22	003	58250154	Gasket	1,000		
	23	003	58250155	Gasket	1,000		
	24	003	07140834	Hexagon bolt	4,000		
	25	003	08752084	Spring washer	4,000		
	26	003	08110813	Hexagon nut	4,000		
	27	003	07130516	Hexagon bolt	2,000		

M	Item No.	Page	Part No.	Description	Quant.	Unit	Remarks
	2	001	07140853	Hexagon bolt	1,000		
	3	001	07230847	Socket-head cap screw	4,000		
	4	001	08110813	Hexagon nut	4,000		
	5	001	08130813	Safety nut	4,000		
	6	001	08510817	Washer	4,000		
	8	001	58080102	Pillow block	1,000		
	9	001	58080103	Pillow block	1,000		
	10	001	58080104	Threaded rod	2,000		
	11	001	58080115	Flat steel	1,000		
	12	001	58080119	Pillow block	1,000		
	13	001	58080101	Pillow block	1,000		
	14	001	58080137	Pillow block	1,000		
	16	001	07130826	Hexagon bolt	1,000		
	17	001	58080112	Flat steel	1,000		
	18	001	07231235	Socket-head cap screw	2,000		
	20	001	58080123	Cover plate	1,000		
	21	001	08590820	Washer	8,000		
	22	001	58080124	Cable guidance	1,000		
	23	001	08510817	Washer	1,000		
	25	001	58080133	Flat steel	1,000		
	26	001	06910101	Fastening clamp	1,000		
	27	001	07130628	Hexagon bolt	2,000		
	28	001	58080134	Spacer piece	1,000		
	29	001	07231235	Socket-head cap screw	2,000		
	30	001	58080115	Flat steel	1,000		
	31	001	58080137	Pillow block	2,000		
	32	001	08510817	Washer	6,000		








M	Item No.	Page	Part No.	Description	Quant.	Unit	Remarks
	0	001	05817039	Travel motor	1,000		
	1	001	05817842	Kit,seal	1,000		
	2	001	05817937	Valve plate	1,000		
	3	001	05817940	Bearing plate	1,000		
	4	001	05817939	Cylinder block	1,000		
	8	001	05817954	Joint	1,000		
	12	001	05817938	Housing	1,000		
	13	001	05817957	Magnet ring	1,000		
	14	001	05817949	Shaft	1,000		
	15	001	05817955	Piston ring set	1,000		
	26	001	05817964	Loop ring	1,000		
		001					
		001					
	27	001	05817115	Radial seal 673525	1,000		
	28	001	05817963	Housing,bearing	1,000		
	29	001	05817965	Socket-head cap screw	8,000		
	33	001	05817947	Gasket	1,000		
		001					
		001					
	34	001	32043052	Pin,cylindric	2,000		
	36	001	05817154	Screw plug	1,000		
	37	001	05817958	Tapped pin	1,000		
	38	001	05817959	Seal lock nut	1,000		
		001					
		001					
	39	001	05817956	Cap	1,000		
	40	001	05817154	Screw plug	1,000		




E91352








M	Item No.	Page	Part No.	Description	Quant.	Unit	Remarks
	1	001	05579032	Compressor	1,000		
	2	001	07231019	Socket-head cap screw	2,000		
	3	001	05579017	Loop ring	2,000		
	4	001	05579029	Shut-off valve	1,000		
	5	001	05579030	Shut-off valve	1,000		
	6	001	58003631	Holder	1,000		
	7	001	07140842	Hexagon bolt	3,000		
	8	001	08752084	Spring washer	3,000		
	9	001	58003729	Back stop	1,000		
	10	001	07140846	Hexagon bolt	1,000		
	11	001	08752084	Spring washer	1,000		
	12	001	58003342	Tube	1,000		
	13	001	07140842	Hexagon bolt	1,000		
	14	001	08510817	Washer	1,000		
	15	001	08500823	Round anchor plate	1,000		
	16	001	08130813	Safety nut	1,000		
	17	001	06312256	V-belt	1,000		
	18	001	58003629	Belt pulley	1,000		
	19	001	58003727	Spacer piece	1,000		
	20	001	05766433	Relay 12V	3,000		
	21	001	05726842	Relay base	3,000		
	22	001	07210506	Lens head screw	3,000		
	23	001	08510511	Washer	6,000		
	24	001	05752951	Diode cable	1,000		
	25	001	58260232	Wiring	1,000		
		001					
		001					





CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL