

SPARE PART CATALOG



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

engine

Item no.	Article no.	Description	Remark	Quantity
1	1000213284	diesel engine		1
2	1000199755	propeller		1
3	1000226630	v-belt	10X775<06.2009	1
4	1000226623	bulb		1
5	1000251226	clutch flange		1
6	1000225421	seal		1
7	1000209633	bracket		1
8	1000209634	bracket		1
9	1000209635	bracket		1
10	1000209636	bracket		1
11	1000228610	rubber buffer		2
12	1000228613	rubber buffer		2
13	1000202316	angle bracket		2
14	1000199794	distance piece		1
15	1000202412	screw		4
16	1000013009	hex screw		1
17	1000085476	cheese head screw		1
18	1000222611	u-washer		6
19	1000015376	cheese head screw		2
20	1000224910	o-ring		8
21	1000198967	earth cable		1
22	1000198976	earth cable		1
23	1000238664	insulating hose		1
24	1000219580	pvc hose		1



exhaust components >10.2006

Item no.	Article no.	Description	Remark	Quantity
25	1000085355	hex screw		2
26	1000022016	spring washer		4
27	1000222588	u-washer		5
28	1000015407	hexagon nut		2
29	1000263194	torx screw	Torx screw	4



cylinder block

Item no.	Article no.	Description	Remark	Quantity
1	1000199750	lock plug		3
2	1000199589	lock plug		1
3	1000199592	lock plug		2
4	1000199597	lock plug		5
5	1000199906	lock plug		2
6	1000199907	lock plug		1
7	1000206793	lock plug		1
8	1000245605	oil pump		1
9	1000244934	bushing		1
10	1000199359	lock plug		1
11	1000199576	bushing		1
12	1000199939	cylinder pin		2
13	1000205304	stud bolt		3
14	1000199942	cylinder pin		2
15	1000199943	cylinder pin		2
16	1000199756	cylinder pin		2
17	1000202586	stud bolt		1
18	1000202587	stud bolt		1
19	1000258621	lock plug		1
20	1000244935	bushing		1
21	1000199452	bearing		1
22	1000258622	bushing		1
23	1000258623	plate		1
24	1000200060	seal		1



crank shaft

Item no.	Article no.	Description	Remark	Quantity
1	1000258626	crank shaft		1
2	1000258627	Gear wheel		1
3	1000199984	fitting key		1
4	1000258629	Bearing block		1
5	1000200175	screw		6
6	1000199940	cylinder pin		8
7	1000199989	screw		3
8	1000205307	Bearing block		1
9	1000205308	Bearing block		1
10	1000205309	Bearing block		1
11	1000205311	screw		2
12	1000200076	screw		2
13	1000258630	Bearing set		1



controlhousing

Item no.	Article no.	Description	Remark	Quantity
25	1000199615	lever		1
26	1000200163	lock ring		1
27	1000258637	o-ring		1
28	1000199876	shaft seal		1



injection nozzle

Item no.	Article no.	Description	Remark	Quantity
1	1000258651	injection line		1
2	1000206857	clamp		2
3	1000234017	leakoil line		1
4	1000206858	banjo bolt		1
5	1000206859	u-washer		1
6	1000244984	injection nozzle		1
7	1000199847	Gasket		1



oil filter

Item no.	Article no.	Description	Remark	Quantity
1	1000258659	filter		1
2	1000199930	thread piece		1



fuel filter

Item no.	Article no.	Description	Remark	Quantity
1	1000087160	fuel filter		1
2	1000258644	fuel filter		1
3	1000199932	SEAL RING		2
4	1000086369	seal		2
5	1000205608	lock plug		1
6	1000200035	SEAL RING		1
7	1000199886	lock screw		2
8	1000200034	SEAL RING		2
9	1000258643	Plug		2
10	1000206873	bracket fuelfilter		1
11	1000206679	screw		2
12	1000199588	u-washer		2
13	1000258619	nut		2
14	1000199421	spring washer		2
15	1000199988	screw		2
16	1000244813	u-washer		2
17	1000258641	fuel line		1
18	1000101948	olive		2
19	1000205607	fuel line		1
20	1000199617	fuel line		1
21	1000199528	hose clamp		2



drive

Item no.	Article no.	Description	Remark	Quantity
1	1000244994	belt pulley		1
2	1000206885	Nut		1
3	1000199430	fitting key		1
4	1000199599	cover		2
5	1000258618	engine gasket		1
6	1000224977	o-ring		1
7	1000258619	nut		4
8	1000199524	nut		4



shaft seal

Item no.	Article no.	Description	Remark	Quantity
1	1000205312	shaft seal		1



oil line

Item no.	Article no.	Description	Remark	Quantity
1	1000244957	engine oil pipe		1
2	1000199920	banjo bolt		1
3	1000200058	SEAL RING		2



injection line

Item no.	Article no.	Description	Remark	Quantity
1	1000214326	injection line		1
2	1000214327	injection line		1
3	1000214329	injection line		1
4	1000214328	injection line		1
5	1000199444	bracket		6
6	1000199433	screw		3
7	1000199519	Nut		3



cooling system

Item no.	Article no.	Description	Remark	Quantity
1	1000199856	belt pulley		1
2	1000199755	propeller		1
3	1000199794	distance piece		1
4	1000202412	screw		4



belt pulley

Item no.	Article no.	Description	Remark	Quantity
1	1000244994	belt pulley		1
2	1000206885	Nut		1
3	1000199430	fitting key		1



valve cover

Item no.	Article no.	Description	Remark	Quantity
1	1000245007	CYLINDER HEAD, VALVE COVER		1
2	1000212118	valve cover seal		1
3	1000199900	filter		1
4	1000206891	plate		1
5	1000205914	screw		4
6	1000199994	Nut		4
7	1000200058	SEAL RING		4
8	1000205765	valve		1
9	1000244411	screw		4
10	1000281999	screw		2
11	1000202455	screw		5
12	1000245008	end piece		1
13	1000206893	exh.manifold gasket		1
14	1000202412	screw		2



switch

Item no.	Article no.	Description	Remark	Quantity
1	1000206886	oil pressure switch		1
2	1000200058	SEAL RING		1
3	1000199920	banjo bolt		1
4	1000206789	lock screw		1



cooling 02.2008 403D-15

Item no.	Article no.	Description	Remark	Quantity
1	1000210555	combicooler		1
2	1000199394	cooler cap		1
3	1000223542	hose clamp		2
4	1000223538	hose clamp		2
5	1000221608	cooler water hose		1
6	1000298362	cooler water hose		1
7	1000085588	hexagon nut		6
8	1000082237	hex screw		6
9	1000222604	u-washer		12
10	1000209776	ventilator cap		1
11	1000228561	rubber buffer		2
12	1000222577	u-washer		4
13	1000022016	spring washer		4
14	1000015407	hexagon nut		4
15	1000222368	pvc hose		1
16	1000274698	foam strap		1
17	1000202215	hose clamp		2
18	1000238658	foam strap		1



drive unit <11.2009

Item no.	Article no.	Description	Remark	Quantity
25	1000221750	Hose		1
26	1000221547	Hose		1
27	1000217486	Hose		1
28	1000221646	Hose		1
29	1000220555	Hose		1
30	1000226181	screw connection		1
31	1000224256	square ring		4
32	1000028689	half flange		8
33	1000082242	cheese head screw		16
34	1000194721	non return valve		1
35	1000018398	screw joint		1
36	1000015517	screw joint		2
37	1000015539	screw joint		1
38	1000103420	screw joint		1
39	1000085089	screw joint		1
40	1000015519	screw joint		1
41	1000225976	screw connection		1
42	1000225977	screw connection		1
43	1000225997	screw connection		1
44	1000226175	screw connection		1
45	1000231370	venting filter		1
46	1000047678	hex screw		1
47	1000022016	spring washer		17
48	1000222577	u-washer		7



drive unit >11.2009 High pressure powertrain

Item no.	Article no.	Description	Remark	Quantity
1	1000254225	modification kit		1
2	1000252424	fastener angle		2
3	1000015364	hex screw		2
4	1000222577	u-washer		11
5	1000015408	hexagon nut		5
6	1000015346	hex screw		3
7	1000047678	hex screw		1
8	1000022016	spring washer		1
9	1000231370	venting filter		1
10	1000231440	reflux filter		1
11	1000223085	filter cover		1
12	1000225482	oil tank cap gasket		1
13	1000226496	oil filler pipe		1
14	1000224914	o-ring		1
15	1000231365	filter insert		1
16	1000224858	o-ring		1
17	1000224909	o-ring		1
18	1000223198	hex screw		2
19	1000015432	u-washer		2
20	1000225995	screw connection		1
21	1000221646	Hose		1
22	1000015517	screw joint		2
23	1000220555	Hose		1
24	1000226181	screw connection		1



front axle `Serial-No: 31289370

Item no.	Article no.	Description	Remark	Quantity
1	1000233511	front axle		1
2	1000210192	differential housing		1
3	1000210214	planetary housing		1
4	1000210191	axle pipe		2
5	1000210215	flange		2
6	1000210216	brake support		1
7	1000210246	ring		1
8	1000248811	pinion set		1
9	1000210237	flange		1
10	1000210309	differential housing		1
11	1000210245	axle shaft		2
12	1000210249	piston		1
13	1000224891	o-ring		1
14	1000210199	pressure spring		1
15	1000210255	washer		1
16	1000210247	ring		2
17	1000210248	brake drum		1
18	1000210264	brake		1
19	1000225253	ball bearing		2
20	1000225309	roller bearing		1
21	1000225681	roller bearing		1
22	1000224645	roller bearing		1
23	1000224367	roller bearing		1
24	1000225291	bearing		1



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

front axle >Serial-No: 31289371

Item no.	Article no.	Description	Remark	Quantity
49	1000223659	lock screw		1
50	1000223164	fitting disc		1
51	1000223166	fitting disc		1
52	1000223165	fitting disc		1
53	1000223412	fitting disc		1
54	1000223414	fitting disc		1
55	1000223413	fitting disc		1
56	1000223167	fitting disc		1
57	1000223168	fitting disc		1
58	1000223415	fitting disc		1
59	1000223169	fitting disc		1
60	1000223170	fitting disc		1
61	1000223171	fitting disc		1
62	1000223172	fitting disc		1
63	1000223173	fitting disc		1
64	1000223174	fitting disc		1
65	1000015407	hexagon nut		16
66	1000215186	venting valve		1
67	1000022016	spring washer		8
68	1000222553	hex screw		16
69	1000226185	screw connection		1
70	1000210254	shift sleeve		1



rear axle Serial-No: 3128937

Item no.	Article no.	Description	Remark	Quantity
25	1000224645	roller bearing		1
26	1000224367	roller bearing		1
27	1000225722	cylinder roller bearing		2
28	1000003117	ball bearing		1
29	1000225305	ball bearing		1
30	1000225291	bearing		1
31	1000225271	shaft seal		1
32	1000225272	shaft seal		1
33	1000225696	shaft seal		2
34	1000225270	shaft seal		1
35	1000224898	o-ring		2
36	1000224902	o-ring		2
37	1000224919	o-ring		2
38	1000224936	o-ring		1
39	1000222981	inner hexagon screw		6
40	1000222693	hex screw		20
41	1000085404	hex screw		14
42	1000222553	hex screw		16
43	1000085419	hex screw		22
44	1000047711	hex screw		1
45	1000222982	stud		8
46	1000222984	stud		2
47	1000226185	screw connection		1
48	1000222699	lock screw		1



rear axle >Serial-No: 31289371

Item no.	Article no.	Description	Remark	Quantity
49	1000085307	lock screw		1
50	1000222514	set nut		2
51	1000215186	venting valve		1
52	1000222584	seal ring		1
53	1000224021	seal ring		2
54	1000223175	cylinder pin		2
55	1000223659	lock screw		1
56	1000223164	fitting disc		1
57	1000223166	fitting disc		1
58	1000223165	fitting disc		1
59	1000223414	fitting disc		1
60	1000223412	fitting disc		1
61	1000223413	fitting disc		1
62	1000223167	fitting disc		1
63	1000223168	fitting disc		1
64	1000223169	fitting disc		1
65	1000223168	fitting disc		1
66	1000223170	fitting disc		1
67	1000223415	fitting disc		1
68	1000223171	fitting disc		1
69	1000223172	fitting disc		1
70	1000223173	fitting disc		1
71	1000223174	fitting disc		1
72	1000222709	u-washer		2



brake assembly

Item no.	Article no.	Description	Remark	Quantity
1	1000210681	pedal lever		1
2	1000196803	parking brake lever		1
3	1000230163	masterbrake cylinder		1
4	1000192754	brake fluid container		1
5	1000192724	cover		1
6	1000205077	brake pedal		1
7	1000085057	screw joint		1
8	1000199114	solenoid valve		1
9	1000226185	screw connection		2
10	1000226712	cardan shaft		1
11	1000194911	distributor		1
12	1000154994	1000154994		1
13	1000050525	banjo bolt		1
14	1000135390	seal ring		2
15	1000225996	screw connection		2
16	1000226594	angle screw joint		1
17	1000222603	hose clamp		2
18	1000216985	fuel line		1
19	1000220962	Hose		1
20	1000220836	Hose		1
21	1000222749	bowden cable		1
22	1000221345	Hose		1
23	1000217486	Hose		1
24	1000221189	Hose		1



brake assembly 20 KmH

Item no.	Article no.	Description	Remark	Quantity
49	1000019593	cheese head screw		4
50	1000048572	flat head screw		1
51	1000085055	screw joint		1
52	1000085057	screw joint		1
53	1000226185	screw connection		2
54	1000224183	sleeve		1
55	1000204171	bracket bowdencable		1
56	1000015408	hexagon nut		1
57	1000085316	hex screw		1
59	1000013022	hexagon nut		2
60	1000222552	u-washer		2
61	1000018400	hex screw		2
62	1000015430	washer		4
63	1000085588	hexagon nut		2
64	1000085310	hex screw		2
65	1000222875	u-washer		2
66	1000015444	spring washer		2
67	1000223025	grease nipple		1
68	1000222577	u-washer		2



brake

Item no.	Article no.	Description	Remark	Quantity
25	1000210237	flange		1
26	1000223056	stud		8
27	1000204815	screw end piece		1
28	1000222988	seal ring		1
29	1000049000	hexagon nut		6
30	1000208428	venting valve		1



steering unit >11.2009

Item no.	Article no.	Description	Remark	Quantity
25	1000015432	u-washer		8
26	1000085588	hexagon nut		4
27	1000213827	steering wheel	<09.2010	1
28	1000198962	cover cap	for Pos.27	1
29	1000214282	steering wheel knob	for Pos.27	1
30	1000230039	steering cylinder		1
31	1000224706	pin		1
32	1000224707	pin		1
33	1000224825	pivoting bearing		2
34	1000223218	lock ring		4
35	1000222586	support washer		4
36	1000019253	lock ring		4
37	1000222726	grease nipple		1
38	1000226188	screw connection		1
39	1000220632	Hose		1
40	1000225914	angle screw joint		1
41	1000222482	hexagon nut		1
42	1000019126	u-washer		1
43	1000225979	lock screw connection		1
44	1000050469	grease nipple		1
45	1000225106	cylinder seal kit		1
46	1000243848	steering wheel	>09.2010	1
47	1000243850	cover cap	for Pos.46	1
48	1000221547	Hose		1



control valve

Item no.	Article no.	Description	Remark	Quantity
1	1000203192	control valve		1
2	1000211561	bracket		1
3	1000048250	cheese head screw		3
4	1000082617	spring washer		4
5	1000222819	u-washer		1
6	1000225948	cross lever controlling		1
7	1000015407	hexagon nut		3
8	1000022016	spring washer		2
9	1000210830	bracket		1
10	1000203618	connection piece		1
11	1000222772	fixing		1
12	1000019136	hex screw		1
13	1000209643	connection piece		1
14	1000222558	tension spring		1
15	1000085588	hexagon nut		2
16	1000196734	buttonhandle		1
17	1000049000	hexagon nut		1
18	1000022017	spring washer		1
19	1000226123	spring centralisation		1

electric

Item no.	Article no.	Description	Remark	Quantity
1	1000209814	steering column		1
2	1000214983	starter motor		1
3	1000208790	generator		1
4	1000208090	starter battery		1
5	1000210421	fuel pump		1
6	1000210735	fuel transmitter		1
7	1000156059	1000156059		1
8	1000254627	shut off switch		1
9	1000201894	cutoff switch key		1
10	1000206774	pressure feeler		1
11	1000229821	plug sleeve housing		1
12	1000206046	working light		2
13	1000274948	mounting pipe		1
14	1000206849	shut off solenoid		1
15	1000157953	1000157953		1
16	1000206887	temperature sensor		1
17	1000206886	oil pressure switch		1
18	1000155563	1000155563		1
19	1000015298	fuse		1
20	1000015302	fuse		1
21	1000015293	bulb		2
22	1000211002	wiring harness instruments		1
23	1000229857	plug sleeve housing		1
24	1000015364	hex screw		1



electric

Item no.	Article no.	Description	Remark	Quantity
49	1000205904	joystick		1
50	1000214495	Control unit		1
51	1000214830	Control unit		1
52	1000214495	Control unit		1
53	1000214833	Control unit		1
54	1000214496	Control unit		1
55	1000214737	Control unit		1
56	1000214497	Control unit		1
57	1000229856	pin housing		1
58	1000216499	wiring harness lighting		1
59	1000193816	bulb		4
60	1000001520	bulb		2
61	1000210725	turn indic.+brake+rear light		1
62	1000210724	turn indic.+brake+rear light		1
63	1000211558	turn indic.+brake+rear light		1
64	1000211559	turn indic.+brake+rear light		1
65	1000096652	rubber cap		2
66	1000229836	plug sleeve housing		2
67	1000162237	1000162237		2
68	1000109712	bulb		2
69	1000206706	sparkler light		2
70	1000106243	light cover		2
71	1000193808	bulb		2
72	1000210545	steeringstick switch		1



steering column

Item no.	Article no.	Description	Remark	Quantity
25	1000196806	relay		1
26	1000210545	steeringstick switch		1
27	1000229770	bushing housing		1
28	1000229766	pin housing		1
29	1000229857	plug sleeve housing		1
30	1000229856	pin housing		1
31	1000229778	plug sleeve housing		1
32	1000229777	pin housing		1
33	1000212962	switch rotating beacon	1-0	1
34	1000223237	gas strut		1
35	1000222460	hexagon nut		1
36	1000082625	washer		1
37	1000047463	hex screw		2
38	1000013022	hexagon nut		2
39	1000235305	diode		1
40	1000246917	cover fuse box		1
41	1000213006	switch working light	0-1-2	1
42	1000237279	tilt switch	1-0-2	1
43	1000237281	tilt switch	1-0	1
44	1000250558	ignition key	without identification	1



electric electric system 2

Item no.	Article no.	Description	Remark	Quantity
25	100027025	number plate light		1
26	1000193819	bulb		1
27	1000162237	1000162237		2
28	1000274948	mounting pipe		1
29	1000106243	light cover		2
30	1000206706	sparkler light		2
31	1000109712	bulb	H7	2
32	1000015293	bulb	H3	2
33	1000229836	plug sleeve housing		2
34	1000096652	rubber cap		2
35	1000155042	1000155042		1
36	1000229795	plug sleeve housing		1
37	1000229794	pin housing		1
38	1000288778	bracket rotating beacon		1
39	1000015364	hex screw		3
40	1000015432	u-washer		4
41	1000015408	hexagon nut		2
42	1000022016	spring washer		2
43	1000069001	rubber cover plate		1
44	1000102844	INSERT ROTATING BEACON		1
45	1000194850	bracket		1
46	1000229809	socket		1
47	1000085550	flat head screw		2
48	1000094962	u-washer		2



steering column E517

Item no.	Article no.	Description	Remark	Quantity
1	1000246874	steering column		1
2	1000256281	steering column		1
3	1000222460	hexagon nut		1
4	1000082625	washer		1
5	1000223237	gas strut		1
6	1000256282	displace lever		1
7	1000047463	hex screw		2
8	1000013022	hexagon nut		2
9	1000228702	bellow		1
10	1000256240	housing instr. Panel		1
11	1000256237	trim instruments		1
12	1000256238	trim instruments		1
13	1000247686	wiring harness instruments		1
14	1000229841	plug sleeve housing		2
15	1000229839	pin housing		2
16	1000229770	bushing housing		1
17	1000229766	pin housing		1
18	1000229857	plug sleeve housing		1
19	1000229856	pin housing		1
20	1000229777	pin housing		1
21	1000229778	plug sleeve housing		1
22	1000048510	flat head screw		4
23	1000223101	ovalhead screw		4
24	1000287214	nut	M4	4



wiring harness lighting lighting

Item no.	Article no.	Description	Remark	Quantity
1	1000237777	wiring harness lighting		1
2	1000229856	pin housing		1
3	1000229852	locking		1
4	1000255531	bushing housing		1
5	1000200198	blind plug	plug	2
6	1000200197	cable junction	cable seal	2
7	1000229851	locking		1
8	1000229857	plug sleeve housing		1



frame

Item no.	Article no.	Description	Remark	Quantity
25	1000228562	rubber buffer		2
26	1000015345	hex screw		7
27	1000194935	bracket battery		1
28	1000209757	floor plate		1
29	1000228616	rubber buffer		2
30	1000085467	cheese head screw		4
31	1000205011	distance piece		2
32	1000019593	cheese head screw		4
33	1000222819	u-washer		8
34	1000205118	bracket hose		1
35	1000224077	countersunk screw		2
36	1000015370	hex screw		2
37	1000085318	hex screw		2
38	1000015412	hexagon nut		2
39	1000205119	bracket hose		2
40	1000288476	exhaust cover		1
41	1000015346	hex screw		3
42	1000015408	hexagon nut		7
43	1000015432	u-washer		10
44	1000206541	Transport securing strip		1
45	1000082730	locking chain		1
46	1000082627	plug		1
47	1000260387	frame front part		1
48	1000224743	pin		1



engine hood

Item no.	Article no.	Description	Remark	Quantity
1	1000214509	engine hood		1
2	1000290684	sticker set		1
3	1000085456	cheese head screw		2
4	1000015444	spring washer		2
5	1000222992	u-washer		1
6	1000222875	u-washer		1
7	1000203912	key		1
8	1000210348	plate		1
9	1000085494	cheese head screw		1
10	1000082621	spring washer		1
11	1000222628	u-washer		1
12	1000222719	lock (w/o keys)		1
13	1000224073	countersunk screw		2
14	1000222552	u-washer		6
15	1000013022	hexagon nut		2
16	1000222728	fasten rope		1
17	1000015345	hex screw		1
18	1000015432	u-washer		4
19	1000015408	hexagon nut		1
20	1000228510	rubber buffer		2
21	1000082617	spring washer		4
22	1000015406	hexagon nut		6
23	1000079385	hex screw		2
24	1000015343	hex screw		2



loading system/armssystem

Item no.	Article no.	Description	Remark	Quantity
1	1000214698	loading system/armssystem		1
2	1000219820	slide bearing		8
3	1000214676	LEVER		1
4	1000225214	pin		1
5	1000085411	hex screw		1
6	1000082652	grooved washer		1
7	1000015432	u-washer		1
8	1000224293	pin		1
9	1000214686	TIE ROD		1
10	1000222386	slide bearing		4
11	1000224368	pin		1
12	1000224757	pin		2
13	1000224371	pin		1
14	1000015346	hex screw		1
15	1000022016	spring washer		1
16	1000124882	quad ring		1
17	1000224184	sleeve		1
18	1000225214	pin		2
19	1000082423	hex screw		2
20	1000048992	hexagon nut		2
21	1000222726	grease nipple		5



loading system/armssystem

Item no.	Article no.	Description	Remark	Quantity
25	1000251024	transformation kit		1



step plate

Item no.	Article no.	Description	Remark	Quantity
25	1000224183	sleeve		1
26	1000022016	spring washer		1
27	1000015364	hex screw		2
28	1000223689	stud		1
29	1000095351	fitting disc		4
30	1000095358	lock ring		4
31	1000015404	hex screw		3
32	1000085419	hex screw		2
33	1000223005	u-washer		2
34	1000022017	spring washer		2
35	1000082633	spring washer		3
36	1000085583	hexagon nut		2
37	1000223013	u-washer		3
38	1000228476	rubber sleeve		1
39	1000223552	hose clamp		1
40	1000228581	bellow		1
41	1000085605	u-washer		3
42	1000222877	u-washer		2
43	1000020788	hexagon nut		1
44	1000015432	u-washer		5
45	1000047364	hex screw		1
46	1000015408	hexagon nut		1
47	1000228565	rubber buffer		1
48	1000048166	cheese head screw		2



protecting roof foldable

Item no.	Article no.	Description	Remark	Quantity
49	1000082730	locking chain		6
50	1000228565	rubber buffer		2
51	1000004593	mirror		1
52	1000004594	mirror		1
53	1000085312	hex screw		4
54	1000015430	washer		8
55	1000085384	hex screw		2
56	1000228596	door fastener		2
57	1000085312	hex screw		4
58	1000266562	lock washer		1
59	1000267251	gas strut		1
60	1000288536	sealing profile		1



protecting roof foldable

Item no.	Article no.	Description	Remark	Quantity
25	1000222875	u-washer		12
26	1000085588	hexagon nut		8
27	1000253313	gas strut		1
28	1000255619	ball and socket		3
29	1000265609	fops roof		1
30	1000255174	Silencing foam		1
31	1000085481	cheese head screw		2
32	1000047408	hex screw		1
33	1000047403	hex screw		1
34	1000265610	overroll bar		1
35	1000260851	locking sheet		1
36	1000050549	fork head		1
37	1000260846	locking sheet		1
38	1000260849	locking sheet		1
39	1000260850	locking sheet		1
40	1000222819	u-washer		3
41	1000085392	hex screw		1
42	1000266560	pin		1
43	1000013022	hexagon nut		2
44	1000047395	hex screw		2
45	1000255208	bracket		2
46	1000082627	plug		2
47	1000224692	pin		2
48	1000193637	key ring		6



bracket immatriculation plate

Item no.	Article no.	Description	Remark	Quantity
1	1000256233	bracket immatriculation plate		1
2	1000214178	bracket immatriculation plate		1
3	1000247684	bracket immatriculation plate		1
4	1000247685	bracket immatriculation plate		1
5	1000214176	bracket immatriculation plate		1
6	1000027025	number plate light		1
7	1000222470	sleeve		2
8	1000228501	rubber buffer		1
9	1000085316	hex screw		2
10	1000015406	hexagon nut		2
11	1000082617	spring washer		2
12	1000222819	u-washer		4
13	1000015405	hexagon nut		1
14	1000015430	washer		1
15	1000085588	hexagon nut		2
16	1000085528	countersunk screw		2
17	1000228502	rubber sleeve		1
18	1000193819	bulb		1



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL