

dservice
DIECI

L 3500



**CATALOGO RICAMBI
SPARE PARTS CATALOGUE
CATALOGO DE PIEZAS DE REPUESTO
CATALOGUE DE PIECES DETACHEES
ERSATZTEILKATALOG**

L 3500
AXL2000



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL



OPTIONAL

TAMBURO E SIVIERA
 DRUM AND CONVEYOR
 CUVE ET CONVEYEUR
 TAMBOR Y EMBUDO
 TROMMEL UND PFANNE

DESCRIZIONE:




CODICE MACCHINA
 MACHINE CODE
AB 3500

VERSIONE
 VERSION
00
 06/04/06

NUMERO TAVOLA
 TABLE NUMBER
R10061

Table	Position	Code	Description	Qty
R20049	35	BCN9517/CL	STOP	1
R20049	36	BCN9511/CL	STOP	1
R20049	37	BCN9627	PANEL	1
R20049	38	BAA7254	SCREW	1
R20049	39	BAA7253	SCREW	1
R20049	40	BAL5115	WASHER	1
R20049	41	BAG4118	NUT	1
R20049	42	BSC0068	KIT	1
R20049	43	BSC0069	FASTENER	1
R20049	44	BSC0061	FASTENER	1
R20049	45	BAG4117	NUT	1
R20049	46	BAA7202	SCREW	1
R20049	48	BCN7673	SUPPORT	1



PARTI ELETTRICHE
 ELECTRIC COMPONENT
 COMPOSANTE ELECTRIQUE
 COMPONENTS ELECTRICAS
 ELEKTRISCHE KOMPONENTE

DESCRIZIONE:




CODICE MACCHINA
 MACHINE CODE
AB 3500

VERSIONE
 VERSION
00
 06/04/06

NUMERO TAVOLA
 TABLE NUMBER
R30059

Table	Position	Code	Description	Qty
R50065_01	18	BLE5670/36	FLEXIBLE PIPE	1
R50065_01	20	BKP0997	FLEXIBLE PIPE	1
R50065_01	21	BKP0997	FLEXIBLE PIPE	1
R50065_01	22	BKQ5651	FLEXIBLE PIPE	1
R50065_01	23	BKQ5651	FLEXIBLE PIPE	1
R50065_01	24	BKQ5651	FLEXIBLE PIPE	1
R50065_01	25	BKQ5651	FLEXIBLE PIPE	1
R50065_01	26	BKR6930	FLEXIBLE PIPE	1
R50065_01	27	BKR6930	FLEXIBLE PIPE	1
R50065_01	28	BKQ5560	FLEXIBLE PIPE	1
R50065_01	29	BKQ5560	FLEXIBLE PIPE	1
R50065_01	30	BKF5080	FLEXIBLE PIPE	1
R50065_01	31	BKL2060	TUBE	1
R50065_01	33	BKR6997	FLEXIBLE PIPE	1
R50065_01	34	BKR6997	FLEXIBLE PIPE	1
R50065_01	35	BKO3550	FLEXIBLE PIPE	1
R50065_01	36	BKO3550	FLEXIBLE PIPE	1
R50065_01	37	BLB7710	FLEXIBLE PIPE	1
R50065_01	39	BKL0040	FLEXIBLE PIPE	1
R50065_01	48	BLE4620	FLEXIBLE PIPE	1
R50065_01	49	BLE5570	FLEXIBLE PIPE	1
R50065_01	50	BLB0994	FLEXIBLE PIPE	1
R50065_01	51	BLB0994	FLEXIBLE PIPE	1
R50065_01	52	BKF4490	FLEXIBLE PIPE	1
R50065_01	53	BKF5250	FLEXIBLE PIPE	1
R50065_01	84	BKC6750	FLEXIBLE PIPE	1
R50065_01	85	BKC7155	FLEXIBLE PIPE	1
R50065_01	86	BKC6790	FLEXIBLE PIPE	1
R50065_01	89	BKC6850	FLEXIBLE PIPE	1
R50065_01	91	BKC6760	FLEXIBLE PIPE	1
R50065_01	93	BKC7075	FLEXIBLE PIPE	1
R50065_01	98	BKC6690	FLEXIBLE PIPE	1
R50065_01	99	BLE4052	FLEXIBLE PIPE	1
R50065_01	538	BHE1134	ONE WAY VALVE	1



NUMERO TAVOLA
 TABLE NUMBER
R60070

VERSIONE
 VERSION
00
 06/04/06

CODICE MACCHINA
 MACHINE CODE
AB 3500



DESCRIZIONE:

CILINDRO SOLLEVAMENTO CASSA
 CLIFT JACKC
 VERIN LEVAGE
 BOTELLA DE ELEVACION
 HUBZYLINDER

**AUTOBETONIERA
3500**

Table	Position	Code	Description	Qty
R70008	1	BHE1106	VALVE	1
R70008	2	BAL5102	WASHER	1
R70008	3	BAG4099	NUT	1
R70008	4	BHG4723	WASHER	1
R70008	5	BHA0101	NIPPLE	1
R70008	6	BAA7052	SCREW	1
R70008	7	BHA0101	NIPPLE	1
R70008	8	BHG4723	WASHER	1
R70008	9	BHA0101	NIPPLE	1
R70008	10	BHG4723	WASHER	1
R70008	11	BHE1390	SOLENOID VALVE	1
R70008	12	BAB5107	SCREW	1
R70008	13	5H.357104	REDUCER	1
R70008	14	BHA0109	NIPPLE	1
R70008	15	BHG4720	WASHER	1
R70008	16	BEP0104	SWITCH	1
R70008	17	BHA1780/F	ADAPTER	1
R70008	18	BHA0101	NIPPLE	1
R70008	19	BHG4723	WASHER	1
R70008	20	BVG2619	O RING	1
R70008	21	BHA0101	NIPPLE	1
R70008	22	BAG4100	NUT	1
R70008	23	BAL5108	WASHER	1
R70008	24	BAL2215	WASHER	1
R70008	25	BAL5118	WASHER	1
R70008	26	BAA7356	SCREW	1
R70008	27	BHE1399/LC	GASKET KIT	1
R70008	28	4H.551010001	CONNECTOR	1
R70008	29	BHE1393/LC	SOLENOID VALVE	1
R70008	30	BHE1400/LC	KIT	1

AUTOBETONIERA**3500**

Table	Position	Code	Description	Qty
R70085	1	BHN1129	HYDROSTATIC MOTOR	1
R70085	2	BHA0101	NIPPLE	1
R70085	3	BHG4723	WASHER	1
R70085	4	BHG4731	WASHER	1
R70085	5	BHA0132	GUIDE	1
R70085	6	BAL2212	WASHER	1
R70085	7	BAB5306	SCREW	1
R70085	8	BHF3197	GASKET KIT	1

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL


Table	Position	Code	Description	Qty
R80026	1	BHB3108/D1	DISTRIBUTOR	1
R80026	2	3D.535125002	ACCELERATOR LEVER	1
R80026	3	3D.535130002	LEVER	1
R80026	4	3D.580800A02	PLUG	1
R80026	5	3D.580800H02	KIT CURING	1
R80026	6	3D.75008006	CONNECTION	1
R80026	7	3D.72512200	CABLE	1
R80026	8	BAB5212	SCREW	1
R80026	9	BAB5210	SCREW	1
R80026	10	BAL5112	WASHER	1
R80026	11	BAG4117	NUT	1
R80026	12	BAL5113	WASHER	1
R80026	13	BAG4117	NUT	1
R80026	14	BHA0128	NIPPLE	1
R80026	15	BHG4730	WASHER	1
R80026	16	BHA0626	HOLLOW STUD	1
R80026	17	BHA0129	NIPPLE	1
R80026	19	BHA0568	NIPPLE	1
R80026	20	BKA0010	FITTING	1
R80026	21	BHA0291	FITTING	1
R80026	22	BWF1104	CLAMP	1
R80026	23	3D.57010202	CONNECTION	1
R80026	24	3D.535118002	LEVER	1
R80026	25	BHB0125/D1	DISTRIBUTOR	1
R80026	26	BHG4728	WASHER	1
R80026	27	BHA0123	NIPPLE	1
R80026	28	BHG4728	WASHER	1
R80026	29	BHA0467	FITTING	1
R80026	30	BHA0403	FITTING	1
R80026	31	3D.57010102	LEVER KIT	1
R80026	32	3D.535118002	LEVER	1

AUTOBETONIERA
3500

Table	Position	Code	Description	Qty
R90080	1	CVC3685/CL	BRACKET	1
R90080	2	BCN9642	SUPPORT	1
R90080	3	CLB4025	GUARD	1
R90080	4	CLB4026	GUARD	1
R90080	5	1F.741569	SILENTBLOCK	1
R90080	6	BSH9019	SUPPORT	1
R90080	7	BKA6070	FLEXIBLE PIPE	1
R90080	8	BKB1060	FLEXIBLE PIPE	1
R90080	9	PAZ3004	BUSHING	1
R90080	10	BWF1113	CLAMP	1
R90080	11	BVK0187	RADIATOR	1
R90080	12	BAA7150	SCREW	1
R90080	13	BAL5110	SCREW	1
R90080	14	BAL2203	WASHER	1
R90080	15	BAL5116	WASHER	1
R90080	16	BAG4119	SELF LOCKING NUT	1
R90080	17	BAA7308	SCREW	1
R90080	18	BAA7310	SCREW	1
R90080	19	BAA7256	SCREW	1
R90080	20	BAL5115	WASHER	1
R90080	21	BAG4118	NUT	1
R90080	22	BHA0130	NIPPLE	1
R90080	23	BHG4733	WASHER	1
R90080	24	BAA7260	SCREW	1
R90080	25	BVK0428	BLOWER	1
R90080	26	BVK0194	COUPLING	1
R90080	27	BAL5131	WASHER	1
R90080	28	1F.04935488	VENT	1
R90080	29	BVK0189	OIL RADIATOR	1
R90080	30	BVK0193	WATER RADIATOR	1
R90080	31	BWF1113	CLAMP	1
R90080	32	BWF1316	COLLAR	1
R90080	33	CVC4580	SUPPORT	1
R90080	34	BAA8203	SCREW	1

AUTOBETONIERA**3500**

Table	Position	Code	Description	Qty
RA0171	1	BVD1501	TRANSMISSION SHAFT	1
RA0171	2	BVD1500	TRANSMISSION SHAFT	1
RA0171	3	BVD1502	KIT	1
RA0171	4	BVD2003	CROSS	1










25 Position kit = 9+10+11+12+13+14+15+24

See mounting position of bevel crown wheel on sketch page 1

NUMERO TAVOLA TABLE NUMBER RA0029	VERSIONE VERSION 00 31/01/06	CODICE MACCHINA MACHINE CODE AB 3500		DESCRIZIONE: DIFFERENZIALE ANTERIORE FRONT AXLE COMPONENTS DIFFERENTIAL ANTERIEUR DIFFERENTIAL DEL'ANTERO
--	--	---	--	---

Table	Position	Code	Description	Qty
RA0033	1	5H.2772500201	REDUCTION BUSHING	1
RA0033	2	5H.2772500301	THRUST BUSHING	1
RA0033	3	5H.2772500102	SUPPORT	1
RA0033	4	5H.008010213	GREASER	1
RA0033	5	5H.7340701501	PLUG	1
RA0033	6	5H.2772561001	SUPPORT	1
RA0033	7	5H.2772561001	SUPPORT	1
RA0033	8	5H.2772500102	SUPPORT	1
RA0033	9	BAA7534	SCREW	1
RA0033	10	BAL5133	SCREW	1
RA0033	11	BAG4108	NUT	1
RA0033	12	5H.02521254	KIT	1

Table	Position	Code	Description	Qty
RA0147	35	5H.002143191	CIRCLIP	1
RA0147	36	5H.1120600603	PLANET GEAR	1
RA0147	37	5H.1120600802	BEARING	1
RA0147	38	5H.006082865	WHEEL NUT	1
RA0147	39	/	NOT AVAILABLE	1
RA0147	40	5H.016060442	SCREW	1
RA0147	41	5H.1120605005	PLANET GEAR CARRIER	1
RA0147	42	5H.1120602501	STUD	1
RA0147	43	5H.006041159	NUT	1
RA0147	44	5H.002063193	CIRCLIP	1
RA0147	45	5H.2130601101	SCREW	1
RA0147	46	5H.006051521	NUT	1
RA0147	47	/	NOT AVAILABLE	1
RA0147	48	/	NOT AVAILABLE	1
RA0147	49	5H.1120602601	LOCKING PLATE	1
RA0147	50	5H.002020088	CIRCLIP	1
RA0147	51	/	NOT AVAILABLE	1
RA0147	52	/	NOT AVAILABLE	1
RA0147	53	/	NOT AVAILABLE	1
RA0147	54	/	NOT AVAILABLE	1
RA0147	55	/	NOT AVAILABLE	1
RA0147	56	/	NOT AVAILABLE	1
RA0147	57A	5H.2120602501	SHIM	1
RA0147	57B	5H.2120602502	SHIM	1
RA0147	57C	5H.2120602503	SHIM	1
RA0147	58	/	NOT AVAILABLE	1
RA0147	59	/	NOT AVAILABLE	1
RA0147	60	5H.2120671017	PLANET GEAR CARRIER	1
RA0147	61	/	NOT AVAILABLE	1
RA0147	62	/	NOT AVAILABLE	1
RA0147	63	/	NOT AVAILABLE	1
RA0147	64	/	NOT AVAILABLE	1
RA0147	65	5H.2120670218	STEERING CASE	1
RA0147	66	5H.2120670318	STEERING CASE	1



NUMERO TAVOLA RF0037 **VERSIONE** 00 **CODICE MACCHINA** AB 3500
TABLE NUMBER **VERSION** **MACHINE CODE**
 23/02/06



DESCRIZIONE:

PEZZI DI RICAMBIO 1 (PER MOTORE DIESEL TURBO)
 EXCHANGE PIECE (FOR TURBO-CHARGED DIESEL ENGINE)
 PIÈCE DE RECHANGE (POUR MOTEUR DIESEL TURBOCOMPRESSE)
 PIEZA DE REPUESTO (POR MOTOR DIESEL SOBREALIMENTADO)
 ERSATZSTÜCK (FÜR DIESEL-TURBOMOTOR)

Table	Position	Code	Description	Qty
RM0003	1	BCD4223/0D	HOUSING	1
RM0003	2	BEQ0200	HEATER	1
RM0003	3	BEQ1209	FITTING	1
RM0003	4	BWF1113	CLAMP	1
RM0003	5	BIM2000	TUBE	1
RM0003	6	BEQ1211	COUPLING	1
RM0003	7	BEQ1212	FITTING	1
RM0003	8	BIM1000	TUBE	1
RM0003	9	BIM1000	TUBE	1
RM0003	10	BEQ1210	OPENING	1
RM0003	11	CAA1949	SCREW	1
RM0003	12	BHA0120	NIPPLE	1
RM0003	13	BHA0288	FITTING	1
RM0003	14	BHA1607	FITTING	1
RM0003	15	BWF1103	CLAMP	1
RM0003	16	BKA4440	TUBE	1
RM0003	17	BKA4230	TUBE	1
RM0003	18	BID1118	NIPPLE FITTING	1
RM0003	19	BIA0244	COUPLING	1
RM0003	20	BID1105	COCK	1
RM0003	21	BKA4240	FLEXIBLE PIPE	1
RM0003	22	BAA7202	SCREW	1
RM0003	23	BAL5113	WASHER	1
RM0003	24	BAG4117	NUT	1
RM0003	25	BAL5112	WASHER	1
RM0003	26	BWF0110	COLLAR	1

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL