


**DYNAPAC
CA150D
SPARE PARTS
CATALOGUE
SCA150D-2EN3**



DYNAPAC

Box 504, SE-371 23 Karlskrona, Sweden
Phone: +46 455 30 60 00, Fax: +46 455 30 60 10
www.dynapac.com

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

939077 Service kit 500 h

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	939068		1	Oil filter	A
4	908450	1	1	Air filter	A
8	939073		1	Fuel filter, cartridge	A
1)	Main				

938891 Drum rotation kit

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	160105		1	O-ring	D
2	929447		1	V-ring	D
3	116041		1	Taper roller bearing	D
4	167023		1	Seal ring	D

Scrapers urethan rubber Option

Ref. No.	Part No.	Rem.	Qty	Description	Code
2	374362		2	Scraper	B
3	500056		11	Screw M12x45 8,8	
4	500049		7	Screw M12-1,75x60 8.8	
5	500046		14	Screw M12x30H 8,8 FZB	
6	904213		28	Washer 13x30x4	
7	904231		22	Washer 13x24x2	
8	586019		18	Lock nut M12	
9	358025		3	Scraper bracket	
10	358026		4	Scraper bracket	
11	370100		2	Scraper bracket	
12	370101		2	Scraper bracket	

Drum

Ref. No.	Part No.	Rem.	Qty	Description	Code
10				Drum (Page 42)	

Combustion air system

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	380161		1	Air cleaner	
2	908450	A	1	.Air filter	A
3	908451	B	1	.Air filter	A
4	908399		1	.Vacuator valve	D
5	908452		1	.Cover	
6	813791		2	Mounting band	
7	904229		4	Washer 8,4x16x1,5	
8	500019		4	Screw M8-1,25x16 8.8	
9	904060		2	Hose clamp	
10	380157		1	Air inlet hose	
11	348309		1	Rubber bushing	
12	499266		1	Protection cover	
13	904059		3	Hose clamp	
14	904637		3	Washer 10x18x2	
15	500028		3	Screw M10-1,5x25 8,8	
16	389976		1	Hose holder	
17	384828		1	Air inlet hose	
18	791170		1	Hose clamp	

- A) Main
B) Safety

Rear axle and wheels

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	384789		1	Rear axle (Page 62)	
2	500295		8	Screw M20x240	
3	904233		16	Washer 21x36x3	
4	901145		8	Lock nut M20-10	
5	371937		2	Wheel, cpl Up to 73X20636	
	379545	G	2	Wheel, cpl From 73X20637	
	371941	A	2	Wheel, cpl Up to 73X20636	
	379548	A,G	1	Wheel, cpl From 73X20637	
6	371594		1	.Rim	
7	929050		1	.Tube Up to 73X20636	D
	792261	H	1	.Air charging valve Straight From 73X20637	B
8	373617		1	.Tyre Up to 73X20636	D
	379531		1	.Tyre From 73X20637	
9	379546	B,G	1	Tractor tyre, cpl	
	379547	C,G	1	Tractor tyre, cpl	
	379549	D,G	1	Tractor tyre, cpl	
	379550	E,G	1	Tractor tyre, cpl	
10	371594		1	.Rim	
11	792261		1	.Air charging valve Straight	B
12	379532		1	.Tyre	D
13	903985	F	2	Decal "SAFETY", "TYRE IN BALLAST"	

- A) Liquidfilled, option
- B) Left, option
- C) Right, option
- D) Liquid filled, left, option
- E) Liquid filled, right, option
- F) Used with Liquid filled tyres.
- G) Tubeless tyre.
- H) Used with tubeless Wheel cpl.

Planet gear

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	939002		1	Housing	
2	939003		16	Spring washer	
3	939004		12	Screw	
4	909596		2	Plug	
5	939005		1	Magnetic plug	
6	939006		1	Seal	
7	939007		1	Shaft	
8	926781		8	Wheel screw	
9	939008		1	Wheel hub	
10	936020		1	O-ring	D
11	939009		2	Bearing	
12		1	1	Missing description	
13		1	1	Missing description	
14		1	1	Missing description	
15	939010		1	Locking plate	
16	939011	1	3	Circlip	
17	939012	1	3	Planet gear	
18	939013	1	3	Bearing	
19	901987		8	Wheel nut	
20	939014		1	Seal	
21	909607		3	Seal	D
22	939015		2	Screw	
23		1	1	Missing description	
24	939016		8	Nut	
25	939017		8	Stud	
26		1	1	Missing description	
30	939018		1	Planet gear carrier Cpl.	
31	939019		4	Nut	
32	939020		4	Stud	

1) Included in ref. 30

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	813822		2	Pin	
2	935618		1	Housing	
3	901453	A	2	O-ring	
4	902928		2	Plug	
5	908432		1	Plug	
7	939242		1	Shaft	
8	901465		1	Bearing	
9	901467		1	Ring	
10	935633	A	1	O-ring	D
11	903575		1	Seal carrier	
12	935632	A	1	Seal	D
13	935634		1	Retainer plate	
14	908773		3	Screw	
15	935626		1	Valve plate	
16	935625		1	Holder	
17	901455		1	Cylinder block, cpl	
18	935624		1	Shim	
19	935623		1	Retainer guide	
20	903571		1	Pressure plate	D
21	903570		9	Piston	D
22	935627		1	Thrust plate	
23	909253		2	Screw	
24	358388		3	Plug	
25		A	3	O-ring	
26	935741		2	Plug, cpl	
30	939238		1	Valve, cpl	
31	939240		1	Spring collar	
32		A	2	O-ring	
33	939239		1	Adapter	
34	939241		1	Plug	
35	935629	A	1	Gasket	D
36	935533		1	Spool	
37	939236		2	Spring washer	
38	939237		2	Spring	
39	937280		1	End cap, cpl	
40	935630		1	Screw	
41	909252		4	Screw	
42	935617		1	Seal kit	D

A) Included in item 42

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Hydraulic oil tank

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	372044		1	Hydraulic oil tank, CPL	
2	372029		1	.Hydraulic oil tank	
3	349880		1	.O-ring	
4	349879		1	.Cover	
5	989151		1	.Oil level glass	D
6	500019		14	.Screw M8-1,25x16 8.8	
7	904229		14	.Washer 8,4x16x1,5	
8	357138		1	.Ventilating filter	A
9	791119		1	.Adapter G3/4	
10	233304		1	.Ball valve	
11	232039		1	.Plug G3/4	
12	791120		2	.Sealing washer G3/4	
13	500192		4	Screw M10x80	
14	904567		4	Washer 10,5x28x6	
16	570006		4	Nut M10	

383855 Rear axle Limited Slip

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Housing (Page 102)	
2			2	Differential with limited slip (Page 104)	
3			1	Brakes (Page 106)	
4			2	Planet gear (Page 108)	
5	901834		1	Splined sleeve	
7	929648		1	O-ring	D
8	909583		1	Flange	
9	909582		8	Screw	
10	909584		1	O-ring	D

Central test panel hydraulic Option

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	374028		1	Test panel	
2	500053		2	Screw M8-1,25x20 8,8	
3	904229		2	Washer 8,4x16x1,5	
4	234388		2	Connector	
5	334196		5	Elbow 90	
6	356348		6	Measuring nipple	D
7	482342		1	Hydraulic hose	
8	902125		3	Connector	
9	483188		2	Hydraulic hose	
10	483445		2	Hydraulic hose	
11	483547		1	Hydraulic hose	
12	234622		1	Elbow 45	

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	999011	1	1	Rotating beacon	D
2	358452		1	Lamp holder	
3	500021		2	Screw M8-1,25x25 8,8	
4	586003		2	Lock nut M8	
5	904229		2	Washer 8,4x16x1,5	
6	500013		1	Screw M6-1x16 8,8	
7	904228		1	Washer 6,4x12x1,5	
8	374398		1	Cable harness	
9	921039		1	Pipe clamp	
10	541702		1	Screw M6x12	
11	389577	2	1	Rotating beacon	D

- 1) Is replaced by item 11, P/N 389577
- 2) Replaces item 1, P/N 999011

Drivers platform

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	380208		1	Drivers seat	
	348331		1	Seat cover	D
	370234	A	1	Drivers seat	
	936283		1	.Seat switch	D
	380889		1	.Cable harness	
	909535	B,C	1	.Sliding rail	D
	909536	D	1	.Sliding rail	D
2	508006		4	Screw	
3	904229		4	Washer 8,4x16x1,5	
4	380123		1	Grab handle	
5	901145		4	Lock nut M20-10	
6	904233		4	Washer 21x36x3	
7	904230		8	Washer 10,5x22x2	
8	500029		4	Screw M10-1,5x30 8,8	
9	376255		1	Step	
10	500111		16	Screw M12x55 8,8	
11	904231		16	Washer 13x24x2	
12	372757		2	Shock absorber	D
13	903290		4	Washer 21x36x6	
14	347512		4	Washer	
15	500226		4	Screw M20-2.5x180 8,8	
16	374471		4	Spacer	
17	373400		2	Shock absorber	D
21	380113		1	Platform	
23	382397		2	Spacer	
24	500053		4	Screw M8-1,25x20 8,8	
25	904229		8	Washer 8,4x16x1,5	
26	380727		2	Cover	
27	372494	E	1	Rubber strip	
28	372785		1	List	
29	927974		13	Washer	
30	904433		13	Blind rivet	
31	382582		2	List	
32	902286		2	Lock nut M8	

- A) Option
 B) With handle
 C) Left
 D) Right
 E) L=2,4 M

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	902186		1	Cover plate	
2			1	Nut	
3	902183		1	Steering wheel	
4	902185		1	Insert adapter	
5	500048		2	Screw M10-1,5x20 8,8	
6	904230		4	Washer 10,5x22x2	
7	902123		1	Steering column	
8	355869		2	Spacer sleeve	
9	500030		2	Screw M10-1,5x35H 8,8	
10	902184		1	Turning knob	D
11	928830		1	Rubber washer	
12	904793		1	Washer 19x34x3	

Cab Screens

Ref. No.	Part No.	Rem.	Qty	Description	Code
108	908506		1	Holder	
109	908507		1	Emergency hammer	
110	908499	D	1	Rubber list	
D)	L=5 m				

Cab Work light

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	908267		4	Working light	D
2	908359		2	Distance	
3	904229		4	Washer 8,4x16x1,5	
4	500019		4	Screw M8-1,25x16 8.8	
5	586003		2	Lock nut M8	

Ref. No.	Part No.	Rem.	Qty	Description	Code
10				Standard equipment (Page 172)	

Scraper

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	815680		1	Scraper	
2	385441		20	Tooth	
3	801631		20	Flexible pin 56,5x40	B
4	500210		4	Screw	
5	904233		4	Washer 21x36x3	
6	586022		4	Lock nut M20-8	
7	903290		4	Washer 21x36x6	
8	815681		4	Shim T=3 mm	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL