


**DYNAPAC
CA602D
SPARE PARTS
CATALOGUE
SCA602D-2EN3**



DYNAPAC

Box 504, SE-371 23 Karlskrona, Sweden
Phone: +46 455 30 60 00, Fax: +46 455 30 60 10
www.dynapac.com

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

	Cab 383030	230
	Cab Interior	232
	Cab Inside panels	234
	Cab Screens	236
	Cab Door	240
	Cab Wipers front and rear	242
	Cab Mirror, Sun curtain	244
	Cab Electric	246
	Cab Heater system	248
385434	Cab heater, cpl	250
	Cab Cable harness	252
	Cab Work lights	254
	Cab Exterior, rear mirror	256
	Radio and cassette/cd player Option	258
	Cab, 12V contact From 71X20714	260
	Decals	262
	Decals	264
	Decals	266
	Standard equipment	268
	Standard equipment	270
	Optional equipment	272
	Tool equipment	274
	Sign SMV, First aid box	276
	Canopy	278
	Air conditioner assembly	280
	Condensor assembly	282
	Compressor assembly	284
	Evaporator assambly	286
	Fire extinguisher assembly	288
	Anti spin CA Up to ECN04171	290
	Anti spin CA From ECN04171	292
	Anti spin, Potentiometer installation	294

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	939082		1	Oil filter element	A
2	939083		1	Fuel filter element	A
8	909270		1	Filter, main	A

938562 Steering hitch kit

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	100040		2	Axial ball bearing	D
2	924620		2	Axial ball bearing	D
3	167032		2	Lip-type oil seal	D
4	167033		2	Ring	D
5	310008	1	3	Grease nipple	D
6	926214		2	Grease fitting	D
7	337045		2	Shim T=1,0 mm	D
8	345874		2	Shim T=0,35 mm	D
9	345875		2	Shim T=0,10 mm	D
10	337221		2	Shim T=1,0 mm	D
11	433722101		2	Shim T=0,35 mm	D
12	433722102		2	Shim T=0,10 mm	D
13	384503		2	Shim T=0,15 mm	D
14	904663		1	Lube grease " DYNAPAC special approved "	
15			1	Instructions	

1) Valid for CC501/CC722 only.

Frames

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	386158		1	Tractor frame Up to 71X20719	
	387999		1	Tractor frame From 71X20720	
2	371700		1	Drum frame Up to 71X20784	
	376707		1	Drum frame From 71X20785	
3			1	Hitch (Page 40)	
4	372169	A	1	Drum shroud	
5	904557		4	Washer 10,5x22x4	
6	374744		1	Safety rod	
7	347119		2	Shaft	D
8	343775		2	Wire	
9	386366		1	Cover	
10	372709		2	O-ring	D
11	386252		1	Cover	
12	813391		1	Magnetic plug	D
13	500043		2	Screw M10x16H 8,8	
14	904230		2	Washer 10,5x22x2	
15	357488		1	Spring	
16	635061		3	Hair clip	D
17	500188		32	Screw M8-1,25x14 8,8	
18	904229		32	Washer 8,4x16x1,5	
19	372087		1	Protection plate	
20	500029		4	Screw M10-1,5x30 8,8	
21	232041		1	Filter plug	D
22	902919		5	Plug	
23	500034		2	Screw M10-1,5x100 8,8	
24	904230		10	Washer 10,5x22x2	
25	376045		2	Holder	
27	500055		2	Screw	
28	500029		6	Screw M10-1,5x30 8,8	
29	928850		4	Screw M20-2,5x120 10,9	
30	904233		8	Washer 21x36x3	
31	927117		4	Screw M20x100	
32	371701		1	Cross beam Up to 71X20784	
	376763		1	Cross beam From 71X20785	
33	499097		1	Filler cap	D

A) Option

Hitch

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	374898		1	Hitch	
2	924620		2	Axial ball bearing	D
3	373123		1	Bearing cover	
4	337221	N		Shim T=1,0 mm	D
5	433722101	N		Shim T=0,35 mm	D
6	433722102	N		Shim T=0,10 mm	D
7	100040		2	Axial ball bearing	D
8	337042		2	Bearing cover	
9	337045	N		Shim T=1,0 mm	D
10	345874	N		Shim T=0,35 mm	D
11	345875	N		Shim T=0,10 mm	D
12	343159		1	Cover	
13	167032		2	Lip-type oil seal	D
14	167033		2	Ring	D
15	926214		4	Grease fitting	D
16	500037		12	Screw M12-1,75x35 8,8	
17	904231		12	Washer 13x24x2	
18	500188		1	Screw M8-1,25x14 8,8	
19	904479		10	Screw	
20	910995		3	Stop screw	
22	904229		1	Washer 8,4x16x1,5	

Drum

Ref. No.	Part No.	Rem.	Qty	Description	Code
10				Drum (Page 52)	
20				Drum cartridge Vibration side (Page 54)	
30				Drum cartridge Drive side (Page 56)	
40				Drum gear (Page 58)	

Engine

Ref. No.	Part No.	Rem.	Qty	Description	Code
10				Engine Cummins QSB 5.9C (Page 62)	
20				Cooling system (Page 66)	
25				Oil cooling system (Page 70)	
30				Combustion air system (Page 74)	
40				Fuel system Up to 71X20730 (Page 76)	
41				Fuel system From 71X20731 (Page 78)	
50				Exhaust system Up to 71X20719 (Page 80)	
60				Exhaust system From 71X20720 (Page 82)	

Oil cooling system

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	376377		1	Hydraulic oil cooler (Page 72)	
2	500022		6	Screw M8-1,25x30 8,8	
3	904640		6	Washer 8,4x22x3	
4	902286		6	Lock nut M8	
5	334237		4	Adapter	
6	483475		1	Hydraulic hose	
7	334563		1	Adapter	
8	482103		1	Hydraulic hose	
9	334520		1	Adapter	
10	234888		1	Tee-connector	
11	482182		1	Hydraulic hose	D
12	234243		2	T-connector	
13	334468		2	Adapter	
14	929122		1	Reducing	
15	334524		1	Connector	
16	482613		1	Hydraulic hose	D
17	482912		1	Hydraulic hose	
18	334156		1	Adapter	
19	482251		1	Hydraulic hose	
20	334248		1	Elbow 45	
21	904110		1	Connector	
23	386051		1	Cooler frame	
24			0	Not used on this model	
25	386050		1	Bracket Right	
26	386049		1	Bracket Left	
27	376437		1	Stay	
28	376438		1	Stay	
29	376444		2	Holder plate	
30	376445		2	Holder plate	
31	904567		4	Washer 10,5x28x6	
32	500149		8	Screw M10x70	
33	500022		4	Screw M8-1,25x30 8,8	
34	904734		4	Washer 8,4x26x4	
35	500031		4	Screw M10-1,5x40 8,8	
36	904230		8	Washer 10,5x22x2	
37	902287		4	Nut	
38	904557		4	Washer 10,5x22x4	
39	334155		1	Connector	
40	483476		1	Hydraulic hose	

Exhaust system

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	386536		1	Muffler	
2	386045		1	Exhaust hose	
3	386046		1	Exhaust pipe	
4	386400		1	Exhaust pipe	
5	386410		1	Thermal guard	
6	386411		1	Thermal guard Up to 71X20602	
	386700		1	Thermal guard From 71X20603	
7	313093		1	Pipe clamp	
8	371086		2	Clamp	
9	313094		3	Pipe clamp	
10	904229		6	Washer 8,4x16x1,5	
11	500053		4	Screw M8-1,25x20 8,8	
12	902166	A	1XL	Edge trim	
13	902166	B	1XL	Edge trim	
14	902166	C	1XL	Edge trim	
15	904230		12	Washer 10,5x22x2	
16	500031		4	Screw M10-1,5x40 8,8	
17	586018		4	Lock nut M10	
18	386152		2	Hose clamp	
19	386153		1	Thermal guard	
20	904228		2	Washer 6,4x12x1,5	
21	500015		2	Screw M6-1x30 8,8	
22	386163		1	Holder plate	
23	386175		1	Thermal guard	
24	500048		2	Screw M10-1,5x20 8,8	
25	904231		4	Washer 13x24x2	
26	500046		4	Screw M12x30H 8,8 FZB	
27	387454		1	Thermal guard	
28	500029		2	Screw M10-1,5x30 8,8	
29				Missing description	
30	375041	D	1	Bracket	
31	313094	D	1	Pipe clamp	
32	375181	D	1	Exhaust pipe	
33	386575	D	1	Exhaust pipe	
34	904229	D	5	Washer 8,4x16x1,5	
35	500053	D	2	Screw M8-1,25x20 8,8	
36	372722	D	1	Cover plate	
37	372725	D	1	Holder	
38	586003	D	1	Lock nut M8	

- A) L=0.330m
 B) L=0.460M
 C) L=0.080M
 D) Option

Rear axle and wheels

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Rear axle (Page 92)	
2	929217		8	Screw	
3	904233		16	Washer 21x36x3	
4	901145		8	Lock nut M20-10	
5	379691	A	2	Wheel, cpl	
	388146	A,I	2	Wheel, cpl	
6	383933		1	.Rim	
7	792261		1	.Air charging valve Straight	B
8	379632		1	.Tyre	D
	791573	J	1	.Tyre	D
9	379414	D	1	Tractor wheel, cpl	
	379413	E	1	Tractor wheel, cpl	
10	383933		1	.Rim	
11	792261		1	.Air charging valve Straight	B
12	379410		1	.Tyre	D
13	383975	B	2	Wheel, tubeless, cpl	
14	383955		1	.Rim cpl	
15	901443		1	..Snap ring	
16	901444		1	..Side ring	
17	791175		1	.Air charging valve	
	791176		1	.Valve foot	
18	901218		1	.Tyre	D
19	903985	G	1	Decal "SAFETY", "TYRE IN BALLAST"	
	355983	H	2	Decal "TYRE PRESSURE"	

- A) Liquidfilled
- B) Liquidfilled, Option, Michelin branded.
- D) Liquidfilled tyre, left, option.
- E) Liquidfilled tyre, right, option.
- G) Used with Liquid filled tyres.
- H) Used with item 13, 383975.
- I) For Chinese market.
- J) Used with 388146.

383856 Rear axle No-Spin, Option

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Rear axle	
2			1	.Differential with No-Spin (Page 102)	
3			2	.Differential housing and brakes (Page 104)	
4			2	.Planet gear (Page 106)	
5	909584		1	O-ring	D
6	909583		1	Flange	
7	929648		1	O-ring	D
8	901834		1	Splined sleeve	
9	909582		8	Screw	

Propulsion system, Front

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	375620		1	Propulsion motor Up to 71X20719 (Page 112)	
	389564		1	Propulsion motor From 71X20720	
	382088	A	1	Hydraulic motor Anti spin	
2	160272		1	O-ring	
3	500028		4	Screw M10-1,5x25 8,8	
4	904230		12	Washer 10,5x22x2	
5	923384		4	Flange half	
6	904005		2	O-ring	
7	502132		8	Screw UNC 7/16" x 22	
8	904638		8	Washer 12x22x2	
9	334132		1	Elbow 45, O-ring	
10	500101		2	Screw M20x50	
11	903290		2	Washer 21x36x6	
12	334138		1	Adapter	
13	483028		1	Hydraulic hose	
14	483029		1	Hydraulic hose	
15	483022		1	Hydraulic hose	
16	372581		1	Rubber part	
17	372578		1	Hose clamp	
18	500092		2	Screw M10-1,5x75 8.8	
19	349909		2	Hose clamp	
20	372580		1	Rubber part	
21	372586		1	Hose clamp	
22	500019		4	Screw M8-1,25x16 8.8	
23	904640		4	Washer 8,4x22x3	
24	586018		2	Lock nut M10	
25	374706		1	Cover From 71X20645	
26	500034		3	Screw M10-1,5x100 8,8	
27			1	Protection cover, Cpl	
28	373878		1	.Protection cover	
29	287724		1	.Edge trim	
30	902166		1	.Edge trim	
31	372235		1	Hose guard	
32	903750		2	Elbow	
33	813499		2	Elbow 90, O-ring	D

A) With Anti spin, Option

374137 Propulsion motor

Ref. No.	Part No.	Rem.	Qty	Description	Code
59	902995		1	.Headless screw	
60	909525	1	1	.Nut	
61	935520		1	Seal kit	D
1)	Includes in Seal kit item 61				

Ref. No.	Part No.	Rem.	Qty	Description	Code
			1	Steering pump, cpl	
1			1	.Snap ring	
2	937896	1	1	.Sealing	
3			1	.Flange	
4	937897	1	2	.Back-up ring	
5	937898	1	2	.Seal	
6			2	.Bearing block	
7	937900	1	2	.O-ring	
8			1	.Housing	
9			3	.Pin	
10			1	.Drive gear	
11			1	.Idler gear	
12			1	.Cover	
13			4	.Screw	
14	937901	1	1	.O-ring	
15			1	.Plug	
16	937902	1	1	.O-ring	
17			1	.Coupling	
18	937813		1	.Seal kit	

1) Included in Seal kit item 18.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Emergency steering Option

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	381254		1	Emergency steering pump	
1-A	937964		1	.Pump unit	
1-B	937965		1	.Relay/Start solenoid	
1-C	937966		2	.Clamp	
1-D	937967		1	.Engine foundation	
1-E	937968		1	.Cable	
2	381684		1	Valve block, cpl	
2-A	381594		1	.Valve block	
2-B	381877		1	.Pressure switch	
2-C	937931		1	.Check valve	
2-D	937969		1	.Plug	
3	381595		1	Bracket	
4	386653		1	Cable harness	
5	791390	A	1	Connection cable	
6	791391	B	1	Connection cable	
7	482254		1	Hydraulic hose	D
8	482306		1	Hydraulic hose	
9	234957		1	Adapter	
10	234379		1	Tee-connector	
11	330418		1	Adapter	
12	334142		1	Connector	
13	334235		1	Elbow 90	
14	334238		1	Elbow 90 o-ring	
15	234659		1	Straight o-ring connector	
16	334135		1	T-connector	
17	924731		1	Connector	
18	160287		4	O-ring	D
19	903773		2	Screw M10x1x50 8,8	
20	904231		1	Washer 13x24x2	
21	904229		12	Washer 8,4x16x1,5	
22	500035		1	Screw M12x020H	
23	500053		8	Screw M8-1,25x20 8,8	
24	313041		N	Cable ties L=186 mm	
25	901224		1	Fuse 3A	D
26	586003		4	Lock nut M8	
27	482467		1	Hydraulic hose	
28	792069	E	1	Straight o-ring connector	
29	377511	E	1	Check valve	
30	334144	E	1	Connector	
31	482782	C	1	Hydraulic hose	
31-1	482482	D	1	Hydraulic hose	
32	334116	C	1	Straight o-ring connector	
32-1	334238	D	1	Elbow 90 o-ring	

- A) To battery switch.
 B) To engine block.
 C) With driver seat turn over.
 D) With driver seat standard platform.
 E) Connected to steering pump.

Electric system

Ref. No.	Part No.	Rem.	Qty	Description	Code
59	923976		2	Nut	
60	904698		4	Washer 4,3x8x0,8	
61	891228		1	Adapter	
63	500006		2	Screw M5x16	
64	500046		1	Screw M12x30H 8,8 FZB	
65	904231		1	Washer 13x24x2	
66	500021		1	Screw M8-1,25x25 8,8	
67	570003		1	Nut M5	
68		D	1	Cover	
69			2	Existing on engine	
70	960796		3	Connector black, MPM 182 09 ND	D

D) See section "Frame"

Instrument panel Upper right

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	345870		1	Plug	
2	359343		1	Fuel gauge	D
	355258		1	.Lamp holder	
	985012		1	.Bulb	D
3	386189		1	Control panel plate	
4	903657		6	Screw	
5	791349	A	1	Pilot lamp Yellow	
6	791349	B	1	Pilot lamp Yellow	
7	791345		5	Blind plug	
8	791348	C	1	Pilot lamp White	
9	791345		1	Blind plug	
10	791347	D	1	Switch	
11	791346	E	1	Switch	

- A) Pre-heater lamp. Replaces P/N 791350, Pilot lamp green.
- B) Fault alarm lamp.
- C) Service indicator lamp.
- D) Diagnostic "ON".
- E) Error code scroll switch.

Ref. No.	Part No.	Rem.	Qty	Description	Code
3	902227		2	Work light	
4	904316	A	1	Direction lamp	
	937107		1	.Lamp glass	
5	904315	B	1	Direction lamp	
	937106		1	.Lamp glass	
6	904318	C	1	Direction lamp	
	937109		1	.Lamp glass	
7	904317	D	1	Direction lamp	
	937108		1	.Lamp glass	
8	374029		2	Lamp shield	
9	374030		2	Bracket	
10	374089		2	Bracket	
11	900790		2	Bulb 60/55w H4	B
12	901369		2	Bulb 55w H3	B
13	928502		6	Bulb 21w	B
14	985014		4	Bulb 5w	B
15	533010		8	Screw	
16	500043		6	Screw M10x16H 8,8	
17	904230		6	Washer 10,5x22x2	
18	500040		8	Screw M6-1x20 8,8	
19	904228		12	Washer 6,4x12x1,5	
20	925802		11	Cable ties L=142 mm	
21	903899		2	Connector	
22	500019		4	Screw M8-1,25x16 8.8	
23	904229		4	Washer 8,4x16x1,5	
25	901182		4	Reflector, red	B
26	901183		2	Reflector, yellow	B
27	500012		12	Screw M6x12	
28	313041		N	Cable ties L=186 mm	
30	921031		6	Clamp	
33	904038		1	Fuse 40A	D
34	374168		1	Cable harness	
35	921028		6	Clamp	
36	921028		6	Clamp	
37	904543		3	Cable tie holder	
38	903852		3	Screw ST4,2x13	
42	374088		2	Holder plate	
43	513009		4	Screw	
44	374194		1	Cable harness	
45	374195		1	Cable harness	
46	373184		1	Cable harness	
47	902066		2	Headlight	
	904313	E	2	Headlight	
48	902064		2	Direction lights	
49	985013		2	Bulb 12V,5W	B
50	374526		2	Cable harness	
51	904281		4	Washer 5,3x10x1	
52	926611		4	Screw	
53	586001		4	Lock nut M5	
54	374196		1	Cable harness	
55	903969		3	Screw ST4,8x19 Black	
56	374184		1	Licence plate light bracket	
57	929455		2	Licence plate light	
58	985013		2	Bulb 12V,5W	B
59	374120		2	Protecting cover	
60	374327		2	Protecting cover	

- A) Front right
- B) Front left
- C) Rear right
- D) Rear left
- E) Left hand asymmet.

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	388210		1	Processor comp.meter	
2	388211		1	Cable harness	
3	348213		1	Sensor, cpl	
4	500079		2	Screw M6-1x50 8,8	
5	902285		4	Lock nut M6	
6	373140		1	Bracket	
9	902496		1	Clamp	
10	500079		2	Screw M6-1x50 8,8	
11	500194		2	Screw M12x40H 8.8	
12	902288		2	Nut M12	
13	313102		15	Cable ties	
14	313041		15	Cable ties L=186 mm	
15	372836		1	Bracket	
16	902286		5	Lock nut M8	
17	930151		1	Switch	D
18	383452		1	Compaction meter	
	904890		2	.Lamp holder	
	904889		2	.Bulb	
19	500047		1	Screw M8-1,25x35 8,8	
20	921072		1	Clamp	
21	901224		1	Fuse 3A	D

Tachograph, simple cab Option

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	901209		1	Tachograph	
2	372497		1	Cable harness	
	908496		1	.Grommet	
	903717		1	.Resistor 470 ohm, 0.5w	
3	372496		1	Cable harness	
4	372495		1	Cable harness	
	904015		1	.Fuse holder	
	904140		1	.Fuse 0.5A	
5	313041	N		Cable ties L=186 mm	
6	385527		1	Cover	
7	385526		1	Holder plate	
10	904281		2	Washer 5,3x10x1	
11	500004		2	Screw M5 0,8x12 8,8	
16	904228		3	Washer 6,4x12x1,5	
19	586002		1	Lock nut M6	
22	904229		3	Washer 8,4x16x1,5	
24	921031		1	Clamp	
45	378110		1	Bracket	
46	500075		3	Screw M6-1,0x25 8.8	
47	500053		3	Screw M8-1,25x20 8,8	
48	904543		2	Cable tie holder	
49	903852		2	Screw ST4,2x13	

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	387968		1	Holder	
2	938686		10	Screw	
3	387969		1	Lever	
4	388189		1	Lever	
5	387571		1	Computer holder	
6	388209		1	Computer	
7	904228		4	Washer 6,4x12x1,5	
8	500013		4	Screw M6-1x16 8,8	
9	791452		3	Lock handle	
10	904640		1	Washer 8,4x22x3	
11	904229		1	Washer 8,4x16x1,5	
12	388214	A	1	Cable harness	
13	388213		1	Cable harness	
14	921046		5	Clamp	
17		B		Sensor	
18	389591		1	Bracket	
19	388212		1	Control box	
20	313041		N	Cable ties L=186 mm	
21	313102		N	Cable ties	
22	387941		1	Control box holder	
23	624021		3	Pop rivet	
24	389570		1	Cable harness	
25		C		Cable harness	

- A) Connected to 12V contact on Cab.
- B) See section " Speedometer and Frequency meter".
- C) See section "Compaction meter".

Drivers platform, for cab

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Cab 383030 (Page 230)	
2				Drivers seat Turn-over in cab (Page 216) Forward and reverse control	
5	374606		2	Shock absorber Green	D
6	374607		2	Shock absorber Yellow	D
8	500195		16	Screw M12-1,75x50 8.8	
9	901145		4	Lock nut M20-10	
10	904233		6	Washer 21x36x3	
11	904231		16	Washer 13x24x2	
12	384759		4	Spacer	
13	791218		4	Screw M20x200	
14	372457		4	Back-up ring	
15	903290		4	Washer 21x36x6	
16	376252		1	Step	
17	500029		6	Screw M10-1,5x30 8,8	
18	904230		6	Washer 10,5x22x2	
19	372494	A	1XL	Rubber strip	
20	372785		1	List	
21	372786		2	List	
22	904433		13	Blind rivet	
23	927974		13	Washer	
24	383705		1	Instruction book holder	
25	357643		1	Wire	
26	791226		4	Screw	

A) L = 2,400 m

Steering system

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	359919		1	Shaft	
2			1	.Nut	
3	359916		4	Chain wheel	D
4	359921		1	Chain	D
5	516051		4	Set screw	
6	350009		4	Flat key	D
7	372653	A	1	Chain	
	372654	B	1	Chain	
8	500021		3	Screw M8-1,25x25 8,8	
9	904734		2	Washer 8,4x26x4	
10	904229		3	Washer 8,4x16x1,5	
11	586003		2	Lock nut M8	
12	903917	C	2	Bearing outer	
	903918	D	2	Bearing inner	
14	904228		4	Washer 6,4x12x1,5	
15	586002		6	Lock nut M6	
17	603001		2	Washer TB6,7x14x3	
18	372672		1	Chain guard	
19	374933	A	1	Shaft	
	374934	B	1	Shaft	
20	381567	E	1	Bracket	
21	904640		5	Washer 8,4x22x3	
22	586003		4	Lock nut M8	
23	370978		1	Linkage shaft	
24			1	.Nut	
25	502036		4	Screw 3/8"-16UNCx1 1/4"8.8	
26	904230		4	Washer 10,5x22x2	
30			1	Steering valve	
31	381403		1	Chain supporter	
32	500040		4	Screw M6-1x20 8,8	
33	904735		4	Washer	
35	904214		1	Washer	
36	904739		2	Chain tensioner	
37	904802		1	Threaded stud	
38	586003		1	Lock nut M8	
39	381571		1	Bracket	
40	150004		1	Retainer ring	

- A) For cab
- B) For platform
- C) Outer
- D) Inner
- E) Steering valve

Ref. No.	Part No.	Rem.	Qty	Description	Code
300				Cab Interior (Page 232)	
310				Cab Inside panels (Page 234)	
320				Cab Screens (Page 236)	
330				Cab Door (Page 240)	
340				Cab Wipers front and rear (Page 242)	
350				Cab Mirror, Sun curtain (Page 244)	
360				Cab Electric (Page 246)	
370				Cab Heater system (Page 248)	
380	385434			Cab heater, cpl (Page 250)	
390				Cab Cable harness (Page 252)	

Cab Door

Ref. No.	Part No.	Rem.	Qty	Description	Code
	938224		1	Door, cpl	
1	938016		1	.Door frame	
2	935277		2	.Lock pin	
3	908545	A	2	.Seal list	
4	935268		1	.List	
5	937932		80	.Screw	
6	937391		1	.Screen	
7	935267		1	.List	
8	938017		1	.Lock	
9	908581		1	.Washer	
10	908582		1	.Cover	
12	908583		1	.Bracket	
13	908580		1	.Lock pin	
14	935250		1	.Rod	
15	935249		1	.Retainer	
16	935248		1	.Turning mechanism	
17	935247		1	.Leader	
18	935246		1	.Seal	
19	935244		1	.Door handle with key	
20	935245		1	.Seal	
21	935270		1	.List	
22	937392		1	.Screen	
23	935269		1	.List	
24	935273		2	.Hinge	
25	935271		4	.Washer, Flexible	
26	935272		4	.Washer, Black	
27	935276		1	.Bracket	
28	935266		1	.List	
29	937390		1	.Screen	
30	935265		1	.List	
31	908545	B	1	.Seal list	
32	937393		1	.Screen	
33	908499		1	.Rubber list	
34	935253		1	.Lock	
35	908987	C	1	.Seal	
36	935255		1	.List	
37	935256		1	.List	
38	935257		1	.Ventilating grill	
39	935258		1	.Panel plate	
40	935260		1	.Panel	
41	935261		1	.Panel	
42	935262		1	.Support list	
43	935263		1	.Panel	
44	938043		1	.Panel	
45	938024		1	.Door stop	
46	937121		2	.Ball joint	
47	938018		1	.Gas spring	

- A) L=1,4 M
 B) L=1,1 M
 C) L=0,75 M

385434 Cab heater, cpl

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	938625		1	Casing	
2	938633		1	Hose adapter	
3	938629		1	Cover	
4	938635		2	Sleeve	
5	938630		1	Bracket	
6	938636		2	Drain valve	
7	938639		1	Heater coil	
8	938627		1	Fan bracket	
9	938638		1	Fan	
10	938641		1	Coil bracket	
11	938626		1	Cover	
12	938643		1	Plug	
13	938640		1	Cover	
14	938634		2	Knob	
15	939693	A	1	Heater control valve	
16	313003		2	Hose clamp 15-24	D
17	384881		1	Hose	
18	938645		1	Bowden cable	
19	938647		1	Cable harness	
20	938643		1	Plug	
21	938620		2	Knob	
22	938618		1	Decal	
23	938617		1	Control panel	
24	385134		1	Lock washer	
25	938621		1	Rotary control	
26	938622		1	Switch	
27	938632		1	Hose adapter	
28	384927		2	Grommet	
29	938628		1	Cover	
30	938644		1	Cap	

A) Replaces Heater control valve P/N 938642.

Cab, 12V contact

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	388981		1	Cable harness	
2	901227		1	Fuse 10A	
3	939603		1	Cable harness	
4	938691		2	Screw	
5	939521		1	Sign 12V	
6	939522		1	Contact 12V	

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Documentation OMS602D	
			1	.Warranty registration card	
			1	.Operating instruction O602	
			1	.Maintenance instruction M602	
			1	.Spare parts catalogue SCA602D	
			1	.Instruction manual Cummins QSB5.9C	
2			1	.Operating / maintenance instruction OM602	
3			1	.Safety manual RSAFE	
4	358881		1	Pad lock	

Air conditioner assembly

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Condensor assembly (Page 282)	
2	384877		4	O-ring	
3	384876		1	Hose	
4	384190		1	Cable harness	
5	384878		4	O-ring	
6	384874		1	Hose	
7	385152		1	Protecting cover	
8	500023		3	Screw M8-1,25x40 8,8	
9	904229		3	Washer 8,4x16x1,5	
10	346230		3	Clamp	
11	383424		1	Drying filter	
12	570006		1	Nut M10	
13	904567		1	Washer 10,5x28x6	
14	500013		1	Screw M6-1x16 8,8	
15	904228		4	Washer 6,4x12x1,5	
16	383409		1	Holder	
17	586003		2	Lock nut M8	
19	904230		1	Washer 10,5x22x2	
20	500192		1	Screw M10x80	
21	483481		1	Hydraulic hose	
23	570004		1	Nut M6	
24	921056		2	Clamp	
25	334604		3	Connector	
26	483548		1	Hydraulic hose	
27	234131		1	Elbow 45, O-ring	
28	904229		2	Washer 8,4x16x1,5	
29	500239		2	Screw M8-1.25x50	
30	370720		1	Direction control valve	
31	234990		2	Elbow 90	
32	482328		1	Hydraulic hose	
33	234659		1	Straight o-ring connector	
34			1	Compressor assembly (Page 284)	
35	483548		1	Hydraulic hose	
36	384879		2	O-ring	
37	384873		1	Hose	
38	334135		1	T-connector	
39	381011727		1	Hydraulic hose	
40	313093		1	Pipe clamp	
41	384875		1	Hose	
42			1	Evaporator assambly (Page 286)	

Anti spin CA

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	382098		1	Control unit	
2	382070		1	Cable harness	
3	500019		1	Screw M8-1,25x16 8.8	
4	904734		3	Washer 8,4x26x4	
5	925846		1	Screw	
6	921039		1	Pipe clamp	
7	373902		1	Sensor	
8	500022		1	Screw M8-1,25x30 8,8	
9	960727		2	Clamp	
10	500021		1	Screw M8-1,25x25 8,8	
11	383856		1	Rear axle No-Spin, Option (Page 100)	
12	483483		2	Hydraulic hose	
13	382133		1	Hydraulic pump	
14				Anti spin, Potentiometer installation (Page 294)	
15	904217		1	Sensor	
16	904216		1	Sensor	
17	382089		1	Hydraulic motor	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL