


**DYNAPAC  
CC322  
SPARE PARTS  
CATALOGUE  
SCC322-3EN2**



***DYNAPAC***

Part of the Atlas Copco Group

Box 504, SE-371 23 Karlskrona, Sweden  
Phone: +46 455 30 60 00, Fax: +46 455 30 60 10  
[www.dynapac.com](http://www.dynapac.com)

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**TABLE OF CONTENTS**

**Page**

	Plates and decals .....	224
	<b>Standard equipment .....</b>	<b>228</b>
	Standard equipment .....	230
	<b>Optional equipment .....</b>	<b>232</b>
	Eyelet .....	234
	SMV-sign, Plate holder .....	236
	Edge cutter, cpl .....	238
	Edge cutter .....	240
	Edge cutter Hydraulics without offset .....	242
	Edge cutter Hydraulics with offset .....	244
	Edge cutter Sprinkler system .....	246
	Air conditioner assembly .....	248
	Condensor assembly .....	252
385766	Heater/AC unit .....	254
	Roof hatch .....	256
	Tool equipment .....	258
	Asphalt temperature meter .....	260

**940238 Service kit 500h, Deutz 4cyl 2011**

<b>Ref. No.</b>	<b>Part No.</b>	<b>Rem.</b>	<b>Qty</b>	<b>Description</b>	<b>Code</b>
1	939515		1	Oil filter	A

**938891 Drum rotation kit**

<b>Ref. No.</b>	<b>Part No.</b>	<b>Rem.</b>	<b>Qty</b>	<b>Description</b>	<b>Code</b>
1	160105		1	O-ring 70	D
2	929447		1	V-ring	D
3	116041		1	Taper roller bearing	D
4	386272		1	Sealing	D

**Frames**

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	904330		20	Screw	
2	904232		40	Washer	17x30x3
3	500074		20	Screw	
	500085	A	20	Screw	
4	925519		16	Screw	
5	904231		32	Washer	13x24x2
7	391290	B	1	Fork	
8	392093	C	1	Fork	
9	391289	D	1	Fork	
10	391981	E	1	Fork	
15	374373		2	Spacer block	
16	359512		N	Shim	T=5 mm
17	359513		N	Shim	T=3 mm
18	359514		N	Shim	T=1mm
19	359515		N	Shim	T=5 mm
20	359516		N	Shim	T=3 mm
21	359517		N	Shim	T=1mm
22	359232	G	1	Frame	
23	376537	H	1	Frame	
24			1	Articulated link ( Page 42 )	
26	925208		10	Screw	M20x90
27	904233		10	Washer	21x36x3
28	928850		10	Screw	M20-2,5x120 10,9
29	500175		18	Screw	M12x60 10,9
30	903366		10	Screw	M12x160 10,9
31				Not used on this model	
32	904231		66	Washer	13x24x2
33	570104		14	Nut	M12
34	500269		24	Screw	M12-1,75x50 10,9
35	359314		1	Spacer ring	
			1	Bearing, offset	
36	377513		1	Yoke	
38	359589		1	Safety rod	
39	347119		2	Shaft	D
40	357488		1	Spring	
41	343775		2	Wire	
42	635061		3	Hair clip	D
43	500191		2	Screw	M10x14
44	904230		2	Washer	10,5X22X2
48	359588		1	Cover	
49	904357		6	Screw	
55	904233		10	Washer	21x36x3
56	904331		4	Screw	
57	904230		8	Washer	10,5X22X2
58			12	Shock absorber	
59	374374		2	Spacer block	
60	500055		4	Screw	

- A) More then 5mm shim
- B) Front left hand
- C) Rear left hand
- D) Rear right hand
- E) Front right hand
- G) Front
- H) Rear

Scrapers, spring loaded, rear drum

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	359455		2	Scraper bracket	
2	388648		1	Scraper	B
3	392620		1	Scraper bracket	
4	376736		1	Sprinkler pipe	
5	391710		1	Scraper bracket	
6	388648		1	Scraper	B
7	500056		18	Screw	M12x45 8,8
8	904231		40	Washer	13x24x2
9	586019		13	Lock nut	M12
10	500049		4	Screw	M12-1,75x60 8.8
11	904703		4	Washer	13x24x4
12	391710		1	Scraper bracket	
13	904557		8	Washer	10,5x22x4
14	500161		4	Screw	M10-1,5x45 8,8
15	904230		12	Washer	10,5X22X2
16	500031		8	Screw	M10-1,5x40 8,8
17	570006		8	Nut	M10
18	387690		2	Scraper bracket, cpl	
19			1	.Scraper bracket	
20			1	.Scraper bracket	
21	390809		1	.Extension spring	
22	500267		1	.Screw	M12x120 8,8 FZB
23	904231		1	.Washer	13x24x2
24	586019		1	.Lock nut	M12
25	500240		1	.Screw	M10x40H 8,8
26	570006		1	.Nut	M10
27	500003		1	.Screw	
28	928381		1	.Washer	6,4x18x1,6
29	388490		1	.Release device	
30	387693		2	Scraper bracket, cpl	
31			1	.Scraper bracket	
32			1	.Scraper bracket	
33	390809		1	.Extension spring	
34	500267		1	.Screw	M12x120 8,8 FZB
35	904231		1	.Washer	13x24x2
36	586019		1	.Lock nut	M12
37	500240		1	.Screw	M10x40H 8,8
38	570006		1	.Nut	M10
39	791963		9	Lock nut	M12

**Sprinkler system Tanks**

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Sprinkler system, front ( Page 54 )	
2			1	Sprinkler system, rear ( Page 58 )	
3	358846		2	Strainer	D
4	904913		4	Washer	Neopren
5	313001		2	Hose clamp	
6	244054	E	2XL	Hose reinforced	
7	924544		2	Hose connection	
8	925599		1	Valve	
9	904556		4	Washer	8,4x16x3,0
10	500022		4	Screw	M8-1,25x30 8,8
11	500053		4	Screw	M8-1,25x20 8.8
12	904229		4	Washer	
13	586003		4	Lock nut	M8
14	381619		2	Wire	
15	513012		8	Screw	M6x20 10,9
16	586002		20	Lock nut	M6
17	928467		8	Washer	
18	904228		12	Washer	
19	928041		4	Hinge	D
20	385339		2	Cover	
21	904914		4	Tap	
22	903342		4	Retaining ring	
23	903344		4	Lock	
24	923253		8	Rivet	
25	359001	A	1	Water tank	
26	359002	B	1	Water tank	
	902916	3	1	.Adapter kit	
27			1	..Connector	
28			1	..Nut	
29			1	..Sealing	
30			1	..Washer	
	902917	3	1	.Adapter kit	
31			1	..Connector	
32			1	..Nut	
33			1	..Sealing	
34			1	..Washer	
	902918	3	1	.Plug kit	
35			1	..Gasket	
36			1	..Plug	
37	359003	3	1	.Cap	D
38	202041	F	2XL	Rubber strip	
39	357138		1	Ventilating filter	A
40	904232		4	Washer	17x30x3
41	570008		4	Nut	M16 -8
42	359444		4	Holder, cpl	
43	904405		2	Screw	
44	904405		2	Screw	
45	359446		2	Holder	
47	374545		4	Cover	
48	902223		16	Screw	
49	382337		3	Rubber cloth	
50	904901		3	Tape	

3) Included in both sprinkling tanks, item 25 & 26

A) Front

B) Rear

E) Length as required

F) L=645 mm

**Sprinkler system, rear**

Ref. No.	Part No.	Rem.	Qty	Description	Code
54	791135		1	Connector	
55	791128		2	Quick coupling	
56	791126		1	Quick coupling	
57	814071		2	Hose clamp	
58	924996		1	Hose connection	D
59	903886		2	Adapter	
60	791125		1	Quick coupling	
61	903769		2	Sealing	
63	903626		1	Connector	
64	904878	G	1XL	Hose reinforced	
65	814071		2	Hose clamp	
66	791127		1	Quick coupling	
67	791126		1	Quick coupling	
80		H	1	Sprinkling tank, rear	
81		H	1	Plastic hose	

G) L=0,30 m

H) See Sprinkler systems, tanks

Diesel engine Deutz TD2011 L04 I

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	395504		1	Diesel engine	
2	939515		1	.Oil filter	A
3	903938		1	.Fuel filter	A
4	909369		1	.Solenoid	D
5	908295		1	.Oil temp guard	D
6	939837		1	.Alternator	C
7	939478		1	..Charging regulator	D
	940222		1	..Charging regulator	13.8V
8	939838		1	.Oil pressure switch	D
9	940980		1	.Starter	
10	939839		1	.V-belt	A
11	936147	A	1	.Strainer	A
12	382351	B	1	Engine bracket	
13	372869	C	1	Engine bracket	
14	359402		1	Coupling, cpl	
15			1	.Hub	
16	902843		1	.Flange	D
17	508095		1	.Screw	
18	359403		1	Pump bracket	
19	330383		1	Cap hydraulic	
20	230515		1	Connector	
21	904233		2	Washer	21x36x3
22	330331		3	Washer	18,2x23,9x1,5
23	747691		1	Hollow screw	
24	500274		10	Screw	
25	357275		4	Steel tube part	
27	508096		9	Screw	M10-1,5x25H 8,8
28	500021		6	Screw	M8-1,25x25 8.8
29	372791	D	1	Hydraulic hose	
30	313002		2	Hose clamp	13-20 mm
31	500122		4	Screw	
32	904231		4	Washer	13x24x2
33	921132		1	Clamp	
34	904229		1	Washer	
35	500019		1	Screw	
36	791969		1	Hose	
37	500050		2	Screw	
40	372588		1	Spacer	
41	372792		1	Bracket	
42	921063		1	Clamp	
43	500040		1	Screw	M6-1x20 8,8
44	570004		1	Nut	M6
45	904228		1	Washer	
46	903320	G	4	Shock absorber	D
47	939840	G,H	1	Toothed belt kit	B
48	939976	G	1	Toothed belt	

- A) Fuel lift pump
- B) Front
- C) Rear
- D) Engine oil drain
- G) Included in item 1
- H) Belt and roller

**Propulsion system Pump**

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	393336		1	Hydraulic pump	C
2	929226		4	Flange half	
3	382113		1	Connector	
4	234243		2	T-connector	
6	483933		1	Hydraulic hose	D
11	334604		2	Elbow 90, O-ring	
12	359557		1	Holder plate	
13	483493		1	Hydraulic hose	
14	334468		1	Adapter	
15	904004		2	O-ring	D
16	483071		1	Hydraulic hose	
18	500028		4	Screw	M10-1,5x25 8.8
20	502037		8	Screw	3/8"-16UNCx1.1/2" 8.8
21	904637		8	Washer	10x18x2
22			1	Hydraulic oil filter	
	359551		1	.Filter head	
	372229	A	1	.Hydraulic oil filter element	A
	359552	B	1	Cleaning filter element	Maximum 50 hours use
23	500194		4	Screw	M12x40H 8.8
24	904213		4	Washer	13x30x4
30	483934		1	Hydraulic hose	D
31	334155		2	Elbow 90	
32	923405		2	Measuring nipple	D
36	904230		14	Washer	10,5X22X2
41	570006		4	Nut	M10
44	482955		1	Hydraulic hose	
45	334237		1	Adapter	
49	904110		1	Connector	
52	382232		1	Hose clamp	
53	372912		1	Hose clamp	
54	500029		7	Screw	M10-1,5x30 8.8
55	904557		6	Washer	10,5x22x4
57	374163		1	Hose clamp	
58	500021		4	Screw	M8-1,25x25 8.8
59	904640		3	Washer	8,4x22x3
78	393338		1	Flushing valve	
	160188	C	5	.O-ring	
79	791409		4	Straight connector orfs	
80	483905		2	Hydraulic hose	
81	791414		2	T-connection, O-ring with swivel	
82	791401		2	Elbow 90, O-ring with swivel	
83	791847		2	Straight connector	
84	500077		2	Screw	
104	483935		1	Hydraulic hose	D
105	392309		1	Hydraulic hose	D
108	903989		1	Bolt	
109	570005		3	Nut	M8
110	904229		4	Washer	
111	375272		1	Connector	
112	374165		1	Cover	
114	374200		3	Spacer	
115	924585		3	Cotter pin	
120	904010		2	O-ring	
123	482182		1	Hydraulic hose	D
124	234810		1	Elbow 90, O-ring	
125	334156		1	Adapter	
126	903774		1	Check valve	

- A) Replacement
- B) Cleaning
- C) For plugs

**359140 Valve Vibration**

<b>Ref. No.</b>	<b>Part No.</b>	<b>Rem.</b>	<b>Qty</b>	<b>Description</b>	<b>Code</b>
1			1	Valve, cpl	Vibration
2	909201		1	.Valve block	
3	909202		2	.Solenoid valve	
5	909208		8	.O-ring	D
6	909204		8	.Screw	
7	909205		2	.Check valve	D
8	909206		1	.Pressure relief valve	D
9	909207		5	.Plug with sealing	
10	902937		2	.Plug	
11	909217		2	.Plug	
12	909216		2	.O-ring	

**Steering system**

Ref. No.	Part No.	Rem.	Qty	Description	Code
93	500021		3	Screw	M8-1,25x25 8.8
97	370155		1	Valve block	
98	160287		4	O-ring	D
99	903773		2	Screw	M10x1x50 8,8
101	235002		1	Connector	
102	904115		1	Bulkhead elbow	D
103	234512		1	Bulkhead union	
104	482257		1	Hydraulic hose	
105	482992		1	Hydraulic hose	
106	482993		1	Hydraulic hose	
107	603009		14	Washer	
108	371669		1	Straight connector	
109	903812		1	Hydraulic hose	
110	903831		1	Nut	M12
111	904231		1	Washer	13x24x2
112	926214		2	Grease fitting	D
113	372680		1	Bracket	
114	921119		1	Pipe clamp	
115	904229		1	Washer	
116	234662		1	Elbow 45	
200				Existing parts	

**Brake system**

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	234233		2	Adapter	
2	484095		1	Hydraulic hose	D
5	234349		1	Connector	
6	482782		1	Hydraulic hose	
7	792094		2	Elbow 90	
8	334524		1	Connector	
10	484096		1	Hydraulic hose	
11	334234		1	Tee-connector	
12	334410		1	Adapter	
13	483463		1	Hydraulic hose	
14	334463		3	Connector	
15	392743		1	Hand pump	
16	392954		1	Bracket	
17	500019		2	Screw	
18	586003		2	Lock nut	M8
19	904229		4	Washer	
20	500021		2	Screw	M8-1,25x25 8.8
21	482757		1	Hydraulic hose	
22	635061		2	Hair clip	D
23	343775		1	Wire	

**Electric battery switch**

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	384038		1	Cable harness	
	357562		1	Relay holder	
2	384055		1	Holder plate	
3	791077		1	Electric battery switch	
4	287597		1	Relay	D
5	508020		1	Screw	M5x20
6	904281		2	Washer	5,3x10x1
7	586001		1	Lock nut	M5
8	500021		2	Screw	M8-1,25x25 8.8
9	904229		4	Washer	
10	570005		2	Nut	M8
12	904015		1	Fuse holder	
13	901226		1	Fuse	7.5A
20		1	1	Cable harness	
21		1	1	Battery cable	
22		1	1	Battery cable	

1) See section " Electrical equipment ".

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**Instrument panel Upper right**

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	345870		1	Plug	
2	359343		1	Fuel gauge	D
	355258		1	.Lamp holder	
	985012		1	.Bulb	D
		1	1	Fuel level sender	D
3	359344	A	2	Water gauge	D
	355258		1	.Lamp holder	
	985012		1	.Bulb	D
		2	2	Water level sender	D
5		3	1	Control panel plate	D
6	903657		2	Screw	
7	343550		2	Connection cable	
8	903927		2	Cable	
9	904016		3	Cable	

- 1) See section " Fuel system "
- 2) See section " Sprinkler system, tanks "
- 3) See section " Instrument panel, lower right "
- A) Sprinkler tanks

**Driving lights Direction & licenseplate light**

Ref. No.	Part No.	Rem.	Qty	Description		Code
			1	Driving lights		
1			1	Instrument panel ( Page 132 )	Lower left	
2	376178		1	Cable harness		
3	376179		1	Cable harness		
4	376180		1	Cable harness		
5	902066	A	2	Headlight		
	904313	B	2	Headlight		
6	904317	C,F	1	Direction lamp		
	937108		1	.Lamp glass		
	904318	C,G	1	Direction lamp		
	937109		1	.Lamp glass		
7	904315	D,H	1	Direction lamp		
	937106		1	.Lamp glass		
	904316	D,I	1	Direction lamp		
	937107		1	.Lamp glass		
8	385264		1	Cable harness		
9	901182		2	Reflector, red		B
10	901183		4	Reflector, yellow		B
11	791389		8	Drive screw		
12	900790		2	Bulb	60/55w H4	B
13	928502		2	Bulb	21w	B
14	928502		4	Bulb	21w	B
15	985014		4	Bulb	5w	B
16	533030		8	Screw		
17	586001		8	Lock nut	M5	
18	601001		8	Washer		
19	902227		2	Work light		
20	392930		2	Junction box		
21	901369		2	Bulb	55w H3	B
22	904032	E	1	Fuse holder		
23	904039		1	Fuse	50A Red High	D
101	902064		2	Direction lights		
102	371185		2	Bracket		
103	926611		4	Screw		
104	586001		8	Lock nut	M5	
105	904281		8	Washer	5,3x10x1	
106	985013		2	Bulb	12V,5W	B
107	500006		4	Screw	M5x16	
201	929455		2	Licence plate light		
202	533038		4	Screw		
203	586002		4	Lock nut	M6	
204	904228		4	Washer		
205	985013		2	Bulb	12V,5W	B

- A) Right asym
- B) Left asym
- C) Yellow/red
- D) Yellow/white
- E) Incl in item 2
- F) Rear, left
- G) Rear, right
- H) Front, left
- I) Front, right

**Tachograph**

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	371885		1	Instrument box	
2	370425		1	Support	
3	586002		2	Lock nut	M6
4	928381		2	Washer	6,4x18x1,6
5	900904	A	1XL	Grommet	
6	541703		4	Screw	M6x16
7	385406		1	Cable harness	
14	901209		1	Tachograph	
15	392567		1	Cable harness	

A) L=200 mm

Drivers seat, turn-over

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	359900		1	Seat frame	
2	381400		1	Bearing cover	
4	359574		1	Cover	
5	359914		1	Cover	
6	359915		1	Grommet	
7	391346		1	Seat frame	
8	377518		1	Drivers seat, cpl	
	945622		1	.Seat switch	
9	945661	B	1	.Adjuster kit	D
10	390963		1	Arm rest kit	
11	359920		1	Plug	
13	372964		1	Steering wheel, cpl	
			1	.Steering wheel and knob	
	935614		1	.Turning knob	D
	935613		1	.Cover	
16	391163		1	Steering column ( Page 168 )	C
17	359919		1	Shaft	
18	359916		2	Chain wheel	D
19	359921		1	Chain	D
20	903917		1	Bearing outer	
	903918		1	Bearing inner	
21	516051		2	Set screw	
22	350009		2	Flat key	D
23			1	Cross sliding ( Page 164 )	Controls
24	359419		1	Control cover	
26	904206		16	Screw	M6X16
27	500021		8	Screw	M8-1,25x25 8.8
28	921104		2	Clamp	
29	500028		3	Screw	M10-1,5x25 8,8
30	904557		3	Washer	10,5x22x4
31	570006		3	Nut	M10
33	904229		12	Washer	
34	586003		2	Lock nut	M8
35	500040		10	Screw	M6-1x20 8,8
36	904228		7	Washer	
37	586002		7	Lock nut	M6
38	570005		8	Nut	M8
40	372672		1	Chain guard	
41	603001		2	Washer	TB6,7x14x3
42	381403		1	Chain supporter	
43				Not used on this model	
44			1	Cross sliding ( Page 166 )	Carrier
45			1	Cross sliding ( Page 164 )	Controls
46	904735		4	Washer	
47	904231		2	Washer	13x24x2
48	313041		1	Cable ties	L=186 mm
100	348331	A	1	Seat cover	D

- A) Option  
B) Left and right sliding rail

Forward and reverse control

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	909747		1	Framing	
2	908200		2	Bearing	
3	909748		1	Cam disc	
4	909749	A	2	Cable	
	570004		1	.Nut	M6
	908193		1	.Fork	
5	909751		1	Bracket	
6	922325		1	Spring ball plunger	D
7	909750		1	Cam	
8	573004		1	Nut	
9	533038		2	Screw	
10	573004		2	Nut	
11	533010		1	Screw	
12	313147		1	Hose clip	
17	909122		2	Grommet	
18	902203		1	Plug	
19	376396		1	Cable harness	
20	359575		1	Control lever	
21	348481		1	Cover	D
22	371009		2	Screw	
23	928497		1	Push button	D
24	359940		1	Washer	
25	359928		1	Control cover	
26	500053		2	Screw	M8-1,25x20 8.8
27	904229		2	Washer	
28	381676		1	Bracket	
30	371507	D	1	Spacer	
31	359932		1	Control bracket	
32	903799		3	Screw	M6 x 70
33	904228		3	Washer	
34	359931		1	Control bracket	
35	586003		2	Lock nut	M8
36	904229		4	Washer	
37	500023		2	Screw	M8-1,25x40 8,8
38	465013		2	Clamp	D
39	921104		1	Clamp	
40	500198		1	Screw	
41	904231		1	Washer	13x24x2
42	586019		1	Lock nut	M12
43	359929		1	Cover	
44	903658		6	Screw	M5x10
59	373177	B	1	Yoke	
60	570019	B	2	Screw	
61	508092		1	Screw	M8-1,25x20H 8,8
62	904229		2	Washer	
63	586003		1	Lock nut	M8

- A) Forward and reverse
- B) Not for cab
- D) Only on early machines.

Rops and fops With seat belt

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	370329		1	Rops	
2	370343		1	Rops roof	
	370349		1	Fops roof	
3				Not used on this model	
4				Not used on this model	
5	372631		1	Insulating material	
6	903792		10	Screw	
7	903736		10	Nut	
8	904234		20	Washer	25x45x4
9	370766	1	1	Seat belt	
	377677		1	Seat belt	2"
	383200	B,2	1	Seat belt	3"
	379637	B	1	Seat belt	3"
10	904180	A	2	Plug	
11	500047		10	Screw	M8-1,25x35 8,8
12	904734		10	Washer	8,4x26x4
13	380176		1	Absorbent holder	
14	376488		1	Absorbent holder	
15	904619		12	Blind rivet	
16	904734		10	Washer	8,4x26x4
17	500170		2	Screw	
18	500180		1	Screw	M8X110 8,8
19	500019		4	Screw	
20	586003		3	Lock nut	M8
21	383898	C	2	Hook	
22	383900	D	2	Hook	

- 1) Replaced by PN 377677.
- 2) Replaced by PN 379637.
- A) For lifting holes
- B) Option, 3"
- C) Valid for Rops.
- D) Valid for Fops.

**Cab, inside panels**

<b>Ref. No.</b>	<b>Part No.</b>	<b>Rem.</b>	<b>Qty</b>	<b>Description</b>	<b>Code</b>
				Cab, cpl	
100	938806		2	.Panel	
101	938807		1	.Panel	
102	938808		1	.Panel	
103	938809		1	.Panel	
104	938810		1	.Panel	
105	938811		1	.Panel	
106	908535		1	.Panel	
107	908536		1	.Panel	
108	908529		1	.Panel	
109	908530		1	.Panel	
110	908531		1	.Panel	
111	908532		1	.Panel	
112	908540		1	.Panel	
113	908542		1	.Panel	
114	938812		1	.Panel	
115	908544		1	.Panel	
116	908537		1	.Panel	
117	938813		1	.Panel	
118	908539		1	.Panel	
119	908541		1	.Panel	
120	938677		50	.Screw	

**Cab, heater and, fan system**

Ref. No.	Part No.	Rem.	Qty	Description	Code
			1	Cab, cpl	
250	385769		1	.Heater unit ( Page 202 )	
251	385442		4	.Air nozzle	
252	908599	A	1XL	.Hose	
253	908600		2	.Clamp	
254	908598		4	.Nozzle	
255	938691		16	.Screw	
256	938872	B	1XL	.Hose	
257	938873	C	1XL	.Hose	
258	938874		2	.Clamp	
259	500153		2	.Screw	
260	938871		1	.Hose clamp	
261	570004		2	.Nut	M6
300	370761		2	Hose	
301	747691		2	Hollow screw	
302	330331		6	Washer	18,2x23,9x1,5
303	371727		4	Sleeve	
A)	L=1,50 m				
B)	L=2,75 m				
C)	L=2,90 m				

**Cab Screens**

Ref. No.	Part No.	Rem.	Qty	Description	Code
			1	Cab, cpl	
28	901315		8	.Screw	
50	937395		1	.Front screen	Green
51	908546		2	.List	
53	938834	A	1XL	.Sealing strip	
54	938616		1	.Screen	Green
55	938839		1	.List	
56	938840		1	.List	
57	938834	B	1XL	.Sealing strip	
58	938614		1	.Screen	Green
59	938841		2	.List	
60	938834	C	1XL	.Sealing strip	
61	938613		1	.Screen	Green
63	938834	A	1XL	.Sealing strip	
64	938612		1	.Screen	Green
65	908573	D	1XL	.Sealing	
66	908574	D	1XL	.Sealing	
67	938837	E	1XL	.Sealing strip	
68	938615		1	.Screen	Green
69	908556		2	.List	
70	938836		2	.List	
71	938834	F	1XL	.Sealing strip	
72	937403		1	.Screen	Green
73	908764		2	.List	
74	908573	D	1XL	.Sealing	
75	938834	A	1XL	.Sealing strip	
76	938566		1	.Screen	Green
79	938834	G	1XL	.Sealing strip	
80	937405		1	.Screen	Green
81	908993		1	.List	
82	908557		1	.List	
83	938834	B	1XL	.Sealing strip	
84	938567		2	.Screen	Green
85	938837	E	1XL	.Sealing strip	
86	938838		8	.List	
87	937932		48	.Screw	
89	908574	D	1XL	.Sealing	
177	908575		2	.Slide bar	

- A) L=1,8 m
- B) L=3,0 m
- C) L=1,0 m
- D) L=1,4 m
- E) L=1,3 m
- F) L=2,5 m
- G) L=2,1 m

**Radio and cassette/cd player**

<b>Ref. No.</b>	<b>Part No.</b>	<b>Rem.</b>	<b>Qty</b>	<b>Description</b>	<b>Code</b>
1	904939		1	Radio and cassette player	
	791967		1	Radio and cd player	
2	791968	A	1	Loud speakers	
4	202043	C	1XL	Rubber strip	
7	937165	1	1	Antenna	

1) Included in cab.

A) 2 pcs

C) L=0,2 m

Ref. No.	Part No.	Rem.	Qty	Description	Code
1			1	Documentation	CC322
			1	.Warranty registration card	
			1	.Operation instruction	
			1	.Maintenance instruction	
			1	.Spare parts catalogue	SCC322
			1	.Instruction manual	Deutz BF4L 2011/TD 2011 L04 I
2			1	.Operation / maintenance instruction	A5
3			1	.Safety manual	RSAFE
4	358881		1	Pad lock	

Edge cutter

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	372378		1	Edge cutter, cpl	
20	909466	B	1	.Holder plate	
31	909465	A	1	.Holder plate	
32	909301		1	.Seal	
33	909302		2	.Bearing	
34	936004		1	.Housing	
35	909304		1	.Washer	
36	909305		1	.Nut	
37	909306		1	.O-ring	
38	936005		1	.Cover	
39	909308		1	.Grease nipple	
40	909309		1	.Protection	
41	936006		4	.Screw	
42	909311		4	.Retaining washer	
51	909467		1	.Lever	
52	909301		1	.Seal	
53	909302		2	.Bearing	
54	909303		1	.Tool holder	
55	909304		1	.Washer	
56	909305		1	.Nut	
57	909306		1	.O-ring	
58	909307		1	.Cover	
59	909308		1	.Grease nipple	
60	909309		1	.Protection	
61	909310		4	.Screw	
62	909311		4	.Retaining washer	
63	909312		4	.Retaining ring	
64	909313		4	.Screw	
70	909288		2	.Nut	
71	909289		2	.Washer	
80	909291		1	.Cylinder end	
81	909290		1	.Cylinder	
82	909292		2	.Bearing	
83	909293		4	.Retaining ring	
84	909294		2	.Screw	
86	909299		1	.Seal kit	
88	909298		2	.Grease nipple	
91	908787		1	.Cutting disc	8 cm
	938263		1	.Cutting disc	12 cm
92	909237		1	.Edge roller	
101	909274		1	.Sprinkler pipe	
102	909275		1	.Bracket	
103	909276		1	.Connector	
104	909277		1	.Strainer	
105	909278		1	.Nozzle	
106	909279		1	.Nut	
107	909280		1	.Screw	
108	909281		1	.Nut	
110	500197	C	4	Screw	12x90
	500196	D	4	Screw	M12-1,75x80 8.8
111	904231		8	Washer	13x24x2
112	586019		6	Lock nut	M12
113	500117		2	Screw	M12x80H 8,8
114	500134		5	Screw	
115	904232		5	Washer	17x30x3
116	904083		1	Safety decal	

- A) Lower
- B) Upper
- C) Without offset
- D) With offset

**Air conditioner assembly**

<b>Ref. No.</b>	<b>Part No.</b>	<b>Rem.</b>	<b>Qty</b>	<b>Description</b>	<b>Code</b>
70	904557		1	Washer	10,5x22x4
72	372680		1	Bracket	
73	500019		1	Screw	

Asphalt temperature meter

Ref. No.	Part No.	Rem.	Qty	Description	Code
1	388522		1	Cable harness	
2	378116		1	Cable harness	
3	930151		1	Switch	D
4	388561		1	Sign	
5	377819		1	Cable harness	
6	388775		1	Temperature meter	
7	387981		1	Box	
8	387982		1	Temperature sender	
9	500053		4	Screw	M8-1,25x20 8.8
10	904229		4	Washer	
11	791594		1	Grommet	
12	925802		N	Cable ties	L=142 mm
13	313068		N	Cable ties	L=92 mm
14	387988	1	1	Bracket	
15	904653	1	8	Screw	M5x16 A2-70
16	904281	1	4	Washer	5,3x10x1
17	586001	1	4	Lock nut	M5
18	377812	2	1	Temperature meter box, cpl	
19		2	1	.Box	
20	903907	2	1	.Hinge	
21	378052	2	1	.Cover	
22	389111	2	1	.Holder	
23	904909	2	1	.Door bumper	
24	904907	2	1	.Door bumper	
25	904908	2	1	.Rubber part	
26	513008	2	4	.Screw	
27	904228	2	10	.Washer	
	904639	2	4	.Washer	6,7x14x1,5
28	904563	2	8	.Lock nut	M6
29	500013	2	4	.Screw	M6-1x16 8,8
30	513027	2	2	.Screw	M4x16H 10,9
31	904698	2	6	.Washer	
32	923976	2	4	.Nut	
33	902566	A,2	5XL	.Rubber strip	
34	500238	2	2	.Screw	
35	570005	2	2	Nut	M8
36	904556	2	2	Washer	8,4x16x3,0
37	500022	2	2	Screw	M8-1,25x30 8,8
38	904640	2	2	Washer	8,4x22x3
39	358881	2	1	Pad lock	
40	377422		1	Bracket	
41	500019		2	Screw	
42	904229		2	Washer	
43	921065		6	Clamp	
44	904228		6	Washer	
45	586002		6	Lock nut	M6

1) Valid for machines with cab.

2) Valid for platform machines.

A) L= 0,4 m

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL