

Spare Parts Catalogue

4812156762.pdf

Valid for planer serial number:

10000900x0A006571 -



Diesel engine:

Cummins QSB 3.3

Published catalogue issues valid for this planer:

Catalogue

Issue date

4812156762

2012 - 10



CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Frame

Item	Part No	Rem Qty	Description	Code
1	4812000299		Covering, compl. (Page 12)	
2	4812000298	1	Main frame Up to 0A0008998	
	4812117571	1	Main frame From 0A0008999 Up to 0A0009011	
	4812000298	1	Main frame From 0A0009012 Up to 0A0009012	
	4812117571	1	Main frame From 0A0009013 Up to 0A0009463	
	4812000298	1	Main frame From 0A0009464 Up to 0A0009464	
	4812117571	1	Main frame From 0A0009465	
5	D501510219	2	Cover	
11	D501510394	1	Holder	
16	D502010227	2	Gum sealing	
24	4812115457	1	Bumper	
25	D939776137	2	Locking washer	
26	D938151192	2	Hex. screw	
27	4749901806	4	Screw retention	
35	D939776111	16	Locking washer	
36	D938155543	16	Hex. screw	
39	D937626271	2	Coach bolt	
40	4700570005	4	Hex. nut M08	
48	D961175211	2	Plug screw	
50			Main frame, back (Page 20)	
61	4812117568	2	Adapter Except s/n: 0A0009012, 0A0009464 From 0A0008999	
62			Ballast Module Option (Page 24)	

Main frame, back

Item	Part No	Rem Qty	Description	Code
3	D501510453	1	Hinge plate	
4	D501510461	1	Distance piece	
7	D501510348	1	Cover	
8	D501510363	1	Tool box	
9	D501510342	1	Rubber sheeting	
10	D501510343	1	Frame	
12	D501510471	1	Frame	
13	D501510462	1	Bolt	
14	D501510463	1	Bolt	
15	4812002978	1	Fastener	
17	4812002695	1	Socket pin	
18	4749302191	2	Hinge	
19	D930450726	1	Padlock	
21	D930288051	1	Fold-away step	
22	D938165712	1	Hex. screw	
23	4749901632	1	Cylinder screw	
27	4749901806	12	Screw retention	
28	4700500019	4	Hex. screw	
29	4749901595	8	Cylinder screw	
30	4700500021	4	Hex. screw	
31	D939776117	2	Locking washer	
32	4700500035	2	Hex. screw	
33	D939475166	8	Screw	
34	D939394448	2	Cylinder screw	
35	D977522354	1	Sensor Door	
36	4812002917	1	Screw	
37	D938500008	4	Nut	
38	D938761005	4	Cap nut	
41	D930251541	1	Stop block	
42	D930251542	1	Holder	
43		1	Rear door compl. (Page 22)	
46	4700570006	2	Hex. nut M10x1,5	
51	4812001611	1	Console	
52	4812001620	1	Pipe	
53	4700500115	1	Hex. screw	
54	D938500007	1	Hex. nut	
58	D937032544	1	Wing screw	
59	D939776113	1	Locking washer DIN25201	
60	4700500012	2	Hex. screw M06x12H	

Hydraulic components

Item	Part No	Rem Qty	Description	Code
1			Drum drive (Page 32)	

Fine milling drum C10

Item	Part No	Rem Qty	Description	Code
1	D501020146	1	Fine milling drum C10	
2	D930320130	160	. Bit holder	
3	D930418509	160	Bits RP18 see chapter Bit Tools	
	D956901050	1	_Anti-seize	

Lever

Item	Part No	Rem Qty	Description	Code
1	D501520501	1	Lever	
2	4749302357	1	Handle	
3	D501520506	1	Screw	
4	D938500008	1	Nut	

D501560110 Holder, compl.

Item	Part No	Rem Qty	Description	Code
1	D501560111	1	Holder	
2	D934361087	1	Pipe clip	
3	4700570005	2	Hex. nut M08	
4	4700600006	4	Disc	
5	4700500053	2	Hex. head screw M08	

Exhaust system

Item	Part No	Rem Qty	Description	Code
1	D501560124	1	Silencer	
2	D501560128	1	Pipe	
3	4812002842	1	Exhaust pipe	
4	D950401225	2	Clip	
5	D930260013	1	Insulation x m	
6	D930260004	1	Insulation x m	
7	D956990007	1	Adhesive strip x m	
8	D956990006	1	Glue	
9	D930440001	12	Protection	
31	4700600008	4	Washer	
34	D501160131	1	Sealing	
35	4700500029	4	Hex. head screw M10x030H	

Engine equipment

Item	Part No	Rem Qty	Description	Code
5	D501160116	1	Lever	
24	D934801210	1	Universal joint	
25	4749300329	1	Tank Cap	
27	D501560125	1	Suction pipe	
28	D930667553	1	Hose	
29	D501060144	1	Return line pipe	
30	D930211476	1	Fuel indicator	
31	4700600008	4	Washer	
33	4700500028	4	Hex. screw M10x025H	
37	4700570003	2	Hex. nut	
38	4700500008	2	Hex. screw	
39	D938165549	2	Hex. screw	
49	4749901807	14	Screw retention	
52	D930667552	1	Hose	
61	D501560135	1	Holder	
67	4812001929	1	Plate	
68	4812001937	1	Plate	
69	4700508059	2	Cylinder screw	
70	4749900216	4	Hex. screw	
71	D938500007	6	Hex. nut	
74			Oil drain	
76	4749300180	1	Clip	
81	4700500240	2	Screw	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

All wheel drive Front wheel

Item	Part No	Rem Qty	Description	Code
1	D967045031	1	Pump, 3 wheel drive (Page 76)	
2	D951020927		Gear with motor (Page 92)	
4	D963172801	1	Hydr. block (Page 88)	
5	D963155711	1	Handpump	
	4812001636	1	_3/2 way valve	
	D963492653	1	_Control valve	
6	D930296631	1	Ball valve	
9	D960861327	1	Hose	
10	4812002080	1	Hose	
11	4812002081	1	Hose	
12	D960831301	1	Hose	
13	4812002082	1	Hose	
14	4812002083	1	Hose	
15	D960833006	1	Hose	
16	D960832005	1	Hose	
17	D960833675	1	Hose	
18	D960832050	1	Hose assy	
19	D960833551	1	Hose	
20	D960831852	1	Hose	
21	D960873327	1	Hose	
31	D960853966	1	Hose	
32	D960854449	1	Hose	
33	D960852202	2	Hose	
34	D961835220	2	Adapter	
35	D961835207	3	Stud	
38	D961935207	1	Adapter	
39	D961353010	1	Adapter	
40	D961772667	1	Test point	
41	D961935321	2	Adapter	
43	D961935307	1	Adapter	
44	D961919007	3	Screwing	
49	D961935121	2	Adapter	
50	D961175106	1	Plug screw	
51	D961935107	1	Adapter	
52	D961951105	2	Adapter	
54	D961772617	1	Test connector	
55	D961935111	1	Adapter	
56	D961919021	1	Swivel nut run tee	
57	D961920661	2	Reduction union	
58	D961121018	1	Adapter	
59	D961935337	2	Adapter	
60	D961906006	1	Adapter	
63	D961907007	3	Adapter	
64	D961772670	1	Test connector	
66	4749300511	2	Tube clip	
67	4749300384	2	Tension plate	
68	D938165659	2	Hex. screw	
69	D961941073	1	Adaptor	

Steering and levelling

Item	Part No	Rem Qty	Description	Code
1	D501040127	2	Guide plate middle, right	
2	D501040126	2	Guide plate rear, right	
3	D966057210	1	Hydraulic motor	
	D932785874	1	_Seal kit for hydr. motor	
	D931701196	1	_Feather key	
	D932785830	1	_Sealing washer	
4	D501040130	1	Gear wheel	
5	D501140104	1	Plate	
6			Dipstick, compl. (Page 102)	
7	D501140102	1	Distance washer	
8			Steering control unit (Page 104)	
10	4811000096	8	Hex. socket countersunk screw M10x020H, 10.9	
11	4700500194	4	Screw	
12	4700500037	4	Hex. head screw M12	
13	4700904231	4	Steel plain washer M12	
14	D937580010	2	Ring eye bolt	
16	4812000622	2	Torsional safety	
17	4700513013	4	Hex. socket countersunk screw	
21	4812000647	1	Shaft	
22	4812000624	2	Guide rail	
23	4700513009	4	Hex. socket countersunk screw	
24	D937944487	1	Threaded pin	
26			All wheel drive (Page 106)	
			One wheel drive (Page 108)	
27			Front axle Up to 0A008998 (Page 110)	
			Front axel From 0A008999 (Page 112)	
28	D501140103	1	Disc	
29	4700513010	1	Hex. socket countersunk screw	
30			Levelling left (Page 114)	
31			Levelling right (Page 118)	

Front axle

Item	Part No	Rem Qty	Description	Code
1	D501150113	1	Wheel support	
2	D501050115	1	Wheel	
	D501050116	1	_Rim	
	D952065000	1	_Steel bandage	
3	4700600017	24	Disc	
4	D937932442	12	Cylinder screw	
5	D937932440	12	Cylinder screw	
6	4700925785	4	Hex. socket screw M06x012H	
7	D951020927	1	Gear with motor Replaced by kit 4812158051 (Page 92)	
8	D935225790	1	Bearing	
9	4749900308	10	Screw	
11	4812000613	1	Cover plate	

Water system

Item	Part No	Rem Qty	Description	Code
1	4812116623	2	Hose connection	
2	D930550014	1	Angle	
3	D930296645	1	Ball valve	
4	D930206204	1	Clutch fast part	
5	D930129730	1	Clutch blind part	
6	4812000448	1	Supporting surface	
7	D930667563	1	Hose	
8	D930177509	2	Hose connection	
10	4700500048	1	Hex. screw	
12	D930290105	2	Hinged split pin	
13	D501210148	1	Nozzle holder	
14	D501190108	1	Hose	
15	D930520314	1	Equal-tee	
16	4749220650	2	Stud	
18	D961935108	1	Adapter	
19	D967342562	1	Water pump	
21	4812000451	1	Cover	
22	4812000278	1	Water tank	
23	D930480074	1	Tank Cap	
24	4812118675	1	Frame	
25	4812000468	1	Air inlet	
26	4812000487	1	Flow divider	
27	D961355024	4	Swivel nut elbow	
28	D930296461	1	Ball valve	
29	4749220805	1	Screwing	
30	4749220527	1	Adapter	
31	4749900168	4	Tapping screw	
32	D960840151	1	Hose	
33	D903508001	2	Connection	
34	D903508005	2	Union nut	
36	D937628377	6	Coach bolt	
37	4700904230	7	Steel plain washer M10 10,5x22x2,0	
38	D938480509	6	Hex. nut	
39	4812000477	1	Pipeline	
40	4749900501	4	Hex. screw	
41	D938490006	4	Hex. nut	
42	4812000450	1	Cover	
43	4700904213	2	Steel plain washer M12x1,75	
44	4700570007	2	Hex. nut	
45	D939143411	14	Flat head cap screw	
46	4749901806	6	Screw retention	
47	D934400050	2	Hose clip	
48	4812000569	2	Tank support	
49	4812000483	1	Pipe	
50	4812000604	2	Hose coupling	
51	4812000602	2	Double nipple	
52	D932333780	2	O-ring	
53	4812000603	2	Union nut	
54	4812000484	2	Rubber hose	
55	D961917008	1	Adapter, 90 adjustable	
56	4749300180	4	Clip	
57	4749300707	1	Clip	
58	4812001976	1	Hose	
59	4812001977	1	Hose	
60	4700792391	01	1 Plastic hose	
61	4700792258	02	1 Edge trim	

01) L=0,3 m

02) L=0,8m

D963176082 Steering block

Item	Part No	Rem Qty	Description	Code
2	D963085313	1	Flow control valve	
3	D963019313	1	Pressure limit valve	
4	D963125332	1	3/2 way valve	
5	D960644926	1	Magnet coil	

Conveyor

Item	Part No	Rem Qty	Description	Code
1			Conveyor (Page 142)	
2			Conveyor (Page 146)	
3			Conveyor (Page 148)	

Drivers Platform

Item	Part No	Rem Qty	Description	Code
1			Seat (Page 152)	
2			Steering control unit (Page 104)	
3			Operators panel (Page 156)	
			Vandalism protection compl. (Page 162)	
4			Levelling system, MOBA Option (Page 164)	
5			Mirror (Page 166)	
6			Pointer (Page 168)	
7			Battery holder, Disconnecter (Page 170)	
8	4700999014	1	Horn	
9	4700500022	1	Hex. head screw M08	
10	4700904229	2	Steel plain washer M08 8,4x16x1,5	
11	4700570005	3	Hex. nut M08	
12	4812001167	1	Back-up alarm	
13	4700904911	1	Back-up alarm	
14	4700513017	2	Hexagon socket flat head cap screw	
15	4700928381	2	Steel plain washer	
16	D977522357	1	Switch See chapter Operators platform	
17	4700600002	4	Disc	
18	4700500238	4	Hex. screw	
19			Operators platform (Page 172)	
20			Foot plate enlargement Option (Page 174)	

Operator panel

Item	Part No	Rem Qty	Description	Code
1	D501580103	1	Operator panel, lower part	
3	D501580108	1	Mounting plate	
5	D977415420	5	SEM-quick connection	
6	D977415415	1	SEM-quick connection	
7	D977415412	2	SEM-quick connection	
8	D977417116	2	Cable screwing	
9	D977416517	3	Counter nut	
10	D977416520	5	Counter nut	
11	D977416512	2	Counter nut	
12	D977418901	2	Corrugated pipe	
13	D977418903	4	Corrugated pipe	
14	D977418902	2	Corrugated pipe	
15	D501580104	1	Operator panel, top part	
29	D977425101	10	Circlip terminal	
30	D977425136	18	Diode terminal	
31	D977730412	3	Micro relay	
32	D977729013	4	Relay socket	
33	D977729010	1	Relay socket	
34	D977730412	1	Micro relay	
35	D977454252	1	Fuse 5A	
36	D977425188	70	Clamp	
37	D977454254	8	Fuse 10A	
38	D977454255	1	Fuse 15A	
39	D977453072	1	Fuse 50A	
41	D977730415	1	Relay	
42	D978008056	1	Amplifier	
44	D977425196	2	Terminal	
45	D977425208	2	Through clamp	

Battery holder, Disconnecter

Item	Part No	Rem Qty	Description	Code
1	D977504059	1	Master switch	
	D977504060	1	_Lever	
2	D977418421	4	Cover for battery poles	
3	D977455758	1	Fuse holder	
4	D977022250	2	Battery	
5	D977453085	3	Fuse 50A	
6	D977730416	1	Relay	
8	4812002554	1	Fludh glow control	
21	D501580126	1	Battery unit cable	
22	D501580127	1	Cable harness W103	
23	D501580130	1	Cable harness W106	
24	D501580129	1	Cable harness	
25	D936750326	4	Flat head cap screw	
26	4700500012	4	Hex. screw M06x12H	
27	D938191013	6	Hex. nut	
28	D938165547	2	Hex. screw	
29	4812000526	1	Battery cover	
30	D939142309	4	Flat head cap screw	
31	4749901806	4	Screw retention	
32	D455014510	1	Clamping strip	
33	4700570005	2	Hex. nut M08	
34	D938150682	1	Screw	

Working light

Item	Part No	Rem Qty	Description	Code
2	D977900137	1	Working lamp	
3	D977999004	1	Slip-on pipe	
4	4749140026	1	Rotating light	
	D977335101	1	_Bulb 70W	
5	4700528041	1	Wing screw M8x25	
6	4700500013	1	Hex. screw	
7	D501510265	1	Holding pipe	
18	4700500021	2	Hex. screw	
19	4700600006	4	Disc	
20	D938481008	2	Nut	

D501040154 High indicator Scales in inch

Item	Part No	Rem Qty	Description	Code
1	D501040151	1	Hight indicator Zoll / inch, Option	
2	D501040152	1	Hight indicator Zoll / inch, Option	
3	D501040153	1	Hight indicator Zoll / inch, Option	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL