


DYNAPAC

LF50

SPARE PARTS

CATALOGUE

SLF050-1EN1



DYNAPAC

Part of the Atlas Copco Group

Box 504, SE-371 23 Karlskrona, Sweden

Phone: +46 455 30 60 00, Fax: +46 455 30 60 10

www.dynapac.com

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

LF50 From S/N: 27600001-

| Ref. No. | Part No. | Rem. | Qty | Description | Code |
|-----------------|-----------------|-------------|------------|--|-------------|
| 10 | | | 1 | Lifting eye, engine plate, and eccentric (Pagelement installation | |
| 20 | | | 1 | Eccentric element (Page 16) | |
| 30 | | | 1 | Engine and engine installation (Page 24) | |
| 40 | | | 1 | Power transmission (Page 34) | |
| 70 | | | 1 | Handle (Page 40) | |
| 80 | | | 1 | Decals and documenation (Page 46) | |

Transport device installation

| Ref. No. | Part No. | Rem. | Qty | Description | Code |
|-----------------|-----------------|-------------|------------|-----------------------------|-------------|
| 1 | 393159 | | 1 | Bracket | |
| 2 | | | | Transport wheel (Page 14) | |
| 3 | 902287 | | 2 | Nut | |
| 4 | 500510 | | 2 | Screw, flange | |
| 5 | 902041 | | 2 | Screw | |

Cover, right side

| Ref. No. | Part No. | Rem. Qty | Description | Code |
|-----------------|-----------------|-----------------|--------------------|-------------|
| 1 | 396549 | 1 | Cover | |
| 2 | 792119 | 3 | Screw | |
| 5 | | 1 | | |

Engine Robin EH09

| Ref. No. | Part No. | Rem. | Qty | Description | Code |
|-----------------|-----------------|-------------|------------|------------------------|-------------|
| 1 | 396759 | | 1 | Engine, cpl | |
| 2 | 950430 | | 1 | ..Air filter, cpl | |
| 3 | 950439 | | 1 | ..Guide | |
| 4 | 950431 | | 1 | ..Air fliter element | |
| 5 | 238935 | | 1 | ..Fuel strainer, cpl | |
| 6 | 950432 | | 1 | ..Recoil starter, cpl | |
| 7 | 950433 | | 1 | ..Spring | |
| 8 | 950434 | | 1 | ..Reel | |
| 9 | 950435 | | 1 | ..Starter rope | |
| 10 | 950436 | | 1 | ..Handle | |
| 11 | 950437 | | 2 | ..Ratchet | |
| 12 | 950438 | | 1 | ..Spring | |
| 13 | 239718 | | 2 | ..Spring | |
| 14 | 950439 | | 1 | ..Guide | |
| 15 | 950440 | | 1 | ..Holder | |
| 16 | 950441 | | 1 | ..Plate | |
| 17 | 950442 | | 1 | ..Plate | |
| 18 | 239715 | | 1 | ..Screw | |
| 19 | 937530 | | 1 | ..Fuel cap, cpl | |
| 20 | 950454 | | 1 | ..Gasket | |
| 21 | 239706 | | 1 | ..Strainer | |
| 22 | 950449 | | 1 | ..Muffler | |
| 23 | 950450 | | 1 | ..Cover | |
| 24 | 950446 | | 1 | ..Cylinder head gasket | |
| 25 | 950444 | | 1 | ..Valve cover gasket | |
| 26 | 238860 | | 1 | ..Oil level plug | |
| 27 | 910267 | | 1 | ..O-ring | |
| 28 | 910268 | | 1 | ..Oil plug | |
| 29 | 910267 | | 1 | ..O-ring | |
| 30 | 950443 | | 1 | ..Spark plug | |

Handle, standard

| Ref. No. | Part No. | Rem. | Qty | Description | Code |
|----------|-----------|------|-----|--------------------|------|
| 1 | 396315-03 | | 2 | Handle, lower part | |
| 2 | 396316-03 | | 1 | Handle, upper part | |
| 3 | 393220 | | 2 | Link | |
| 4 | 394029 | | 2 | Cover | |
| 5 | 394145 | | 2 | Spacer sleeve | |
| 6 | 541705 | | 4 | Screw | |
| 7 | 394228 | | 2 | Washer | |
| 8 | 791182 | | 4 | Lock nut | M8 |
| 9 | 792497 | | 4 | Disc spring | |
| 10 | 792408 | | 2 | Screw | |
| 11 | 615061 | | 2 | Washer | |
| 12 | 392084 | | 2 | Sleeve bearing | |
| 13 | 391822 | | 2 | Shock absorber | |

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL