


**DYNAPAC**  
**LT6000**  
**SPARE PARTS**  
**CATALOGUE**  
SLT6000-2EN4



***DYNAPAC***

Part of the Atlas Copco Group

Box 504, SE-371 23 Karlskrona, Sweden

Phone: +46 455 30 60 00, Fax: +46 455 30 60 10

[www.dynapac.com](http://www.dynapac.com)

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

**LT6000 From SN: 76103889**

<b>Item</b>	<b>Part No</b>	<b>Rem Qty</b>	<b>Description</b>	<b>Code</b>
10			Handle ( Page 4 )	
20			Ramming system ( Page 8 )	
30			Engine, engine installation and fuel tank ( Page 20 )	
40			Power transmission ( Page 34 )	
80			Decals and documentation ( Page 40 )	

**Spring unit**

Item	Part No	Rem	Qty	Description	Code
1		A	1	Crank shaft	
2	4700381482		2	Plug	
3	4700381479		1	Piston bolt	
4		B	1	Outer tube	
5	4700381961		1	Rod piston head	
6	4700383681		1	Lid	
7	4700380895		2	Spring	
8	4700380894		2	Spring	
9	4700380899		1	Stop	
10	4700383668		1	Rod piston	
11	4700380902		1	Stop	
12	4700283631		2	Hose clamp	
13	4700500023		2	Screw	M8-1,25x40 8,8
14	4700283627		1	Bellows	
15	4700508092		13	Screw	
16	4700388409		1	Bellows support	
17	4700791395		1	Sight plug	
18	4700383666		1	Gasket	
19	4700383669		1	Inner tube	
20	4700384416		1	Handle	
21	4700904951		1	Plug	
22	4700160054		1	O-ring	
23	4700382369		1	Lid	
24	4700162009		6	Seal ring	D
25		C	6	Nut	D
26		C	1	Foot	D
27	4700791376		1	Fiber washer	

- A) See section transmission. item 3
- B) See section transmission, item 28
- C) See section foot

**Engine Honda GX100**

Item	Part No	Rem	Qty	Description	Code
1	4700389872	B	1	Engine, cpl	
	4700379011	C	1	Engine, cpl	
2	4700938934		1	.Spark plug	
3	4700938143		1	.Switch	
4	4700938972		1	.Recoil starter, cpl	
5	4700938973		1	..Rope	
6	4700938974		1	..Grip	
7	4700238303		2	.Gasket	D
8	4700238302		2	.Oil plug	D
9	4700938477		1	.Gasket	
10	4700938977		2	.Oil dipstick, cpl	
11	4700379490		1	Hose	D
12	4700792269		1	Hose clamp	D
13	4700945554		2	Stud	
14	4700379333		1	Hose connection	
15	4700792278		2	Hose clamp	
16	4700379489		1	Hose	
17	4700377180		1	Cyclone, housing	
18	4700377179		1	Cyclone	
19	4700377328		1	Air filter	
20	4700376853		1	Air filter housing	
21	4700377184		1	Cover	
22	4700377424		4	Clips	
23	4700378076	D,E	4	Spacer	
23-A	4700393618	F	4	Spacer	
24	4700378032		1	Bracket	
25	4700500501	D	4	Screw	M6x20
	4700500187	F	4	Screw	M6x60
27	4700508023		4	Screw	
28	4700601001		4	Washer	
29	4700500006		2	Screw	M5x16
30	4700902284		2	Nut	M5
31	4700904281		2	Washer	5,3x10x1 300HV
32	4700904228	F	4	Washer	6,4x12x1,5

B) Old version

C) New version, carburettor with primer pump

D) Old version

E) To change one old spacer, use kit 4700945803. This kit consist of 1x4700393618, 1x4700904228 and 1x4700500187

F) New version

Fuel system for old version of fuel tank

Item	Part No	Rem	Qty	Description	Code
1			1	Fuel tank	
2	4700791574		4	Hose clamp	
3	4700945502		1	Fuel filter	A
4	4700792613	A	1XL	Hose	
5	4700792613	B	1XL	Hose	
6	4700921068		1	Clamp	
7	4700921031		1	Clamp From 76104784	
8	4700500501		1	Screw From 76104784	M6x20
9	4700902285		1	Lock nut From 76104784	M6
10	4700904212		1XL	Conduit From 76104784	
11	4700945546		1	Check valve From 76104784	
12	4700945548		1	Hose From 76104784	
13	4700791574		2	Hose clamp From 76104748	
14	4700945547		1	T-connection From 76104748	
15			1	Hose	

- A) L = 0,14 m
- B) L = 0,35 m

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: [www.heydownloads.com](http://www.heydownloads.com) by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL