

Combilift Ltd	CONTENTS	Model:C5000 SL	Section C
SECTION			
1.	MAINFRAME - CABIN SIDE		
1.1	MAINFRAME - CABIN SIDE CON'D		
1.2	MAINFRAME - ENGINE SIDE		
2.	REAR ARM ASSEMBLY		
3.	RADIATOR ASSEMBLY - DIESEL		
3.1	RADIATOR ASSEMBLY - LPG		
4.	BONNET		
5.	HYDRAULIC TANK		
6.	DIESEL TANK		
7.	CAB ASSEMBLY - INTERIOR		
7.1	CABIN PEDALS		
8.	CAB ASSEMBLY - EXTERIOR		
8.1	CAB DOOR ASSEMBLY		
9.	EXHAUST ASSEMBLY - DIESEL		
9.1	EXHAUST ASSEMBLY - LPG		
10.	AIR FILTER ASSEMBLY		
11.	DIVERTER AND CHANGEOVER VALVES		
12.	STEERING MOTOR		
13.	WHEEL MOTORS		
14.	PUMP MOUNTINGS - DIESEL		
14.1	PUMP MOUNTINGS - LPG		
15.	DASH / STEERING COLUMN		
16.	RELAY BOX ASSEMBLY/LAYOUT		
17.	WATER TIGHT FUSEBOX		
18.	WHEELS		
19.	MAST CARRIAGE		
20.	FORKS		
21.	VALVE BANK FEED AND RETURN LINES		
22.	VALVE BANK TO MAST CONTROL LEVER		
23.	GEAR PUMP SUCTION LINE		
24.	HYDROSTATIC PUMP FEED AND RETURN LINES		
25.	STEERING HYDRAULICS		
26.	STEERING HYDRAULICS CONT'D		
27.	PUMP TO INCHING AND BRAKE VALVES		
28.	OIL COOLER HYDRAULICS		
29.	REAR HUB HYDRAULICS		
30.	FRONT HUB HYDRAULICS		
31.	TILT HYDRAULICS		
32.	MAST CARRIAGE HYDRAULICS		
33.	VALVE BANK TO MAST - DUPLEX		
33.	VALVE BANK TO MAST - FREE LIFT		
34.	MAST		

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Combilift Ltd	Parts List	Model: C5000 SL	Section 03
---------------	------------	-----------------	------------

RADIATOR ASSEMBLY - DIESEL	Last Updated: 24/07/07	Ref No: SLM0003-00
----------------------------	---------------------------	-----------------------

Parts List				
Item	Qty	Description	Ref No	Serial Break
1	1	RADIATOR	SPK00081-00	
2	1	BEEPER MOUNTING	NMF00330-00	
3	2	RADIATOR AV MOUNT	CPC00105-00	
4	1	RADIATOR SUPPORT	NMF00823-00	
5	1	RADIATOR BOBBIN (30MM DIA)	CPC00106-00	
6	1	12V HORN	CPE00011-00	
7	1	REVERSING BEEPER	CPE00059-00	
8	2	RADIATOR HOSE	SPK00019-00	
9	1	KUBOTA ENGINE FAN	NPK00004-00	
10	8	JUBILEE CLIP 40 - 64MM	CPB00258-00	
11	19	8MM FLAT WASHER	CPB00015-00	
12	5	M8 LOCK NUT	CPB00029-00	
13	14	M8x20 HEX HEAD BOLT	CPB00012-00	
14	10	8MM SPRING WASHER	CPB00104-00	
15	2	RADIATOR MOUNT WASHER	CMF00399-00	
16	2	10MM FLAT WASHER	CPB00032-00	
17	2	M10 LOCK NUT	CPB00005-00	

Combilift Ltd		Parts List		Model: C5000 SL	Section 07
CABIN ASSEMBLY - INTERIOR				Last Updated: 25/07/07	Ref No: SLM0007-00
Parts List					
Item	Qty	Description	Ref No	Serial Break	
1	1	JOYSTICK	NPHY0007-00		
2	1	6 PORT DIVERTER VALVE	CPHY0001-00		
3	2	AIR VENT	CPC00025-00		
4	1	INCHING PEDAL	See Section 7.1		
5	1	ACCELERATOR PEDAL	See Section 7.1		
6	1	CABIN SEAT	CPC00101-00		
7	1	STRIKER CLAMP PLATE ASSEMBLY	NMC00524-00		
8	2	WINDSHIELD VENT	CPC00102-00		
9	1	CAB FLOOR PLATE	NMC00509-00		
10	1	DOOR OPEN LIMIT BRACKET	NMC00551-00		
11	1	STRIKER PLATE	NMC00521-00		
12	1	CONTROL COLUMN ACCESS PANEL	NMC00530-00		
13	4	5MM FLAT WASHER	CPB00128-00		
14	4	M5x16 SOCKET CAP BOLT	CPB00247-00		
15	4	6MM FLAT WASHER	CPB00060-00		
16	4	6MM SPRING WASHER	CPB00126-00		
17	4	M6x20 HEX HEAD BOLT	CPB00044-00		
18	3	M6x30 DOME HEAD BOLT	CPB00251-00		
19	13	8MM FLAT WASHER	CPB00015-00		
20	2	M8 LOCK NUT	CPB00029-00		
21	2	M8x20 HEX HEAD BOLT	CPB00012-00		
22	8	M5x12 COUNTER SUNK BOLT	CPB00247-00		
23	2	8MM SPRING WASHER	CPB00104-00		
24	2	M8x90 HEX HEAD BOLT	CPB00103-00		
25	7	M8x20 DOME HEAD BOLT	CPB00183-00		
26	7	10MM FLAT WASHER	CPB00032-00		
27	4	M10 LOCK NUT	CPB00005-00		
28	4	M10x20 HEX HEAD BOLT	CPB00081-00		
29	1	M10 ROD CONNECTOR	CPB00129-00		
30	1	M10x60 HEX HEAD BOLT	CPB00195-00		

Combilift Ltd		Parts List		Model:C5000 SL	Section 09
EXHAUST ASSEMBLY - LPG				Last Updated: 24/07/07	Ref No: SLM0009.1-00
Parts List					
Item	Qty	Description	Ref No	Serial Break	
1	1	FLEXI-EXHAUST	NPL00007-00		
2	1	EXHAUST BRACKET	NMF00033-03		
3	2	EXHAUST CLAMP ASSEMBLY	CPV00033-00		
4	1	2 WAY CATALITIC	CPV00171-00		
5	8	10MM FLAT WASHER	CPB00032-00		
6	8	10MM SPRING WASHER	CPB00053-00		
7	2	M10x35 SOCKET CAP BOLT	CPB00144-00		
8	6	M10x50 HEX HEAD BOLT	CPB00014-00		
9	4	8MM FLAT WASHER	CPB00015-00		
10	4	M8 LOCK NUT	CPB00029-00		

Combilift Ltd	Parts List	Model: C5000 SL	Section 14
---------------	------------	-----------------	------------

PUMP MOUNTINGS - DIESEL	Last Updated: 02/10/07	Ref No: SLM0014-01
-------------------------	---------------------------	-----------------------

Parts List				
Item	Qty	Description	Ref No	Serial Break
1	1	HYDROSTATIC PUMP	SPHY0007-00	
2	1	LH REAR ENGINE MOUNT	SMK00008-01	
3	1	RH REAR ENGINE MOUNT	SMK00009-01	
4	1	V2003T ENGINE	CPK00011-00	
5	1	DIESEL ENGINE MOUNT BRACKET	SMK00011-00	
6	1	BELL HOUSING	SPK00098-00	
7	1	GEAR PUMP	SPHY0058-00	
8	1	GEAR PUMP O RING	CPSK0010-00	
9	1	COUPLING PLATE	SPK00106-00	
10	1	HUB STAR	SPK00107-00	
11	2	MANIFOLD BLOCK	SPHY0002-00	
12	2	HYDROSTATIC PUMP MANIFOLD O RING	SPHY0011-00	
13	2	ENGINE DAMPNER MOUNTS	CPV00005-00	
14	2	ENGINE RUBBER MOUNT WASHER	CMV00028-00	
15	36	10MM FLAT WASHER	CPB00032-00	
16	12	M10x30 HEX HEAD BOLT	CPB00021-00	
17	4	20MM FLAT WASHER	CPB00091-00	
18	24	M10x40 HEX HEAD BOLT	CPB00189-00	
19	4	12MM FLAT WASHER	CPB00082-00	
20	2	M12x30 SOCKET HEAD BOLT	CPB00068-00	
21	8	M12X70 HEAX HEAD BOLT	LPB00006-00	
22	2	M12 NUT	CPB00123-00	
23	2	M12x100 HEX HEAD BOLT	CPB00163-00	
24	4	M20x40 HEX HEAD BOLT	CPB00198-00	

Combilift Ltd	Parts Diagram	Model:C5000 SL	Section 18
---------------	---------------	----------------	------------

WHEELS	Last Updated: 20/07/07	Ref No: SLM0018-00
--------	---------------------------	-----------------------

Parts List				
Item	Qty	Description	Ref No	Serial Break
1	1	REAR WHEEL ASSEMBLY	NPW00002-01	
2	1	REAR WHEEL RIM	NPW00003-00	
3	1	FRONT WHEEL ASSEMBLY	LPW00001-01	
4	1	FRONT WHEEL RIM	LPW00003-00	

--	--	--	--	--

Combilift Ltd	Parts List	Model: C5000 SL	Section 23
---------------	------------	-----------------	------------

GEAR PUMP SUCTION LINE	Last Updated: 23/07/07	Ref No: SLM0023-01
------------------------	---------------------------	-----------------------

Parts List				
Item	Qty	Description	Ref No	Serial Break
1	1	HYDRAULIC TANK	NMH00303-03	
2	1	HYDRAULIC HOSE	NPH00320-00	
3	1	STRAINER ELEMENT	SPHY0009-00	
4	1	GEAR PUMP	SPHY0058-00	
5	3	1" 1/4 BOND SEAL	CPF00059-00	
6	1	1" 1/4 BSP AD MF	CPF00015-00	
7	2	1" 1/4 BSP 1" 5/16" JIC AD MM	CPF00010-00	
8	1	1" 1/4 BALL VALVE	NPF00001-00	

Combilift Ltd	Parts List	Model:C5000 SL	Section 28
---------------	------------	----------------	------------

OIL COOLER HYDRAULICS	Last Updated: 19/09/07	Ref No: SLM0028-01
-----------------------	---------------------------	-----------------------

Parts List				
Item	Qty	Description	Ref No	Serial Break
1	1	HYDRAULIC TANK	NMH00303-03	
2	1	20T50014 OIL COOLER	SPHY0052-00	
3	1	HYDROSTATIC PUMP	SPHY0007-00	
4	1	HYDRAULIC HOSE 1	NPH00324-00	
5	1	HYDRAULIC HOSE 2	NPH00341-00	
6	1	OIL COOLER TEMPERATURE SENDER	SPHY0063-00	
7	1	1/2" BOND SEAL	CPF00056-00	
8	1	M26 BOND SEAL	SPF00057-00	
9	1	M26 1" 1/16 JIC AD MM	SPF00017-00	
10	2	3/ 4" BOND SEAL	CPF00057-00	
11	2	3/ 4" BSP 1" 1/16 JIC AD MM	CPF00019-00	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL