



ERSATZTEILE

SPARE PARTS

PIÈCES DETACHEES



000 001 041 01 H - 11/06/2015

AMT 3200 CV

ab Masch.-Nr.
from mach.-no.
à partir de mach.-no

477 340 - 542 000

/ 000 001 041 01 H /

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

Mähholm mit Lagerung Cutter bar with bearings Lamier avec paliers						477340 - 542000	A M T 3 2 0 0 C V						000 001 041 01	
													448 839 6	7.0
Pos.	ID-Nr.	Benennung	Description	Description	Masch.-Nr-								Bemerkung/Remarks/Remarque	
1	00 930 566 0	Rillenkugellager	Grooved ball bearing	Roulement à gorge	477340 - 510000	8							6306 2RS	
	00 930 343 1	Rillenkugellager	Grooved ball bearing	Roulement à gorge	510001 -	8							6306 2RS C3	
2	00 150 221 0	Lagergehäuse	Bearing housing	Cage de roulement	477340 - 510000	8								
	00 150 503 1	Lagergehäuse -10 Loch	Bearing housing -10 hole	Cage de roulement -10 trou	510001 -	8								
3	00 936 150 2	Radial-Wellendichtring	Radial-shaft sealing ring	Radial-bague d'étanchéité		8							A 40 X 55 X 7	
4	00 146 390 0	Distanzring	Spacer ring	Bague d'écartement		8								
5	00 937 525 0	O-Ring	O-ring	Joint torique		8							30 X 2	
6	00 930 536 1	Rillenkugellager	Grooved ball bearing	Roulement à gorge	477340 - 510000	8							6206 2RS	
	00 930 342 1	Rillenkugellager	Grooved ball bearing	Roulement à gorge	510001 -	8							6206 2RS C3	
7	00 150 017 0	Ritzel	Pinion	Pignon		8							Z= 16	
8	00 937 553 0	O-Ring	O-ring	Joint torique		8							78,5 X 6,0	
9	00 144 238 4	Scheibe	Washer	Rondelle		15							40 X 54 X 4,5	
10	00 909 605 0	Tensirip Mutter	Self-locking nut	Ecrou autobloquant		15							M 14 x 1,5	
11	00 145 095 3	Klemmtopf	Clamping piece	Pièce de serrage		15								
12	00 937 511 0	O-Ring	O-ring	Joint torique		15							45 X 4	
13	00 937 523 1	O-Ring	O-ring	Joint torique		15							28 X 3	
14	00 139 190 0	Stirnrad	Spur gear	Roue d'engrenage		8							Z= 59	
15	00 150 039 0	Stosskante	Sheet edge	Arête du bord à souder		4							X= 127	
17	00 150 123 2	Flachrundschraube	Coach bolt	Vis a tête bombée		15							M 14 X 1,5 X 36 -10.9	
18	00 150 269 0	Gleitkufe	Skid	Lame		x								
19	00 909 910 1	Sperrkantscheibe	Detent edged washer	Disque à bord d'arrêt		x							SKM 12	
20	00 908 758 0	Sicherungsmutter	Locknut	Écrou hex		x							M 10	
21	00 229 321 0	Mähholm	Cutter bar	Lamier		x								
	00 926 101 0	Getriebeöl -Id.-Nr.= 1ltr	Oil -Id.-no.= 1ltr	Huile -Id.-no.= 1ltr		x								
22	00 908 701 0	Sicherungsmutter	Locknut	Écrou hex		x							M 12	
23	00 904 010 0	Senkschraube	Countersunkscrew	Vis à tête fraisée		x							M 10 X 20 -10.9	
24	00 150 028 0	Kufenbefestigung -10 Loch	Skid holder -10 hole	Support de patin -10 trou		8								
27	00 229 326 0	Verschleissblech	Wearing plate	Tôle d'usure		x								
30	00 937 727 0	Dichtring	Gasket ring	Bague d'étanchéité		x							A 18 X 24	
31	00 906 010 1	Verschlusssschraube	Screw plug	Bouchon fileté		x							M 18 X 1,5	
32	00 908 536 4	6kt-Mutter	Hex nut	Écrou hex		8							M 27 X 1,5	
33	00 146 504 0	Abdeckscheibe	Cover disc	Rondelle de recouvrement		8								
34	00 910 864 1	Passscheibe	Shim ring	Cale		8							30 X 42 X 1,0	
	00 910 863 0	Passscheibe	Shim ring	Cale		x							30 X 42 X 0,5	
35	00 906 439 1	Schweißbolzen	Weld. pin	Boulon soude		x							M 12 X 30	
36	00 915 105 0	Passfeder	Fit-in key	Clavette		8							B 10 X 8 X 25	
37	00 150 041 0	Kreiselnabe	Rotor hub	Moyeu de disque		8								
38	00 904 062 0	Senkschraube	Countersunkscrew	Vis à tête fraisée		x							M 12 X 25 -10.9	

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO **DOWNLOAD** THE COMPLETE MANUAL