AT-141-1 42043100038 UPPER

PD2000102-00 SWING UNIT
PG2000113-00 BOOM UNIT
PH1000545-00 SAFETY DEVICES (MOMENT LIMITER)
PJ3000362-00 BUCKET SYSTEM
PK2000429-00 FRAME UNIT
PO1000149-00 INDICATION PLATES
PY1000850-01 OPTIONS,1
PY1000851-01 OPTIONS,2
ASSEMBLY

CLICK HERE TO DOWNLOAD THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO DOWNLOAD THE COMPLETE MANUAL


AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Rema
1		(**********)	FRAME (WITH MOTOR UNIT)	1					
2		(**********)	OUTRIGGER (FRONT)	1					
3		(**********)	OUTRIGGER (REAR)	1					
4		(**********)	PIPING,LOWER (FRAME)	1					
5		(**********)	OPE.ASSY,OUTRIGGER	1					
6		(**********)	ELEC.ASSY (SUB FRAME)	1					
7		(**********)	TANK SUPPORT INSTALLATION	1					
9		(**********)	ELEC.ASSY (POWER SELECT)	1					
31		(**********)	POWER SUPPLY (MOTOR UNIT)	1					
32		(**********)	POWER SUPPLY (BATTERY)	1					
33		(**********)	POWER SUPPLY (CHARGER)	1					
34		(**********)	POWER SUPPLY (WIRING)	1					

AT-141-1 42043100038 UPPER

PY1060000-01 CUTTER HEAD (IZUMI 6.4TON AIR)
PY1060001-00 CUTTER HEAD (IZUMI 6.4TON 2.5M ELECTRIC)
PY1060002-00 CUTTER HEAD (SANWA 6.5TON)
PY1070000-00 ROPE (SAFETY,YELLOW:TD-TYPE)
PY1070000-00 ROPE (SAFETY,YELLOW:TD-TYPE)
PY1070001-00 ROPE (SAFETY,1.5M,WITH HOOK)
PY1080000-02 ARM (STD JIB/WITHOUT INSULATOR)
PY1080002-02 ARM
PY1080003-02 ARM
PY1080004-02 ARM
PY1080005-01 ARM (STD-JIB)
PY1080006-01 ARM
PY1080007-01 ARM (INSULATION JIB)
PY1080027-00 ARM (STD JIB/WITHOUT INSULATOR/PLASTIC)
PY1160049-03 BOOSTER (ELECTRICAL,WITH LIFT)
PY1160053-03 BOOSTER (AIR,WITHOUT BUCKET LIFT)
PY1170016-01 BOOSTER (700KG/CM2)
PY1180092-03 LAMP (FOR SWING FRAME OPERATION)
PY1180143-03 LAMP (BOOM SIDE WORKING LAMP)
PY1180145-02 LAMP (FOR BUCKET OPERATION)
PY1180158-00 LAMP (AML)
PY1180208-00 LAMP (12V60W,WITH CIGARETTE LIGHTER)
PY1500006-02 SELECTOR,BOOSTER (AIR.WITH LIFT)
PY1500009-02 SELECTOR,BOOSTER (VALVE)
PY1500015-02 SELECTOR,BOOSTER (ELECTRIC)
PY1540007-00 COVER,BUCKET (INNER CASE)
PY1540010-02 COVER,BUCKET
PY1590000-02 HOSE,BOOSTER (WITH AIR BALLOON)
PY1590001-01 HOSE,BOOSTER (FEMALE-FEMALE,3M)
PY1590002-02 HOSE,BOOSTER (MAIL-FEMALE,3M)
PY1590007-00 HOSE,BOOSTER (FEMALE-FEMALE,5M)
PY1590008-00 HOSE,BOOSTER (MALE-FEMALE,5M)
PY1590009-00 HOSE,BOOSTER (MALE-FEMALE,8M)
PY1590010-00 HOSE,BOOSTER (WITH AIR BALLOON,2M)
PY1590012-00 HOSE,BOOSTER (WITH AIR BALLOON,5M)
PY1590013-00 HOSE,BOOSTER (WITH AIR BALLOON,8M)
PY1640000-01 DRIL,HYDRAULIC
PY1680000-02 WRENCH,IMPACT (HYDRAULIC)
PY1760001-00 STEP,BUCKET
PY1760001-00 STEP,BUCKET
PY1760003-00 STEP,BUCKET (GRAY,FOR BUCKET INNER)
PY1790001-00 HANGER (FOR BUCKET)
PY1790001-00 HANGER (FOR BUCKET)
PY1790004-01 HANGER (FOR BUCKET,FRP)
PY1930004-00 BLOCK,RUBBER (WAZUMI)
PY1930005-00 BLOCK,RUBBER (NAKAMURA)
PY2120000-00 BOX,TOOL (FOR BUCKET)
PY2120001-00 BOX,TOOL (FOR BUCKET)
PY2130001-00 COVER,LAMP (WORKING)
PY2170001-00 COVER,WINCH
PY2200011-01 INTERPHONE
PY2350003-01 SWITCH,BOOSTER


AT-141-1 42043100038 UPPER
PB1300106-05 JOINT,ROTARY




AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End
2		36634515010	PLUG ASSY	1				
4		36634365120	VALVE,CONTROL (BUCKET LIFT)	1				
5		36634365130	VALVE,CONTROL (BUCKET SWING)	1				
6		36634365140	VALVE,CONTROL (ELEVATING)	1				
7		36634365150	VALVE,CONTROL (SWING)	1				
8		36634365160	VALVE,CONTROL (TELESCOPING)	1				
9		36634365170	VALVE,CONTROL (WINCH)	1				
10		36634365180	VALVE,CONTROL (ATTACHMENT)	1				
11		36634365090	VALVE,RELIEF	1				
24		91002905500	O-RING	8		1B G55		
32		91000501500	O-RING	1		AS568-015		
33		91002802200	O-RING	1		1B P22		
43		36631975010	O-RING	14				
44		36634365190	WIPER,DUST	14				
45		36634365200	RETAINER (SEAL)	14				
54		36630045150	COVER	3				
58		91002801400	O-RING	7		1B P14		
74		12435101180	RETAINER (SEAL)	5				
87		91001100300	O-RING	2		1A P3		
95		91001101001	O-RING	1		1A P10A		
96		36634365100	RING,BACKUP	1				
97		19215101010	O-RING	2				
103		91001001600	O-RING	2		1A S16		
105		36634365110	RING,BACKUP	1				
106		91001100600	O-RING	1		1A P6		
119		13115102010	RETAINER (SEAL)	2				
200		36634360002	VALVE,MANUAL CONTROL (BUCKET)	1				

AT-141-1 42043100038 UPPER
PB1370053-02 POWER SUPPLY (BATTERY)





AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks
1		37000908730	JOINT (WITH O-RING)	2		L,G3/8-G1/4			
2		37002413050	HOSE	1		L=280			
3		37002425720	HOSE	1		L=295			
5		90101210016	BOLT	2		M10X16			
6		90302041001	WASHER,SPRING	2		10			
7		37000508030	PLATE	1					
8		91810132530	FASTENER	5					
9		82100001412	TUBE,SPIRAL	2	M	SE-12BK			
31		42343590500	FITTING,FLANGE	1					
32		36624970000	VALVE,PILOT CHECK	1					
33		90172110060	BOLT,HEXAGON SOCKET	4		M10X60			
34		37000914970	JOINT	2					
35		91002801100	O-RING	4		1B P11			
36		80430620400	JOINT	2					
41		91002801400	O-RING	2		1B P14			

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks
1		(**********)	OUTRIGGER (FRONT)	1					
3		(**********)	COVER (OUTRIGGER SIDE)	1					

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks
2		42650337510	BOARD	1					
4		42650337560	PANEL	1					
9		82100001408	CONNECTOR (SEAL)	1					
10		82100001409	CONNECTOR (SEAL)	1					
11		42650337530	CABLE	1					
12		42350427560	CABLE	1					
50		42650334003	INDICATOR,OUTRIGGER	1					

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks
1		36080905010	GEAR,SPUR	1					
2		36080095020	RING,SEAL	1					
3		91001207000	O-RING	1		1A G70			
4		91216105001	SEAL,OIL	1					
5		80515006314	BEARING,BALL	1					
7		36080895030	WHEEL,WORM	1					
8		36080895040	KEY	1					
9		80516006212	BEARING,BALL	1					
11		90102510025	BOLT	6		M10X25			
12		90302041001	WASHER,SPRING	6		10			
13		80562100120	WASHER,PLAIN	1		AW12			
14		80561100120	NUT	1		AN12			
17		12643302100	RETAINER	1					
18		91001208500	O-RING	1		1A G85			
19		12643302120	SHIM (T=0.1)	N					
20		12643302130	SHIM (T=0.2)	N					
21		12643302140	SHIM (T=0.3)	N					
22		36080095120	BEARING,ROLLER	2					
23		36080095090	WORM	1					
24		80316090040	PLUG SOCKET	1		R1/4			
25		36080095110	SEAL,OIL	1					
28		36080095072	GAUGE,OIL	1					
29		36080235080	WASHER,SEAL	1		M16			
41		90102510025	BOLT	6		M10X25			
42		90302041001	WASHER,SPRING	6		10			
51		36080905020	CASE ASSY	1					
100		36080900000	REDUCER,SWING SPEED	1					


AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks
1		36340255010	DRUM,SHAFT	1				226193	
		36340255011	DRUM,SHAFT	1			226194		
2		36340165020	SLEEVE	1					
3		91216055002	SEAL,OIL	1					
4		80500006009	BEARING,BALL	2				226193	
		80500006009	BEARING,BALL	1			226194		
5		90131708020	BOLT,HEXAGON SOCKET	8		M8X20			
6		36340255020	HOUSING	1					
7		91001210000	O-RING	1		1A G100			
8		36340255030	WHEEL,WORM	1				226193	
		36340255031	WHEEL,WORM	1			226194		
9		36340255040	CASE,GEAR	1				226193	
		36340255041	CASE,GEAR	1			226194		
10		36340255050	KEY	2				226193	
11		36340255070	PLUG	1					
12		80316090060	PLUG	2		KKT PT3/8			
13		80316090020	PLUG	1		KKT PT1/8			
14		80601110400	RING,RITAINING	1		S40			
15		80500006008	BEARING,BALL	1					
16		36340255060	WORM	1					
17		80513006306	BEARING,BALL	1					
18		36340165070	RETAINER	1					
19		80561100060	NUT	1		AN06			
20		80562100060	WASHER,TOOTH	1		AW06			
21		90102208025	BOLT	4		M8X25			
22		90302040801	WASHER,SPRING	4		8			
23		80500006207	BEARING,BALL	1			226194		
30		36340250000	WINCH (1-PART LINE)	1					

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1		37001002260	SHEAVE	1						
3		80601110350	RING,RITAINING	2		S35				
4		42220041010	COVER	2						
5		42220041020	PIN	1						
6		42220011200	SUPPORT	1						
7		90201201600	NUT	1		M16				
8		42220041101	JIB (L=2000)	1						
9		90303071601	WASHER,PLAIN	1		16				
10		42220041200	PIN	1						
11		80620210080	PIN,SNAP	1						
12		42220041050	PLATE,NAME	2						
13		37000302490	SPACER	2		L=2				
14		37000302290	SPACER	2						
21		80516006207	BEARING,BALL	1						

AT-141-1 42043100038 UPPER
PG1050148-04 CYLINDER,TELESCOPING



△:PACKING SET KEY NO. 100 (KEY NO.2,4,5,6,7,8,9,14,16,17,18,25)

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	
93		42340234230	ROLLER	3		W=12			
94		42340234240	ROLLER	4		W=9			
95		42340234210	ROLLER	4					
96		42340234200	PIN	1					
97		80136320016	PIN,SPLIT	2		2X16			
98		90303100801	WASHER,PLAIN	24		8			
101		80192486014	SCREW,MACHINE (WITH WASHER)	10		M6X14			
104		42340233010	PLATE	1					
105		42340233020	PLATE	1					
106		42340233030	COVER	1					


AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Rema
4		82105410110	SWITCH,TOGGLE	1					
6		82197518119	CAP (PLUS ONE MFG./BLACK)	1					
		82197518114	CAP (MATSUSHITA/BLACK)	1					
7		82100001382	SWITCH,PUSH (BLACK)	1					
21		82100001169	BUTTON (BLACK)	1					
100		42473710011	HARNESS	1					


AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pag
1		36661655010	SEAL KIT	1						
10		36661650000	MOTOR,HYDRAULIC	1						


AT-141-1 42043100038 UPPER
PI1120096-00 VALVE,SOLENOID



AT-141-1 42043100038 UPPER
PI1140133-01 VALVE,CHECK



AT-141-1 42043100038 UPPER
PI1280074-00 VALVE,PILOT CHECK



AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	R
69		37000917210	FITTING	1		PF1/4XPF1/4			
70		37000918990	JOINT	1					
71		80313020080	GASKET	2					
72		91001001800	O-RING	2		S18			
74		91810130230	FASTENER	2					
81		42341860110	JOINT	1					
82		80430410450	JOINT	18					
83		80430410650	JOINT	12					
91		42341860210	JOINT	1					
94		37000918520	JOINT	1					
95		80306030020	JOINT,NIPPLE	1					
96		36630950000	VALVE	1					
111		42340017510	CAP (DUST)	1					
121		42340017550	CAP (DUST)	1					

CLICK HERE TO DOWNLOAD THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO DOWNLOAD THE COMPLETE MANUAL


AT-141-1 42043100038 UPPER


Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1		42230291500	TABLE,SLEWING	1						
2		32610010040	PLATE	1						
3		90101208012	BOLT	2		M8X12				
4		90302040801	WASHER,SPRING	2		8				
5		90101716070	BOLT	15						
6		90303501601	WASHER,PLAIN	15		16				
7		37000507560	PLATE	1						
8		90101510022	BOLT	3		M10X22				
9		90302041001	WASHER,SPRING	3		10				
10		37000112690	PIN	1						
11		37000509190	PLATE	1						
12		90101512030	BOLT	2		M12X30				
13		90302041201	WASHER,SPRING	2		12				
14		37000144420	PIN	1						
15		37000112150	PIN	1						
16		37000505950	PLATE	1		T=3.2				
17		37000507730	PLATE	1						
18		90103520045	BOLT	1		M20X45				
19		90302042001	WASHER,SPRING	1		20				
20		82400000205	GROMMET	1						
21		42340240700	GROMMET	8						
22		42230290010	GROMMET	1						

AT-141-1 42043100038 UPPER


Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1		16715402000	FITTING,ELBOW	1						
2		16715403000	SLEEVE	2						
3		16715404000	NIPPLE	2						
4		81408000051	PIPE,STEEL	1	M	6X1.2T				
5		16715401000	NIPPLE	1						
6		82456201000	NIPPLE,GREASE	1		A-TYPE PT1/8				

AT-141-1 42043100038 UPPER
PN1010738-02 ELEC.ASSY (MOTOR UNIT)







AT-141-1 42043100038 UPPER
PN1030014-00 OPTICAL CABLE



AT-141-1 42043100038 UPPER
PN1350022-00 REEL,CORD



AT-141-1 42043100038 UPPER
PO1011525-02 PLATE,INDICATION



AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pa
2		42470721010	JOINT	2				229107		
		37000933940	JOINT	2			229108			
3		42470721301	PRUNER	1						
4		80456020410	JOINT,SELF SEALING	1						
5		80456010410	JOINT,SELF SEALING	1						
6		42470721200	HOSE ASSY	1						
7		42470721100	COVER	1						
8		91000590800	O-RING	2		AS568-908	229108			
21		42470727530	CAP (DUST)	1						
24		42470727540	CAP (DUST)	1						
26		42470727520	CAP (DUST)	1						
27		42470727510	CAP (DUST)	1						
51		42340017540	CAP	1						
61		42340017530	CAP	1						

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Se
1		42470980100	SWITCH,PUSH	1			
2		82100002220	CABLE	5	M		
3		82100002173	CONNECTOR	1			
10		42470985000	SWITCH BOX (ELECTRIC BOOSTER, 5M,NANABOSI,SINKOU DENKI)	1			

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)
1		42470341000	ACCESSORIES (BUCKET INNER MAT)	1				

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Seria
1		42460012540	WEDGE (STOPPER FOR TIRE/NAKAMURA KIKI)	1				

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	R
1		42470230000	CLAMP HEAD (IZUMI 12TON 3.5M)	1					

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No
1		42472640000	CLAMP HEAD (IZUMI 8TON 3.5M ELECTRIC)	1				

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	
1		42470330000	ROPE (SAFETY,YELLOW:TD-TYPE)	1					

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1		42470121000	ARM ASSY	1						
2		42470122000	HOLDER	3						
3		42470123000	CLAMP ASSY	1						
4		42470044000	HOT STICK	1						
5		42470422000	SUPPORT	1						
6		90101216140	BOLT	1		M16X140				
7		90303071601	WASHER,PLAIN	1		16				
8		90201201600	NUT	1		M16				
21		90101210025	BOLT	6		M10X25				
22		90302041001	WASHER,SPRING	6		10				
24		42470601010	SUPPORT	3						
28		42470601050	SUPPORT	1						
31		42470121100	ARM	1						
32		42470121200	CAP	2						

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1		42470121000	ARM ASSY	1						
2		42471231000	HOLDER	3						
3		42470123000	CLAMP ASSY	1						
4		42470044000	HOT STICK	1						
5		42470045000	SUPPORT	1						
6		90101216130	BOLT	1		M16X130				
7		90303071601	WASHER,PLAIN	1		16				
8		90201201600	NUT	1		M16				
31		42470121100	ARM	1						
32		42470121200	CAP	2						

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks	Pages
1		42473730100	SUPPORT	1						
2		82100000711	CLAMP	10						
3		91810130240	FASTENER	10						
4		42473730010	HARNESS	1						
5		82100002563	LAMP,LICENSE	1						
6		42470450020	SWITCH,TOGGLE	1						
7		42473730020	COVER	1						
8		90101206010	BOLT	2		M6X1.0				
9		90302040601	WASHER,SPRING	2		6				
10		90201200500	NUT	1		M5				
11		90303070501	WASHER,PLAIN	1		5				
12		91810130230	FASTENER	1						
13		42473730500	SUPPORT	2						
14		90101208020	BOLT	2		M8X20				
15		90302040801	WASHER,SPRING	1		8				
21		82100000783	BULB,LAMP	1		24V 12W				
36		82105410110	SWITCH,TOGGLE	1						

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (E
1		42473530020	GASKET	2				
2		42470510100	PLATE,NAME	2				
3		80456240600	JOINT,SELF SEALING (WITH DUST CAP)	1				
4		42473531000	SELECTOR,BOOSTER (VALVE)	1				
5		37002450540	HOSE	1		L=325 TO 350		
6		42473532500	LEVER ASSY	1				
7		90101506012	BOLT	2		M6X12		
8		90302040601	WASHER,SPRING	2		6		
9		36631120050	NUT	2		M20		
10		42473530010	PLATE	1				
11		42310040050	ROPE (TETORON)	1				
12		82100001735	SLEEVE	2				
14		91810130240	FASTENER	1				
21		82430208020	GRIP	1				
31		42471437520	CAP	1				

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (E
1		80456210600	JOINT,SELF SEALING	1				
2		42470367750	HOSE ASSY	1		3M		
3		42470362100	JOINT,SELF SEALING	1				
4		42470367770	HOSE,AIR	1		3M		
5		42470362200	PUMP	1				
6		80456240600	JOINT,SELF SEALING (WITH DUST CAP)	1				
7		42470367840	TUBE	2		25X0.15M		
8		42470367780	JOINT	1				
21		42471437520	CAP	1				
50		42470362000	HOSE,BOOSTER	1		L=3000		

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (E
5		80456210600	JOINT,SELF SEALING	1				
6		80456240600	JOINT,SELF SEALING (WITH DUST CAP)	1				
11		42471437520	CAP	1				
30		42471084000	HOSE,BOOSTER (MALE-FEMALE,8M)	1				

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)
1		42472191000	WRENCH,IMPACT	1				
2		80460003080	JOINT	2		S,G3/8-3/4-16UNF		
3		37002417130	HOSE	2		L=2900		
4		91810132530	FASTENER	5				
5		80456020610	JOINT,SELF SEALING	1				
6		42340013200	JOINT,SELF SEALING (WITH CAP)	1				
11		42340017550	CAP (DUST)	1				
16		42340017510	CAP (DUST)	1				

AT-141-1 42043100038 UPPER

Pos No.		Parts No	Parts Name	Qty	Unit	Technical Data	Serial No (Start)	Serial No (End)	Remarks
1		42474160000	HANGER (FOR BUCKET)	1					

CLICK HERE TO DOWNLOAD THE COMPLETE MANUAL

- Thank you very much for reading the preview of the manual.
- You can download the complete manual from: www.heydownloads.com by clicking the link below



- Please note: If there is no response to CLICKING the link, please download this PDF first and then click on it.

CLICK HERE TO DOWNLOAD THE COMPLETE MANUAL